

# MMS 6

Service instructions



Original service instructions.

**CONTENTS**

	Page
<b>1. Symbols used in this document</b>	<b>2</b>
<b>2. Identification</b>	<b>2</b>
2.1 Nameplate	2
2.2 Type key	3
<b>3. Tightening torques and lubricants</b>	<b>3</b>
<b>4. Service tools</b>	<b>4</b>
4.1 Special tools	4
4.2 Standard tools	5
4.3 Torque tools	5
<b>5. General information</b>	<b>6</b>
5.1 Position numbers	6
5.2 Before dismantling	6
5.3 Before assembly	6
5.4 During assembly	6
<b>6. Inspection</b>	<b>6</b>
<b>7. Dismantling and assembly</b>	<b>6</b>
7.1 Dismantling the motor	6
7.2 Assembling the motor	7
<b>8. Maintenance and service</b>	<b>8</b>
<b>9. Fault finding</b>	<b>9</b>
<b>10. Checking motor and cable</b>	<b>10</b>
<b>11. Winding resistances</b>	<b>11</b>
11.1 50 Hz	11
11.2 60 Hz	19
<b>12. Drawings</b>	<b>27</b>
12.1 5.5 - 37 kW, 7.5 - 50 hp	27

**1. Symbols used in this document**



**Warning**  
If these safety instructions are not observed, it may result in personal injury.



**Warning**  
If these instructions are not observed, it may lead to electric shock with consequent risk of serious personal injury or death.



**Warning**  
These instructions must be observed for explosion-proof pumps. It is advisable also to follow these instructions for standard pumps.

**Caution**

If these safety instructions are not observed, it may result in malfunction or damage to the equipment.

**Note**

Notes or instructions that make the job easier and ensure safe operation.

**2. Identification**

**2.1 Nameplate**




Fig. 1 Nameplate

Pos.	Description
1	Pump generation (A = first generation)
2	Output power in [kW] and [hp]
3	Product number
4	Type designation
5	Number of phases
6	Supply voltage
7	Frequency
8	Max. liquid temperature for flow past the motor
9	Motor designed for continuous operation
10	Temperature sensor (Pt100)
11	CE mark
12	Maximum operating pressure
13	Service factor
14	Serial number
15	Power factor
16	Production code and date of production (YYWW)
17	Rated speed in [min <sup>-1</sup> ]
18	Rated current
19	Net weight in [kg] and [lb]
20	Enclosure class
21	Country of origin
22	Connection of motor windings
23	Locked-rotor current [kVA] per [hp]
24	Bar code

TM04 3945 3709


## 2.2 Type key

Example	MMS	6	R	E	S	D	T60
<b>Type range</b> MMS: Motor, submersible, rewindable							
<b>Motor diameter [inch]</b> 6: 6							
<b>Material</b> Blank: cast iron, EN-JL-1040 N: stainless steel, EN 1.4401 (AISI 316) R: stainless steel, EN 1.4539 (AISI 904L)							
<b>Rubber parts</b> Blank: NBR E: FKM							
<b>Shaft seal</b> Blank: ceramic/carbon S: SiC/SiC							
<b>Motor liquid</b> Blank: SML-3 D: demineralised water							
<b>Temperature</b> T30: 30 °C (37 kW, PVC-insulated windings) T35: 35 °C (5.5 to 30 kW, PVC-insulated windings) T50: 50 °C (PE2/PA-insulated windings) Txx: xx °C (derating + PE2/PA-insulated windings)							

## 3. Tightening torques and lubricants

Pos.	Designation	Number	Dimensions	Torque [Nm]	Lubricant
213	End cover	1		160	Vaseline oil
219	Thrust bearing housing			180	Vaseline oil
226	Shaft seal housing	1		160	Vaseline oil
235	Intermediate housing	1		200	Vaseline oil
235a	Screw	4	4 mm	3	
236	Lower bearing housing			200	Vaseline oil
247	Screw	3	M8 x 25	20	
248	Screw	1	M8 x 10	20	

## 4. Service tools



### 4.1 Special tools

Pos.	Description	For pos.	Further information	Part number
A	Tool for end cover	213		95927376
B	Tool for thrust bearing housing	219		96163771
C	Tool for lock nut	216		95927467
D	Tool for shaft	202, 216		96163797
E	Punch for shaft seal	226b		V7216306
F	Jaws	201		00SV7900
G	Shaft height gauge	201, 202		00SV0305
H	Strap wrench	213, 219, 236	48"	00SV0853
I	Tool for lower bearing housing	236		95927377
J	Tool for intermediate housing	235		95927380
K	Tool for shaft seal housing	226		95927378
L	Shaft height gauge	201, 202	6"	00SV0115

#### 4.2 Standard tools

Pos.	Description	For pos.	Further information	Part number
<i>M</i>	Tee key	215, 247, 235a	M4 - 4 mm	00SV0181
			M6 - 5 mm	00SV0124
			M8 - 6 mm	00SV0050
<i>N</i>	Rubber mallet	226b, 232		00SV0349
<i>O</i>	Ratchet			96777072
<i>P</i>	Funnel			-
<i>Q</i>	Screwdriver	226b		00SV0804
<i>R</i>	Ring/open-end spanner	236	27 mm	00SV0084
		235	36 mm	
<i>S</i>	Hexagon head driver	247, 248	M8 - 6 mm	00SV0296
<i>T</i>	Hexagon socket	213, 226, 236	27 mm	00SV0427
		235	36 mm	

#### 4.3 Torque tools

Pos.	Description	For pos.	Further information	Part number
<i>U</i>	Torque wrench	213, 226, 236		

## 5. General information

### 5.1 Position numbers

Position numbers of motor parts (digits) refer to exploded view and sectional drawing in section 12. *Drawings*; position numbers of service tools (letters) refer to section 4. *Service tools*.

### 5.2 Before dismantling

- Switch off the power supply to the motor.
- Disconnect the power supply cable in accordance with local regulations.

### 5.3 Before assembly

- Clean and check all parts.
- Replace defective parts by new parts.
- Order the necessary service kits.
- Always replace gaskets and O-rings when the motor is serviced.

### 5.4 During assembly

Lubricate and tighten screws and nuts to the correct torque. See section 3. *Tightening torques and lubricants*.

## 6. Inspection

1. Check the cable for any visible damage.
2. Check the winding and insulation resistance. See section 10. *Checking motor and cable*, steps 3 and 4.
3. Check that the hole in end cover (pos. 213) is not blocked.
4. Through the hole in end cover (pos. 213), check that diaphragm (pos. 212) is intact.
5. Remove and check air vent valve (pos. 223a).
6. Check that shaft with rotor (pos. 202) rotates freely and noiselessly.
7. Remove sand shield (pos. 229).
8. Check the distance between rotor shaft end (pos. 202) and stator housing (pos. 201) with a shaft height gauge (pos. G) or (pos. L). The distance must be  $72.8 \pm 0.2$  mm.
9. If the distance is not within the above tolerances, adjust the height. See section 7.1 *Dismantling the motor* and 7.2 *Assembling the motor*.
10. Drain the motor liquid. See section 7.1 *Dismantling the motor*, steps 1 to 4.
11. Remove shaft seal housing (pos. 226) with tool for shaft seal housing (pos. K) and a ring/open-end spanner (pos. R).  
**Note:** Left-hand thread.
12. Check the spring action of rotating shaft seal part (pos. 226b), and check for excessive wear and visible damage. Replace the shaft seal if necessary.
13. Remove cable entry components (pos. 250, 250c, 250a and 250b) and NEMA flange (pos. 205).  
See section 7.1 *Dismantling the motor*, steps 22 to 26.
14. Check the bearing surfaces of NEMA flange (pos. 205).
15. Remove two screws (pos. 235a) and intermediate housing (pos. 235) with tool for intermediate housing (pos. J) and a ring/open-end spanner (pos. R).  
**Note:** Left-hand thread on housing.
16. Check that motor cable (pos. 220) is properly connected to the stator.
17. Check that the upper part of winding coil (pos. 201b) is intact.
18. Remove end cover (pos. 213) and thrust bearing components. See section 7.1 *Dismantling the motor*, steps 5 to 13.
19. Check rotating thrust bearing (pos. 206).
20. Remove screw (pos. 235a) and lower bearing housing (pos. 236) with tool for lower bearing housing (pos. I) and a ring/open-end spanner (pos. R).
21. Check the bearing surfaces of lower bearing housing (pos. 236).
22. Check that the lower part of winding coil (pos. 201b) is intact.
23. Remove shaft with rotor (pos. 202).
24. Check that the rotor lamination is intact.

25. Assemble the motor. See section 7.2 *Assembling the motor*.


## 7. Dismantling and assembly

### 7.1 Dismantling the motor

1. Place the motor horizontally in jaws (pos. F) and tighten jaws (pos. F).
2. Remove plug (pos. 223b) and seal washer (pos. 222c).
3. Remove air vent valve (pos. 223a) and O-ring (pos. 222b).
4. Place stator housing (pos. 201) in a tilted position with end cover (pos. 213) pointing downwards and drain motor liquid into a bucket.
5. Remove end cover (pos. 213) with tool for end cover (pos. A).
6. Remove O-ring (pos. 224b) from thrust bearing housing (pos. 219).
7. Remove two set screws (pos. 215).
8. Remove thrust bearing support (pos. 208b).
9. Remove screw (pos. 235a) and thrust bearing housing (pos. 219) with tool for thrust bearing housing (pos. B).
10. Remove thrust bearing (pos. 203).
11. Remove O-ring (pos. 224a) from lower bearing housing (pos. 236).
12. Slacken lock nut (pos. 216) with tool for lock nut (pos. C) and for shaft (pos. D).
13. Remove lock nut (pos. 216), washer (pos. 216a), rotating thrust bearing (pos. 206), thrust ring (pos. 208a) and upthrust disc (pos. 242) from shaft with rotor (pos. 202), and check if they are worn or damaged.
14. Remove screw (pos. 235a) and lower bearing housing (pos. 236) with tool for lower bearing housing (pos. I) and a ring/open-end spanner (pos. R).
15. Remove lower coil head protector (pos. 201a).
16. Remove O-ring (pos. 224b) from stator housing (pos. 201).
17. Remove sand shield (pos. 229).
18. Remove shaft seal housing (pos. 226) with tool for shaft seal (pos. K) and a ring/open-end spanner (pos. R).  
**Note:** Left-hand thread.
19. Remove O-ring (pos. 231).
20. Remove stationary shaft seal part (pos. 226a) from shaft seal housing (pos. 226).
21. Knock lip seal (pos. 232) out of shaft seal housing (pos. 226) with a screwdriver (pos. Q) and a rubber mallet (pos. N). It may stick.
22. Unscrew two screws (pos. 248).
23. Remove cable entry components (pos. 250, 250c, 250a and 250b) and NEMA flange (pos. 205).
24. Unscrew three screws (pos. 247) with a tee key (pos. M).
25. Remove NEMA flange (pos. 205) and rotating shaft seal part (pos. 226b).
26. Remove screw (pos. 173a) with a tee key (pos. M) and washer (pos. 173b), and remove earth cable (pos. 173h).
27. Remove gasket (pos. 234).
28. Remove two screws (pos. 235a) and intermediate housing (pos. 235) with tool for intermediate housing (pos. J) and a ring/open-end spanner (pos. R).  
**Note:** Left-hand thread on housing.
29. Remove upper coil head protector (pos. 201a).
30. Remove O-ring (pos. 224b).
31. Pull shaft with rotor (pos. 202) out of the non-drive end of stator housing (pos. 201).

## 7.2 Assembling the motor


1. Fit lower coil head protector (pos. 201a) in stator housing (pos. 201).
2. Insert shaft with rotor (pos. 202) carefully into stator housing (pos. 201) from the non-drive end.
3. Fit O-ring (pos. 224b).
4. Fit upper coil head protector (pos. 201a) in stator housing (pos. 201).
5. Lubricate the thread of the drive end of stator housing (pos. 201).
6. Fit intermediate housing (pos. 235) on stator housing (pos. 201) with tool for intermediate housing (pos. J) and a torque wrench (pos. U) with a hexagon socket (pos. T), and tighten it. Fit and tighten two screws (pos. 235a). See section 3. *Tightening torques and lubricants*.  
**Note:** Left-hand thread on housing.
7. Fit gasket (pos. 234) on intermediate housing (pos. 235).
8. Pull motor cable (pos. 220) through the cable entry hole in intermediate housing (pos. 235).
9. Fit earth cable (pos. 173h) with screw (pos. 173a) and washer (pos. 173b).
10. Fit NEMA flange (pos. 205) on intermediate housing (pos. 235).
11. Tighten three screws (pos. 247) using a torque wrench (pos. U) with a hexagon head driver (pos. S). See section 3. *Tightening torques and lubricants*.
12. Fit cable entry components (pos. 250, 250c, 250a and 250b) and NEMA flange (pos. 205).
13. Tighten two screws (pos. 248) using a torque wrench (pos. U) with a hexagon head driver (pos. S). See section 3. *Tightening torques and lubricants*.
14. Fit O-ring (pos. 224b) on stator housing (pos. 201).
15. Lubricate the thread of the non-drive end of stator housing (pos. 201).
16. Fit lower bearing housing (pos. 236) on stator housing (pos. 201) and tighten it with tool for lower bearing housing (pos. I), a torque wrench (pos. U) with a hexagon socket (pos. T) and a strap wrench (pos. H). Fit and tighten screw (pos. 235a). See section 3. *Tightening torques and lubricants*.
17. Fit O-ring (pos. 224a) on lower bearing housing (pos. 236).
18. Fit upthrust disc (pos. 242), thrust ring (pos. 208a) and rotating thrust bearing (pos. 206) on shaft with rotor (pos. 202). See fig. 2 for correct assembly of thrust ring (pos. 208a) and rotating thrust bearing (pos. 206).



**Fig. 2** Assembly of thrust ring and rotating thrust bearing


19. Fit washer (pos. 216a) and lock nut (pos. 216). Tighten lock nut (pos. 216) with tool for lock nut (pos. C) and for shaft (pos. D).
20. Lubricate the thread of the drive end of lower bearing housing (pos. 236).

21. Screw thrust bearing housing (pos. 219) on lower bearing housing (pos. 236) while holding thrust bearing (pos. 203) in position with a finger through the hole in thrust bearing housing (pos. 219). See fig. 3.




**Fig. 3** Fitting the thrust bearing housing

22. Tighten thrust bearing housing (pos. 219) with tool for thrust bearing housing (pos. B), a torque wrench (pos. U) and a strap wrench (pos. H). Fit and tighten screw (pos. 235a). See section 3. *Tightening torques and lubricants*.
23. Fit thrust bearing support (pos. 208b).
24. Check the distance between rotor shaft end (pos. 202) and stator housing (pos. 201) with a shaft height gauge (pos. G) or (pos. L). The distance must be  $72.8 \pm 0.2$  mm.



**Fig. 4** Measuring shaft end height

25. Turn thrust bearing support (pos. 208b) to adjust the distance. See fig. 5.



**Fig. 5** Adjusting shaft end height

26. Repeat steps 25 and 26 until the distance is correct. The distance must be  $72.8 \pm 0.2$  mm.
27. Apply a suitable threadlocker to the thread of two set screws (pos. 215) and fit them in thrust bearing support (pos. 208b). Tighten two set screws (pos. 215) with a tee key (pos. M).
28. Fit O-ring (pos. 224a) on thrust bearing housing (pos. 219).
29. Lubricate the thread of thrust bearing housing (pos. 219).
30. Screw end cover (pos. 213) onto thrust bearing housing (pos. 219) and tighten it with tool for end cover (pos. A), a torque wrench (pos. T) and a strap wrench (pos. H). See section 3. *Tightening torques and lubricants*.
31. Fit plug (pos. 223b) and seal washer (pos. 222c).
32. Lubricate rotor shaft end (pos. 202) and rotating shaft seal part (pos. 226b) with motor liquid.
33. Fit rotating shaft seal part (pos. 226b) on shaft with rotor (pos. 202) with a soft punch (pos. E) and a rubber mallet (pos. N).

TM03 9284 3707

TM03 9282 3707

TM03 9285 3707

TM03 9142 3407

34. Fit a new lip seal (pos. 232) in shaft seal housing (pos. 226) with the flat side towards the motor. Use a soft punch (pos. E) and a rubber mallet (pos. N).
35. Press a new stationary shaft seal part (pos. 226a) into shaft seal housing (pos. 226) with the white side towards the motor. Use a soft punch (pos. E).
36. Check that stationary shaft seal part (pos. 226a) is positioned correctly in shaft seal housing (pos. 226).
37. Fit O-ring (pos. 231) on shaft seal housing (pos. 226).
38. Fit and tighten shaft seal housing (pos. 226) using a torque wrench (pos. U), tool for shaft seal housing (pos. K) and a strap wrench (pos. H). See section 3. *Tightening torques and lubricants*. **Note:** Left-hand thread.
39. Press sand shield (pos. 229) on shaft with rotor (pos. 202), and check that the shaft rotates freely and noiselessly.
40. Fit a new O-ring (pos. 222b) on air vent valve (pos. 223a). Fit air vent valve (pos. 223a) in end cover (pos. 213) and tighten it.

#### 7.2.1 Filling of motor liquid

1. Place stator housing (pos. 201) in a tilted position with the drive end pointing upwards.
2. Fill stator housing (pos. 201) with liquid through hole for air vent valve (pos. 223a) using a funnel (pos. P). Turn shaft with rotor (pos. 202) to let air escape. Repeat until stator housing (pos. 201) has been filled.
3. Fit and tighten air vent valve (pos. 223a).

## 8. Maintenance and service



### **Warning**

***If used in a liquid which is injurious to health or toxic, the motor will be classified as contaminated.***

If Grundfos is requested to service a contaminated motor, Grundfos must be contacted with details about the pumped liquid, etc. *before* the motor is returned for service. Otherwise Grundfos can refuse to accept the motor for service.

Possible costs of returning the motor are paid by the customer.



## 9. Fault finding



### Warning

**Before fault finding, remove the fuses or switch off the mains switch. Make sure that the power supply cannot be accidentally switched on.**

**All rotating parts must have stopped moving.**







### Warning

**All regulations applying to pumps installed in potentially explosive environments must be observed.**

**No work must be carried out in potentially explosive atmosphere.**

Fault	Cause	Remedy
1. The motor does not run.	a) Fuses are blown.	Replace the fuses. Check the electrical installation and the submersible drop cable if the new fuses burn too.
	b) The ELCB or voltage-operated ELCB has tripped out.	Cut in the circuit breaker.
	c) No power supply.	Contact the power supply company.
	d) Motor-protective circuit breaker has tripped.	Cut in the motor-protective circuit breaker (takes place automatically or must be done manually). Check the voltage if the motor-protective circuit breaker trips again. If the voltage is okay, see the items e) to h).
	e) Motor-protective circuit breaker or contactor is defective.	Replace the motor-protective circuit breaker or contactor.
	f) Starter device is defective.	Repair or replace the starter device.
	g) Control circuit has cut out or is defective.	Check the electrical installation.
	h) Motor or submersible drop cable is defective.	Repair or replace the motor or the submersible drop cable.

## 10. Checking motor and cable

<p>1. Supply voltage</p>  <p style="text-align: right; font-size: small;">TM00 1371 5092</p>	<p>Measure the voltage between the phases by means of a voltmeter on the terminals where the submersible drop cable is connected.</p>	<p>When the motor is loaded, the voltage should be within the required voltage quality for Grundfos MS and MMS submersible motors which - measured at the motor terminals - is - 10 %/+ 6 % of the rated voltage for continuous operation (including variation in the supply voltage and losses in cables). Check also that there is voltage symmetry in the power supply lines, i.e. the same difference of voltage between the individual phases. Large variations in voltage may cause the motor to burn. Large variations in voltage indicate poor power supply, and the motor should be stopped until the defect has been remedied.</p>
<p>2. Current consumption</p>  <p style="text-align: right; font-size: small;">TM00 1372 5092</p>	<p>Measure the current of each phase while the pump is operating at a constant discharge pressure (if possible, at the capacity where the motor is most heavily loaded). For maximum operating current, see nameplate.</p>	<p>The difference between the current of the phase with the highest current consumption and the current of the phase with the lowest current consumption must not exceed 5 %. If so, or if the current exceeds the maximum operating current, look for one of the following possible faults:</p> <ul style="list-style-type: none"> <li>• The contacts of the motor-protective circuit breaker are burnt. <ul style="list-style-type: none"> <li>– Replace the contacts or the control box for single-phase operation.</li> </ul> </li> <li>• Poor connection of conductors, possibly in the cable joint. <ul style="list-style-type: none"> <li>– See item 3.</li> </ul> </li> <li>• Too high or too low supply voltage. <ul style="list-style-type: none"> <li>– See item 1.</li> </ul> </li> <li>• The motor windings are short-circuited or partly disjointed. <ul style="list-style-type: none"> <li>– See item 3.</li> </ul> </li> <li>• Damaged pump is causing the motor to be overloaded. <ul style="list-style-type: none"> <li>– Pull out the pump for overhaul.</li> </ul> </li> <li>• The resistance value of the motor windings deviates too much (three-phase). <ul style="list-style-type: none"> <li>– Move the phases in phase order to a more uniform load. If this does not solve the problem, see item 3.</li> </ul> </li> </ul>
<p>Items 3 and 4: Measurement is not necessary when supply voltage and current consumption are normal.</p>		
<p>3. Winding resistance</p>  <p style="text-align: right; font-size: small;">TM00 1373 5092</p>	<p>Disconnect the motor cable from the motor-protective circuit breaker. Measure the winding resistance between the conductors of the motor cable.</p>	<p>The difference between the highest and lowest resistance value must not exceed 10 %. If the deviation is higher, dismantle the motor as described in section 7.1 <i>Dismantling the motor</i>, and check the motor cable and stator for damage. Repair/replace defective parts.</p>
<p>4. Insulation resistance</p>  <p style="text-align: right; font-size: small;">TM00 1374 5092</p>	<p>Motors outside a well: Clean the motor cable end.</p> <p>Installed motors: Disconnect the submersible drop cable from the motor-protective circuit breaker and clean the cable end (contact points). Measure the insulation resistance from each phase to earth (frame) using an insulation tester (500 VDC, 2 min.). Make sure that the earth connection is made carefully.</p>	<p>Check the value on the instrument. If the insulation resistance is lower than the values below, pull out the motor for checking and repair.</p> <p>The values apply to an ambient temperature of 20 °C.</p> <p>With cable:</p> <ul style="list-style-type: none"> <li>• new motor: 2 MΩ.</li> <li>• used motor: 1 MΩ.</li> </ul> <p>Without drop cable:</p> <ul style="list-style-type: none"> <li>• new motor: 200 MΩ.</li> <li>• used motor: 10 MΩ.</li> </ul>

## 11. Winding resistances

**Note** Winding resistance measured between two lines and with original cable length.

### 11.1 50 Hz

#### 11.1.1 MMS6T30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 220-230	SD	37	50	0.132	96879502
3 x 380-400-415	DOL	37	50	0.375	96879380
3 x 380-400-415	SD	37	50	0.380	96879384
3 x 460	DOL	37	50	0.485	96879542

#### 11.1.2 MMS6T35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	2,70	96880880
3 x 380-400-415	DOL	7.5	10	2,06	96880881
3 x 380-400-415	DOL	9.2	12.5	1,70	96880882
3 x 380-400-415	DOL	11	15	1,46	96880883
3 x 380-400-415	DOL	13	17.5	1,14	96880884
3 x 380-400-415	DOL	15	20.5	1,12	96880885
3 x 380-400-415	DOL	18.5	25	0,795	96880886
3 x 380-400-415	SD	11	15	1,46	96880887
3 x 380-400-415	SD	13	17.5	1,14	96880888
3 x 380-400-415	SD	15	20.5	1,10	96880889
3 x 380-400-415	SD	18.5	25	0,785	96880890
3 x 220-230	DOL	5.5	7.5	0,920	96881044
3 x 220-230	DOL	7.5	10	0,710	96881045
3 x 220-230	DOL	9.2	12.5	0,575	96881046
3 x 220-230	DOL	11	15	0,410	96881047
3 x 220-230	DOL	13	17.5	0,355	96881048
3 x 220-230	DOL	15	20.5	0,290	96881049
3 x 220-230	DOL	18.5	25	0,260	96881050
3 x 460	DOL	7.5	10	2,80	96881094
3 x 460	DOL	9.2	12.5	2,70	96881095
3 x 460	DOL	11	15	2,12	96881096
3 x 460	DOL	13	17.5	1,74	96881097
3 x 460	DOL	15	20.5	1,34	96881098
3 x 460	DOL	18.5	25	1,24	96881099
3 x 415	DOL	5.5	7.5	3,43	98044371
3 x 220-230	DOL	22	30	0.226	96879499
3 x 220-230	DOL	26	35	0.178	96879500
3 x 220-230	DOL	30	40	0.180	96879501
3 x 380-400-415	DOL	22	30	0.635	96879377
3 x 380-400-415	DOL	26	35	0.495	96879378
3 x 380-400-415	DOL	30	40	0.440	96879379
3 x 380-400-415	SD	22	30	0.635	96879381
3 x 380-400-415	SD	26	35	0.480	96879382
3 x 380-400-415	SD	30	40	0.445	96879383
3 x 460	DOL	22	30	1.000	96879539
3 x 460	DOL	26	35	0.830	96879540
3 x 460	DOL	30	40	0.735	96879541

## 11.1.3 MMS6T50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	3,20	96880924
3 x 380-400-415	DOL	7.5	10	2,40	96880925
3 x 380-400-415	DOL	9.2	12.5	1,96	96880926
3 x 380-400-415	DOL	11	15	1,56	96880927
3 x 380-400-415	DOL	13	17.5	1,34	96880928
3 x 380-400-415	DOL	15	20.5	1,12	96880929
3 x 380-400-415	DOL	18.5	25	0,915	96880930
3 x 380-400-415	SD	13	17.5	1,32	96880931
3 x 380-400-415	SD	15	20.5	1,10	96880932
3 x 380-400-415	SD	18.5	25	0,905	96880933
3 x 380-400-415	DOL	22	30	0,740	96879409
3 x 380-400-415	DOL	26	35	0,625	96879410
3 x 380-400-415	DOL	30	40	0,550	96879411
3 x 380-400-415	DOL	37	50	0,415	96879412
3 x 380-400-415	SD	22	30	0,725	96879413
3 x 380-400-415	SD	26	35	0,610	96879414
3 x 380-400-415	SD	30	40	0,555	96879415
3 x 380-400-415	SD	37	50	0,420	96879416
3 x 415	DOL	30	40	0,665	96879449
3 x 415	DOL	37	50	0,500	96879450

## 11.1.4 MMS6ST30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	37	50	0,375	96879396
3 x 380-400-415	SD	37	50	0,380	96879400

## 11.1.5 MMS6ST35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	2,70	96880902
3 x 380-400-415	DOL	7.5	10	2,06	96880903
3 x 380-400-415	DOL	9.2	12.5	1,70	96880904
3 x 380-400-415	DOL	11	15	1,46	96880905
3 x 380-400-415	DOL	13	17.5	1,16	96880906
3 x 380-400-415	DOL	15	20.5	1,12	96880907
3 x 380-400-415	DOL	18.5	25	0,795	96880908
3 x 380-400-415	SD	11	15	1,46	96880909
3 x 380-400-415	SD	13	17.5	1,14	96880910
3 x 380-400-415	SD	15	20.5	1,10	96880911
3 x 380-400-415	SD	18.5	25	0,785	96880912
3 x 380-400-415	DOL	22	30	0,650	96879393
3 x 380-400-415	DOL	26	35	0,495	96879394
3 x 380-400-415	DOL	30	40	0,440	96879395
3 x 380-400-415	SD	22	30	0,635	96879397
3 x 380-400-415	SD	26	35	0,480	96879398
3 x 380-400-415	SD	30	40	0,445	96879399

11.1.6 MMS6ST50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	3.20	96880944
3 x 380-400-415	DOL	7.5	10	2.40	96880945
3 x 380-400-415	DOL	9.2	12.5	1.96	96880946
3 x 380-400-415	DOL	11	15	1.56	96880947
3 x 380-400-415	DOL	13	17.5	1.34	96880948
3 x 380-400-415	DOL	15	20.5	1.12	96880949
3 x 380-400-415	DOL	18.5	25	0.915	96880950
3 x 380-400-415	SD	13	17.5	1.32	96880951
3 x 380-400-415	SD	15	20.5	1.10	96880952
3 x 380-400-415	SD	18.5	25	0.905	96880953
3 x 220-230	DOL	5.5	7.5	1.10	96881058
3 x 220-230	DOL	7.5	10	0.825	96881059
3 x 220-230	DOL	9.2	12.5	0.660	96881060
3 x 220-230	DOL	11	15	0.525	96881061
3 x 220-230	DOL	13	17.5	0.445	96881062
3 x 220-230	DOL	15	20.5	0.350	96881063
3 x 220-230	DOL	18.5	25	0.290	96881064
3 x 500-525	DOL	9.2	12.5	3.35	96881079
3 x 500-525	DOL	11	15	2.70	96881080
3 x 500-525	DOL	13	17.5	2.12	96881081
3 x 500-525	DOL	15	20.5	0.635	96881082
3 x 500-525	DOL	18.5	25	0.925	96881083
3 x 460	DOL	7.5	10	3.30	96881106
3 x 460	DOL	9.2	12.5	2.70	96881107
3 x 460	DOL	11	15	2.14	96881108
3 x 460	DOL	13	17.5	1.96	96881109
3 x 460	DOL	15	20.5	1.44	96881110
3 x 460	DOL	18.5	25	1.24	96881111
3 x 200	SD	26	35	0.184	96879531
3 x 200	SD	30	40	0.140	96879532
3 X 220-230	DOL	22	30	0.248	96879507
3 X 220-230	DOL	26	35	0.192	96879508
3 X 220-230	DOL	30	40	0.194	96879509
3 X 220-230	SD	37	50	0.300	96879510
3 x 380-400-415	DOL	22	30	0.740	96879425
3 x 380-400-415	DOL	26	35	0.625	96879426
3 x 380-400-415	DOL	30	40	0.55	96879427
3 x 380-400-415	DOL	37	50	0.415	96879428
3 x 380-400-415	SD	22	30	0.725	96879429
3 x 380-400-415	SD	26	35	0.61	96879430
3 x 380-400-415	SD	30	40	0.555	96879431
3 x 380-400-415	SD	37	50	0.42	96879432
3 x 380-400-415	DOL	30	40	0.55	96879559
3 x 380-400-415	DOL	37	50	0.415	96879560
3 x 400	SD	26	35	0.66	96879535
3 x 400	SD	30	40	0.49	96879536
3 x 460	DOL	22	30	1.0	96879547
3 x 460	DOL	26	35	0.955	96879548
3 x 460	DOL	30	40	0.840	96879549
3 x 460	DOL	37	50	0.605	96879550
3 x 500-525	DOL	22	30	0.455	96879519
3 x 500-525	DOL	26	35	1.08	96879520
3 x 500-525	DOL	30	40	1.04	96879521
3 x 500-525	DOL	37	50	0.735	96879522

## 11.1.7 MMS6NST30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	37	50	0.375	96879404
3 x 380-400-415	SD	37	50	0.380	96879408

## 11.1.8 MMS6NST35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	2.70	96880913
3 x 380-400-415	DOL	7.5	10	2.06	96880914
3 x 380-400-415	DOL	9.2	12.5	1.70	96880915
3 x 380-400-415	DOL	11	15	1.46	96880916
3 x 380-400-415	DOL	13	17.5	1.16	96880917
3 x 380-400-415	DOL	15	20.5	1.12	96880918
3 x 380-400-415	DOL	18.5	25	0.795	96880919
3 x 380-400-415	SD	11	15	1.46	96880920
3 x 380-400-415	SD	13	17.5	1.14	96880921
3 x 380-400-415	SD	15	20.5	1.10	96880922
3 x 380-400-415	SD	18.5	25	0.785	96880923
3 x 380-400-415	DOL	22	30	0.650	96879401
3 x 380-400-415	DOL	26	35	0.495	96879402
3 x 380-400-415	DOL	30	40	0.440	96879403
3 x 380-400-415	SD	22	30	0.635	96879405
3 x 380-400-415	SD	26	35	0.480	96879406
3 x 380-400-415	SD	30	40	0.445	96879407

## 11.1.9 MMS6NST50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	3.20	96880954
3 x 380-400-415	DOL	7.5	10	2.40	96880955
3 x 380-400-415	DOL	9.2	12.5	1.96	96880956
3 x 380-400-415	DOL	11	15	1.56	96880957
3 x 380-400-415	DOL	13	17.5	1.34	96880958
3 x 380-400-415	DOL	15	20.5	1.12	96880959
3 x 380-400-415	DOL	18.5	25	0.915	96880960
3 x 380-400-415	SD	13	17.5	1.32	96880961
3 x 380-400-415	SD	15	20.5	1.10	96880962
3 x 380-400-415	SD	18.5	25	0.905	96880963
3 x 220-230	DOL	5.5	7.5	1.10	96881065
3 x 220-230	DOL	7.5	10	0.825	96881066
3 x 220-230	DOL	9.2	12.5	0.660	96881067
3 x 220-230	DOL	11	15	0.525	96881068
3 x 220-230	DOL	13	17.5	0.445	96881069
3 x 220-230	DOL	15	20.5	0.350	96881070
3 x 220-230	DOL	18.5	25	0.290	96881071
3 x 500-525	DOL	9.2	12.5	3.35	96881084
3 x 500-525	DOL	11	15	2.70	96881085
3 x 500-525	DOL	13	17.5	2.12	96881086
3 x 500-525	DOL	15	20.5	0.635	96881087
3 x 500-525	DOL	18.5	25	0.925	96881088
3 x 460	DOL	7.5	10	3.30	96881112
3 x 460	DOL	9.2	12.5	2.70	96881113
3 x 460	DOL	11	15	2.14	96881114
3 x 460	DOL	13	17.5	1.96	96881115
3 x 460	DOL	15	20.5	1.44	96881116
3 x 460	DOL	18.5	25	1.24	96881117
3 X 220-230	DOL	22	30	0.248	96879511
3 X 220-230	DOL	26	35	0.192	96879512
3 X 220-230	DOL	30	40	0.194	96879513
3 X 220-230	SD	37	50	0.300	96879514
3 x 380-400-415	DOL	22	30	0.740	96879433
3 x 380-400-415	DOL	26	35	0.625	96879434
3 x 380-400-415	DOL	30	40	0.550	96879435
3 x 380-400-415	DOL	37	50	0.415	96879436
3 x 380-400-415	SD	22	30	0.725	96879437
3 x 380-400-415	SD	26	35	0.610	96879438
3 x 380-400-415	SD	30	40	0.555	96879439
3 x 380-400-415	SD	37	50	0.420	96879440
3 x 380-400-415	DOL	30	40	0.550	96879561
3 x 380-400-415	DOL	37	50	0.415	96879562
3 x 460	DOL	22	30	1.000	96879551
3 x 460	DOL	26	35	0.955	96879552
3 x 460	DOL	30	40	0.840	96879553
3 x 460	DOL	37	50	0.605	96879554
3 x 500-525	DOL	22	30	0.455	96879523
3 x 500-525	DOL	26	35	1.080	96879524
3 x 500-525	DOL	30	40	1.040	96879525
3 x 500-525	DOL	37	50	0.735	96879526

## 11.1.10 MMS6RST50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	3.20	96880964
3 x 380-400-415	DOL	7.5	10	2.40	96880965
3 x 380-400-415	DOL	9.2	12.5	1.96	96880966
3 x 380-400-415	DOL	11	15	1.56	96880967
3 x 380-400-415	DOL	13	17.5	1.34	96880968
3 x 380-400-415	DOL	15	20.5	1.12	96880969
3 x 380-400-415	DOL	18.5	25	0.915	96880970
3 x 380-400-415	SD	13	17.5	1.32	96880971
3 x 380-400-415	SD	15	20.5	1.10	96880972
3 x 380-400-415	SD	18.5	25	0.905	96880973
3 x 220-230	DOL	5.5	7.5	1.10	96881072
3 x 220-230	DOL	7.5	10	0.825	96881073
3 x 220-230	DOL	9.2	12.5	0.660	96881074
3 x 220-230	DOL	11	15	0.525	96881075
3 x 220-230	DOL	13	17.5	0.445	96881076
3 x 220-230	DOL	15	20.5	0.350	96881077
3 x 220-230	DOL	18.5	25	0.290	96881078
3 x 500-525	DOL	9.2	12.5	3.35	96881089
3 x 500-525	DOL	11	15	2.70	96881090
3 x 500-525	DOL	13	17.5	2.12	96881091
3 x 500-525	DOL	15	20.5	0.635	96881092
3 x 500-525	DOL	18.5	25	0.925	96881093
3 x 460	DOL	7.5	10	3.30	96881118
3 x 460	DOL	9.2	12.5	2.70	96881119
3 x 460	DOL	11	15	2.14	96881120
3 x 460	DOL	13	17.5	1.96	96881121
3 x 460	DOL	15	20.5	1.44	96881122
3 x 460	DOL	18.5	25	1.24	96881123
3 x 200	SD	26	35	0.184	96879533
3 x 200	SD	30	40	0.140	96879534
3 X 220-230	DOL	22	30	0.248	96879515
3 X 220-230	DOL	26	35	0.192	96879516
3 X 220-230	DOL	30	40	0.194	96879517
3 X 220-230	SD	37	50	0.300	96879518
3 x 380-400-415	DOL	22	30	0.740	96879441
3 x 380-400-415	DOL	26	35	0.625	96879442
3 x 380-400-415	DOL	30	40	0.550	96879443
3 x 380-400-415	DOL	37	50	0.415	96879444
3 x 380-400-415	SD	22	30	0.725	96879445
3 x 380-400-415	SD	26	35	0.610	96879446
3 x 380-400-415	SD	30	40	0.555	96879447
3 x 380-400-415	SD	37	50	0.420	96879448
3 x 380-400-415	DOL	30	40	0.550	96879563
3 x 380-400-415	DOL	37	50	0.415	96879564
3 x 400	SD	26	35	0.660	96879537
3 x 400	SD	30	40	0.490	96879538
3 x 460	DOL	22	30	1.0	96879555
3 x 460	DOL	26	35	0.955	96879556
3 x 460	DOL	30	40	0.840	96879557
3 x 460	DOL	37	50	0.605	96879558
3 x 500-525	DOL	22	30	0.455	96879527
3 x 500-525	DOL	26	35	1.08	96879528
3 x 500-525	DOL	30	40	1.04	96879529
3 x 500-525	DOL	37	50	0.735	96879530



## 11.1.11 MMS6NT30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 220-230	SD	37	50	0.132	96879506
3 x 380-400-415	DOL	37	50	0.375	96879388
3 x 380-400-415	SD	37	50	0.380	96879392
3 x 460	DOL	37	50	0.485	96879546

## 11.1.12 MMS6NT35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	2,70	96880891
3 x 380-400-415	DOL	7.5	10	2,06	96880892
3 x 380-400-415	DOL	9.2	12.5	1,70	96880893
3 x 380-400-415	DOL	11	15	1,46	96880894
3 x 380-400-415	DOL	13	17.5	1,14	96880895
3 x 380-400-415	DOL	15	20.5	1,12	96880896
3 x 380-400-415	DOL	18.5	25	0,795	96880897
3 x 380-400-415	SD	11	15	1,46	96880898
3 x 380-400-415	SD	13	17.5	1,14	96880899
3 x 380-400-415	SD	15	20.5	1,10	96880900
3 x 380-400-415	SD	18.5	25	0,785	96880901
3 x 220-230	DOL	5.5	7.5	0,920	96881051
3 x 220-230	DOL	7.5	10	0,710	96881052
3 x 220-230	DOL	9.2	12.5	0,575	96881053
3 x 220-230	DOL	11	15	0,410	96881054
3 x 220-230	DOL	13	17.5	0,355	96881055
3 x 220-230	DOL	15	20.5	0,290	96881056
3 x 220-230	DOL	18.5	25	0,260	96881057
3 x 460	DOL	7.5	10	2,80	96881100
3 x 460	DOL	9.2	12.5	2,70	96881101
3 x 460	DOL	11	15	2,12	96881102
3 x 460	DOL	13	17.5	1,74	96881103
3 x 460	DOL	15	20.5	1,34	96881104
3 x 460	DOL	18.5	25	1,24	96881105
3 x 220-230	DOL	22	30	0.226	96879503
3 x 220-230	DOL	26	35	0.178	96879504
3 x 220-230	DOL	30	40	0.180	96879505
3 x 380-400-415	DOL	22	30	0.650	96879385
3 x 380-400-415	DOL	26	35	0.495	96879386
3 x 380-400-415	DOL	30	40	0.440	96879387
3 x 380-400-415	SD	22	30	0.635	96879389
3 x 380-400-415	SD	26	35	0.480	96879390
3 x 380-400-415	SD	30	40	0.445	96879391
3 x 460	DOL	22	30	1.0	96879543
3 x 460	DOL	26	35	0.830	96879544
3 x 460	DOL	30	40	0.735	96879545

## 11.1.13 MMS6NT50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 380-400-415	DOL	5.5	7.5	3.20	96880934
3 x 380-400-415	DOL	7.5	10	2.40	96880935
3 x 380-400-415	DOL	9.2	12.5	1.96	96880936
3 x 380-400-415	DOL	11	15	1.56	96880937
3 x 380-400-415	DOL	13	17.5	1.34	96880938
3 x 380-400-415	DOL	15	20.5	1.12	96880939
3 x 380-400-415	DOL	18.5	25	0.915	96880940
3 x 380-400-415	SD	13	17.5	1.32	96880941
3 x 380-400-415	SD	15	20.5	1.10	96880942
3 x 380-400-415	SD	18.5	25	0.905	96880943
3 x 380-400-415	DOL	22	30	0.740	96879417
3 x 380-400-415	DOL	26	35	0.625	96879418
3 x 380-400-415	DOL	30	40	0.550	96879419
3 x 380-400-415	DOL	37	50	0.415	96879420
3 x 380-400-415	SD	22	30	0.725	96879421
3 x 380-400-415	SD	26	35	0.610	96879422
3 x 380-400-415	SD	30	40	0.555	96879423
3 x 380-400-415	SD	37	50	0.420	96879424
3 x 415	DOL	30	40	0.665	96879451
3 x 415	DOL	37	50	0.500	96879452

## 11.2 60 Hz

## 11.2.1 MMS6T30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 220-230	SD	37	50	0.104	96879482
3 x 380	DOL	37	50	0.265	96879462
3 x 460	DOL	37	50	0.375	96879380
3 x 460	SD	37	50	0.380	96879384

## 11.2.2 MMS6T35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	2,70	96880880
3 x 460	DOL	7.5	10	2,06	96880881
3 x 460	DOL	9.2	12.5	1,70	96880882
3 x 460	DOL	11	15	1,46	96880883
3 x 460	DOL	13	17.5	1,14	96880884
3 x 460	DOL	15	20.5	1,12	96880885
3 x 460	DOL	18.5	25	0,795	96880886
3 x 460	SD	11	15	1,46	96880887
3 x 460	SD	13	17.5	1,14	96880888
3 x 460	SD	15	20.5	1,10	96880889
3 x 460	SD	18.5	25	0,785	96880890
3 x 380	DOL	5.5	7.5	1,94	96880974
3 x 380	DOL	7.5	10	1,48	96880975
3 x 380	DOL	9.2	12.5	1,10	96880976
3 x 380	DOL	11	15	1,02	96880977
3 x 380	DOL	13	17.5	0,810	96880978
3 x 380	DOL	15	20.5	0,690	96880979
3 x 380	DOL	18.5	25	0,520	96880980
3 x 220-230	DOL	5.5	7.5	0,665	96881009
3 x 220-230	DOL	7.5	10	0,515	96881010
3 x 220-230	DOL	9.2	12.5	0,390	96881011
3 x 220-230	DOL	11	15	0,290	96881012
3 x 220-230	DOL	13	17.5	0,255	96881013
3 x 220-230	DOL	15	20.5	0,226	96881014
3 x 220-230	DOL	18.5	25	0,206	96881015
3 x 220-230	DOL	22	30	0.164	96879479
3 x 220-230	DOL	26	35	0.128	96879480
3 x 220-230	DOL	30	40	0.124	96879481
3 x 380	DOL	22	30	0.440	96879459
3 x 380	DOL	26	35	0.335	96879460
3 x 380	DOL	30	40	0.345	96879461
3 x 460	DOL	22	30	0.635	96879377
3 x 460	DOL	26	35	0.495	96879378
3 x 460	DOL	30	40	0.440	96879379
3 x 460	SD	22	30	0.635	96879381
3 x 460	SD	26	35	0.480	96879382
3 x 460	SD	30	40	0.445	96879383

## 11.2.3 MMS6T50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	22	30	0.740	96879409
3 x 460	DOL	26	35	0.625	96879410
3 x 460	DOL	30	40	0.550	96879411
3 x 460	DOL	37	50	0.415	96879412
3 x 460	SD	22	30	0.725	96879413
3 x 460	SD	26	35	0.610	96879414
3 x 460	SD	30	40	0.555	96879415
3 x 460	SD	37	50	0.420	96879416

## 11.2.4 MMS6ST30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	37	50	0.375	96879396
3 x 460	SD	37	50	0.380	96879400
3 x 220-230	SD	37	50	0.104	96881207

## 11.2.5 MMS6ST35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	22	30	0.650	96879393
3 x 460	DOL	26	35	0.495	96879394
3 x 460	DOL	30	40	0.440	96879395
3 x 460	SD	22	30	0.635	96879397
3 x 460	SD	26	35	0.480	96879398
3 x 460	SD	30	40	0.445	96879399

## 11.2.6 MMS6ST50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	3.20	96880944
3 x 460	DOL	7.5	10	2.40	96880945
3 x 460	DOL	9.2	12.5	1.96	96880946
3 x 460	DOL	11	15	1.56	96880947
3 x 460	DOL	13	17.5	1.34	96880948
3 x 460	DOL	15	20.5	1.12	96880949
3 x 460	DOL	18.5	25	0.915	96880950
3 x 460	SD	13	17.5	1.32	96880951
3 x 460	SD	15	20.5	1.10	96880952
3 x 460	SD	18.5	25	0.905	96880953
3 x 575	DOL	9.2	12.5	3.35	96881079
3 x 575	DOL	11	15	2.70	96881080
3 x 575	DOL	13	17.5	2.12	96881081
3 x 575	DOL	15	20.5	0.635	96881082
3 x 575	DOL	18.5	25	0.925	96881083
3 x 220	SD	26	35	0.184	96879531
3 x 220	SD	30	40	0.140	96879532
3 x 220-230	DOL	22	30	0.178	96879487
3 x 220-230	DOL	26	35	0.16	96879488
3 x 220-230	DOL	30	40	0.15	96879489
3 x 220-230	SD	37	50	0.114	96879490
3 x 380	DOL	22	30	0.555	96879467
3 x 380	DOL	26	35	0.410	96879468
3 x 380	DOL	30	40	0.380	96879469
3 x 380	DOL	37	50	0.285	96879470
3 x 400	SD	26	35	0.660	96879535
3 x 400	SD	30	40	0.490	96879536
3 x 460	DOL	22	30	0.740	96879425
3 x 460	DOL	26	35	0.625	96879426
3 x 460	DOL	30	40	0.550	96879427
3 x 460	DOL	37	50	0.415	96879428
3 x 460	SD	22	30	0.725	96879429
3 x 460	SD	26	35	0.610	96879430
3 x 460	SD	30	40	0.555	96879431
3 x 460	SD	37	50	0.410	96879432
3 x 460 (US)	DOL	30	40	0.55	96879559
3 x 460 (US)	DOL	37	50	0.415	96879560
3 x 575	DOL	22	30	0.455	96879519
3 x 575	DOL	26	35	1.08	96879520
3 x 575	DOL	30	40	1.04	96879521
3 x 575	DOL	37	50	0.735	96879522

## 11.2.7 MMS6NST30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	37	50	0.375	96879404
3 x 460	SD	37	50	0.380	96879408

## 11.2.8 MMS6NST35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	2.70	96880913
3 x 460	DOL	7.5	10	2.06	96880914
3 x 460	DOL	9.2	12.5	1.70	96880915
3 x 460	DOL	11	15	1.46	96880916
3 x 460	DOL	13	17.5	1.16	96880917
3 x 460	DOL	15	20.5	1.12	96880918
3 x 460	DOL	18.5	25	0.795	96880919
3 x 460	SD	11	15	1.46	96880920
3 x 460	SD	13	17.5	1.14	96880921
3 x 460	SD	15	20.5	1.10	96880922
3 x 460	SD	18.5	25	0.785	96880923
3 x 460	DOL	22	30	0.650	96879401
3 x 460	DOL	26	35	0.495	96879402
3 x 460	DOL	30	40	0.440	96879403
3 x 460	SD	22	30	0.635	96879405
3 x 460	SD	26	35	0.480	96879406
3 x 460	SD	30	40	0.445	96879407

11.2.9 MMS6NST50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	3.20	96880954
3 x 460	DOL	7.5	10	2.40	96880955
3 x 460	DOL	9.2	12.5	1.96	96880956
3 x 460	DOL	11	15	1.56	96880957
3 x 460	DOL	13	17.5	1.34	96880958
3 x 460	DOL	15	20.5	1.12	96880959
3 x 460	DOL	18.5	25	0.915	96880960
3 x 460	SD	13	17.5	1.32	96880961
3 x 460	SD	15	20.5	1.10	96880962
3 x 460	SD	18.5	25	0.905	96880963
3 x 380	DOL	5.5	7.5	2.26	96880995
3 x 380	DOL	7.5	10	1.70	96880996
3 x 380	DOL	9.2	12.5	1.42	96880997
3 x 380	DOL	11	15	1.20	96880998
3 x 380	DOL	13	17.5	0.945	96880999
3 x 380	DOL	15	20.5	0.795	96881000
3 x 380	DOL	18.5	25	0.670	96881001
3 x 220-230	DOL	5.5	7.5	0.775	96881030
3 x 220-230	DOL	7.5	10	0.590	96881031
3 x 220-230	DOL	9.2	12.5	0.500	96881032
3 x 220-230	DOL	11	15	0.360	96881033
3 x 220-230	DOL	13	17.5	0.310	96881034
3 x 220-230	DOL	15	20.5	0.246	96881035
3 x 220-230	DOL	18.5	25	0.236	96881036
3 x 575	DOL	9.2	12.5	3.35	96881084
3 x 575	DOL	11	15	2.70	96881085
3 x 575	DOL	13	17.5	2.12	96881086
3 x 575	DOL	15	20.5	0.635	96881087
3 x 575	DOL	18.5	25	0.925	96881088
3 x 220-230	DOL	22	30	0.178	96879491
3 x 220-230	DOL	26	35	0.160	96879492
3 x 220-230	DOL	30	40	0.150	96879493
3 x 220-230	SD	37	50	0.114	96879494
3 x 380	DOL	22	30	0.555	96879471
3 x 380	DOL	26	35	0.410	96879472
3 x 380	DOL	30	40	0.380	96879473
3 x 380	DOL	37	50	0.285	96879474
3 x 460	DOL	22	30	0.740	96879433
3 x 460	DOL	26	35	0.625	96879434
3 x 460	DOL	30	40	0.550	96879435
3 x 460	DOL	37	50	0.415	96879436
3 x 460	SD	22	30	0.725	96879437
3 x 460	SD	26	35	0.610	96879438
3 x 460	SD	30	40	0.555	96879439
3 x 460	SD	37	50	0.420	96879440
3 x 460	DOL	30	40	0.550	96879561
3 x 460	DOL	37	50	0.415	96879562
3 x 575	DOL	22	30	0.455	96879523
3 x 575	DOL	26	35	1.08	96879524
3 x 575	DOL	30	40	1.04	96879525
3 x 575	DOL	37	50	0.735	96879526

## 11.2.10 MMS6RST50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	3.20	96880964
3 x 460	DOL	7.5	10	2.40	96880965
3 x 460	DOL	9.2	12.5	1.96	96880966
3 x 460	DOL	11	15	1.56	96880967
3 x 460	DOL	13	17.5	1.34	96880968
3 x 460	DOL	15	20.5	1.12	96880969
3 x 460	DOL	18.5	25	0.915	96880970
3 x 460	SD	13	17.5	1.32	96880971
3 x 460	SD	15	20.5	1.10	96880972
3 x 460	SD	18.5	25	0.905	96880973
3 x 380	DOL	5.5	7.5	2.26	96881002
3 x 380	DOL	7.5	10	1.70	96881003
3 x 380	DOL	9.2	12.5	1.42	96881004
3 x 380	DOL	11	15	1.20	96881005
3 x 380	DOL	13	17.5	0.945	96881006
3 x 380	DOL	15	20.5	0.795	96881007
3 x 380	DOL	18.5	25	0.670	96881008
3 x 220-230	DOL	5.5	7.5	0.775	96881037
3 x 220-230	DOL	7.5	10	0.590	96881038
3 x 220-230	DOL	9.2	12.5	0.500	96881039
3 x 220-230	DOL	11	15	0.360	96881040
3 x 220-230	DOL	13	17.5	0.310	96881041
3 x 220-230	DOL	15	20.5	0.246	96881042
3 x 220-230	DOL	18.5	25	0.236	96881043
3 x 575	DOL	9.2	12.5	3.35	96881089
3 x 575	DOL	11	15	2.70	96881090
3 x 575	DOL	13	17.5	2.12	96881091
3 x 575	DOL	15	20.5	0.635	96881092
3 x 575	DOL	18.5	25	0.925	96881093
3 x 200	SD	26	35	0.184	96879533
3 x 200	SD	30	40	0.140	96879534
3 x 220-230	DOL	22	30	0.178	96879495
3 x 220-230	DOL	26	35	0.160	96879496
3 x 220-230	DOL	30	40	0.150	96879497
3 x 220-230	SD	37	50	0.114	96879498
3 x 380	DOL	22	30	0.555	96879475
3 x 380	DOL	26	35	0.410	96879476
3 x 380	DOL	30	40	0.380	96879477
3 x 380	DOL	37	50	0.285	96879478
3 x 400	SD	26	35	0.660	96879537
3 x 400	SD	30	40	0.490	96879538
3 x 460	DOL	22	30	0.740	96879441
3 x 460	DOL	26	35	0.625	96879442
3 x 460	DOL	30	40	0.550	96879443
3 x 460	DOL	37	50	0.415	96879444
3 x 460	SD	22	30	0.725	96879445
3 x 460	SD	26	35	0.610	96879446
3 x 460	SD	30	40	0.555	96879447
3 x 460	SD	37	50	0.420	96879448
3 x 460	DOL	30	40	0.550	96879563
3 x 460	DOL	37	50	0.415	96879564
3 x 575	DOL	22	30	0.455	96879527
3 x 575	DOL	26	35	1.08	96879528
3 x 575	DOL	30	40	1.04	96879529
3 x 575	DOL	37	50	0.735	96879530



## 11.2.11 MMS6NT30

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 220-230	SD	37	50	0.104	96879486
3 x 380	DOL	37	50	0.265	96879466
3 x 460	DOL	37	50	0.375	96879388
3 x 460	SD	37	50	0.380	96879392

## 11.2.12 MMS6NT35

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	2,70	96880891
3 x 460	DOL	7.5	10	2,06	96880892
3 x 460	DOL	9.2	12.5	1,70	96880893
3 x 460	DOL	11	15	1,46	96880894
3 x 460	DOL	13	17.5	1,14	96880895
3 x 460	DOL	15	20.5	1,12	96880896
3 x 460	DOL	18.5	25	0,795	96880897
3 x 460	SD	11	15	1,46	96880898
3 x 460	SD	13	17.5	1,14	96880899
3 x 460	SD	15	20.5	1,10	96880900
3 x 460	SD	18.5	25	0,785	96880901
3 x 380	DOL	5.5	7.5	1,94	96880981
3 x 380	DOL	7.5	10	1,48	96880982
3 x 380	DOL	9.2	12.5	1,10	96880983
3 x 380	DOL	11	15	1,02	96880984
3 x 380	DOL	13	17.5	0,810	96880985
3 x 380	DOL	15	20.5	0,690	96880986
3 x 380	DOL	18.5	25	0,520	96880987
3 x 220-230	DOL	5.5	7.5	0,665	96881016
3 x 220-230	DOL	7.5	10	0,515	96881017
3 x 220-230	DOL	9.2	12.5	0,390	96881018
3 x 220-230	DOL	11	15	0,290	96881019
3 x 220-230	DOL	13	17.5	0,255	96881020
3 x 220-230	DOL	15	20.5	0,226	96881021
3 x 220-230	DOL	18.5	25	0,206	96881022
3 x 220-230	DOL	22	30	0.164	96879483
3 x 220-230	DOL	26	35	0.128	96879484
3 x 220-230	DOL	30	40	0.124	96879485
3 x 380	DOL	22	30	0.440	96879463
3 x 380	DOL	26	35	0.335	96879464
3 x 380	DOL	30	40	0.345	96879465
3 x 460	DOL	22	30	0.650	96879385
3 x 460	DOL	26	35	0.495	96879386
3 x 460	DOL	30	40	0.440	96879387
3 x 460	SD	22	30	0.635	96879389
3 x 460	SD	26	35	0.480	96879390
3 x 460	SD	30	40	0.445	96879391


## 11.2.13 MMS6NT50

Voltage [V]	Starting method	Output power		Winding resistance [ $\Omega$ ] ( $\pm 10\%$ )	Product number
		[kW]	[hp]		
3 x 460	DOL	5.5	7.5	3.20	96880934
3 x 460	DOL	7.5	10	2.40	96880935
3 x 460	DOL	9.2	12.5	1.96	96880936
3 x 460	DOL	11	15	1.56	96880937
3 x 460	DOL	13	17.5	1.34	96880938
3 x 460	DOL	15	20.5	1.12	96880939
3 x 460	DOL	18.5	25	0.915	96880940
3 x 460	SD	13	17.5	1.32	96880941
3 x 460	SD	15	20.5	1.10	96880942
3 x 460	SD	18.5	25	0.905	96880943
3 x 460	DOL	22	30	0.740	96879417
3 x 460	DOL	26	35	0.625	96879418
3 x 460	DOL	30	40	0.550	96879419
3 x 460	DOL	37	50	0.415	96879420
3 x 460	SD	22	30	0.725	96879421
3 x 460	SD	26	35	0.610	96879422
3 x 460	SD	30	40	0.555	96879423
3 x 460	SD	37	50	0.420	96879424

## 12. Drawings


### 12.1 5.5 - 37 kW, 7.5 - 50 hp

#### 12.1.1 Exploded view



TM04 5193 3409

12.1.2 Sectional drawing



**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana, ramal Campana Centro Industrial Garín - Esq. Haendel y Mozart  
AR-1619 Garín Pcia. de Buenos Aires  
Pcia. de Buenos Aires  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomssesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в Минске  
220123, Минск,  
ул. В. Хоружей, 22, оф. 1105  
Тел.: +(37571) 233 97 65,  
Факс: +(37571) 233 97 69  
E-mail: grundfos\_minsk@mail.ru

**Bosnia/Herzegovina**

GRUNDFOS Sarajevo  
Trg Heroja 16,  
BiH-71000 Sarajevo  
Phone: +387 33 713 290  
Telefax: +387 33 659 079  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo Branco,  
630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztocna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
50/F Maxdo Center No. 8 XingYi Rd.  
Hongqiao development Zone  
Shanghai 200336  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Cebini 37, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.grundfos.hr

**Czech Republic**

GRUNDFOS s.r.o.  
Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111  
Telefax: +420-585-716 299

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumput AB  
Mestarintie 11  
FIN-01730 Vantaa  
Phone: +358-3066 5650  
Telefax: +358-3066 56550

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infoservice@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

HILGE GmbH & Co. KG  
Hilgestrasse 37-47  
55292 Bodenheim/Rhein  
Germany  
Tel.: +49 6135 75-0  
Telefax: +49 6135 1737  
e-mail: hilge@hilge.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Park u. 8  
H-2045 Törökbalint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private Limited  
118 Old Mahaballipuram Road  
Thoraiakkam  
Chennai 600 096  
Phone: +91-44 2496 6800

**Indonesia**

PT GRUNDFOS Pompa  
Jl. Rawa Sumur III, Blok III / CC-1  
Kawasan Industri, Pulogadung  
Jakarta 13930  
Phone: +62-21-460 6909  
Telefax: +62-21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
Gotanda Metalion Bldg., 5F,  
5-21-15, Higashi-gotanda  
Shiagawa-ku, Tokyo  
141-0022 Japan  
Phone: +81 35 448 1391  
Telefax: +81 35 448 9619

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Stramsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przemierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос  
Россия, 109544 Москва, ул. Школьная  
39  
Тел. (+7) 495 737 30 00, 564 88 00  
Факс (+7) 495 737 75 36, 564 88 11  
E-mail grundfos.moscow@grundfos.com

**Serbia**

GRUNDFOS Predstavništvo Beograd  
Dr. Milutina Ivkovića 2a/29  
YU-11000 Beograd  
Phone: +381 11 26 47 877 / 11 26 47 496  
Telefax: +381 11 26 48 340

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovenia**

GRUNDFOS d.o.o.  
Šiandrova 8b, SI-1231 Ljubljana-Črnuče  
Phone: +386 1 568 0610  
Telefax: +386 1 568 0619  
E-mail: slovenia@grundfos.si

**South Africa**

GRUNDFOS (PTY) LTD  
Corner Mountjoy and George Allen Roads  
Wilbart Ext. 2  
Bedfordview 2008  
Phone: (+27) 11 579 4800  
Fax: (+27) 11 455 6066  
E-mail: smart@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentequilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-1-806 8111  
Telefax: +41-1-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloom Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.  
Gebze Organize Sanayi Bölgesi  
İhsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

ТОВ ГРУНДФОС УКРАЇНА  
01010 Київ, Вул. Московська 8б,  
Тел.: (+38 044) 390 40 50  
Факс.: (+38 044) 390 40 59  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971 4 8815 166  
Telefax: +971 4 8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 8TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
17100 West 118th Terrace  
Olathe, Kansas 66061  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Представительство ГРУНДФОС в Ташкенте  
700000 Ташкент ул. Усмана Носира 1-й  
тулик 5  
Телефон: (3712) 55-68-15  
Факс: (3712) 53-36-35

Revised 27.04.2012

**97709391** 0612

The name Grundfos, the Grundfos logo, and the payoff Be-Think-Innovate are registered trademarks owned by Grundfos Management A/S or Grundfos A/S, Denmark. All rights reserved worldwide.