

TPE, TPED Series 1000; NBE, NBGE, MTBE, NKE, NKGE; TPE, TPED, NBE, NKE Series 2000

Installation and operating instructions



**TPE, TPED Series 1000; NBE,
NBGE, MTBE, NKE, NKGE; TPE,
TPED, NBE, NKE Series 2000**
Installation and operating instructions
<http://net.grundfos.com/qr/i/98476024>

TPE, TPED Series 1000; NBE, NBGE, MTBE, NKE, NKGE; TPE, TPED, NBE, NKE Series 2000

English (GB)

Installation and operating instructions 4

Appendix A. 81

Appendix B. 83

English (GB) Installation and operating instructions

Original installation and operating instructions

Table of contents

1. Symbols used in this document	5	13. Description of functions	33
2. Abbreviations and definitions	6	13.1 Setpoint	33
3. General information	6	13.2 Operating mode	33
4. General description	6	13.3 Set manual speed	33
4.1 Radio communication	6	13.4 User-defined speed	33
4.2 Battery	7	13.5 "Control mode"	34
5. Receiving the product	7	13.6 "Proportional-pressure setup"	39
5.1 Transporting the product	7	13.7 Analog inputs	39
5.2 Inspecting the product	7	13.8 Built-in Grundfos sensor	41
6. Mechanical installation	7	13.9 Pt100/1000 inputs	41
6.1 Handling the product	7	13.10 Digital inputs	42
6.2 Mounting the product	8	13.11 Digital inputs/outputs	43
6.3 Cable entries	8	13.12 "Signal relays 1 and 2" (Relay outputs)	44
6.4 Ensuring motor cooling	8	13.13 Analog output	45
6.5 Outdoor installation	8	13.14 "Controller" ("Controller settings")	46
6.6 Drain holes	8	13.15 Operating range	47
7. Electrical installation	9	13.16 External setpoint function	48
7.1 Protection against electric shock, indirect contact	9	13.17 Limit-exceeded function	51
7.2 Cable requirements	9	13.18 "Pulse flowmeter setup"	52
7.3 Mains supply	9	13.19 "Ramps"	52
7.4 Additional protection	11	13.20 "Standstill heating"	53
7.5 Connection terminals	12	13.21 Motor bearing monitoring	53
7.6 Signal cables	15	13.22 "Service"	53
7.7 Bus connection cable	15	13.23 "Number" (Pump number)	54
8. Operating conditions	16	13.24 "Radio communication" (Enable/disable radio comm.)	54
8.1 Maximum number of starts and stops	16	13.25 Language	54
8.2 Alternating operation of twin-head pumps	16	13.26 "Date and time" (Set date and time)	54
8.3 Ambient temperature	16	13.27 "Unit configuration" (Units)	55
8.4 Installation altitude	16	13.28 "Buttons on product" (Enable/disable settings)	55
8.5 Humidity	17	13.29 Delete history	55
8.6 Motor cooling	17	13.30 Define Home display	55
9. User interfaces	17	13.31 Display settings	55
10. Standard control panel	17	13.32 "Store settings" (Store actual settings)	55
10.1 Setpoint setting	18	13.33 "Recall settings" (Recall stored settings)	56
11. Advanced control panel	20	13.34 "Undo"	56
11.1 Home display	21	13.35 "Pump name"	56
11.2 Startup guide	22	13.36 "Connection code"	56
11.3 Menu overview for advanced control panel	23	13.37 Run start-up guide	57
12. Grundfos GO	28	13.38 Alarm log	57
12.1 Communication	28	13.39 Warning log	57
12.2 Menu overview for Grundfos GO	29	13.40 Assist	57
		13.41 Assisted pump setup	57
		13.42 Setup, analog input	58
		13.43 "Multipump setup" (Setup of multi-pump system)	58
		13.44 Description of control mode	61
		13.45 Assisted fault advice	61
		14. Selection of control mode	62

15.	Bus signal	63
16.	Priority of settings	64
17.	Grundfos Eye	65
18.	Signal relays	67
19.	Installing a communication interface module	69
20.	Identification of the functional module	72
21.	Identification of control panel	72
22.	Changing the position of the control panel	73
23.	Servicing the product	74
23.1	Motor	74
23.2	Pump	74
24.	Cleaning the product	74
25.	Megging	74
26.	Technical data, single-phase motors	74
26.1	Supply voltage	74
26.2	Leakage current	74
27.	Technical data, three-phase motors	75
27.1	Supply voltage	75
27.2	Leakage current, AC	75
28.	Inputs and outputs	76
29.	Other technical data	77
29.1	Torques	77
29.2	Sound pressure level	78
30.	Factory settings	79
31.	Disposing of the product	80



Tips and advice that make the work easier.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.

1. Symbols used in this document



DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

-



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

-



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

-

2. Abbreviations and definitions

AI	Analog input.
AL	Alarm, out of range at lower limit.
AO	Analog output.
AU	Alarm, out of range at upper limit.
CIM	Communication interface module.
Current sinking	The ability to draw current into the terminal and guide it towards earth in the internal circuitry.
Current sourcing	The ability to push current out of the terminal and into an external load which must return it to earth.
DI	Digital input.
DO	Digital output.
ELCB	Earth leakage circuit breaker.
FM	Functional module.
GDS	Grundfos Digital Sensor. Factory-fitted sensor in some Grundfos pumps.
GENIbus	Proprietary Grundfos fieldbus standard.
GFCI	Ground fault circuit interrupter. USA and Canada.
GND	Earth.
Grundfos Eye	Status indicator light.
LIVE	Low voltage with the risk of electric shock if the terminals are touched.
OC	Open collector: Configurable open-collector output.
PE	Protective earth.
PELV	Protective extra-low voltage. A voltage that cannot exceed ELV under normal conditions and under single-fault conditions, except earth faults in other circuits.
RCD	Residual-current device
SELV	Safety extra-low voltage. A voltage that cannot exceed ELV under normal conditions and under single-fault conditions, including earth faults in other circuits.

TPE, NBE, NBGE, NKE, NKGE	Single-head pump without factory-fitted differential-pressure sensor.
---------------------------	---

TPED	Twin-head pump without factory-fitted differential-pressure sensor.
------	---

TPE, TPED, NBE, NKE Series 2000	Single-head pump (TPE, NBE, NKE) and twin-head pump (TPED) with factory-fitted differential-pressure sensor.
---------------------------------	--

3. General information

These installation and operating instructions are a supplement to the installation and operating instructions for the corresponding standard pumps TP, TPD, NB, NBG, NK and NKG. For instructions not mentioned specifically in this manual, see the installation and operating instructions for the standard pump.

4. General description

The pumps are fitted with frequency-controlled permanent-magnet motors for single-phase or three-phase mains connection.



The product must only be connected to protected network subnets with strict access control.

4.1 Radio communication

This product incorporates a radio module for remote control which is a class 1 device and can be used anywhere in the EU member states without restrictions.

For use in USA and Canada, see section Installation in the USA and Canada.

Some variants of the product and products sold in China and Korea have no radio module.

This product can communicate with Grundfos GO and other products of the same type via the built-in radio module.

In some cases, an external antenna may be required. Only Grundfos-approved external antennas may be connected to this product, and only by a Grundfos-approved installer.

Related information

[A.1. Installation in the USA and Canada](#)

4.2 Battery

Pumps fitted with the advanced functional module, FM 300, incorporate a Li-ion battery. The Li-ion battery complies with the Battery Directive (2006/66/EC). The battery does not contain mercury, lead and cadmium.



WARNING **Intoxication or risk of chemical burn**

Death or serious personal injury

- The battery can cause severe or fatal injuries in 2 hours or less if it is swallowed or placed inside any part of the body. In such an event, seek medical attention immediately.



- The replacement or servicing of batteries must be carried out by a qualified person.
- The battery contained within this product, whether new or used, is hazardous and is to be kept away from children.

5. Receiving the product

5.1 Transporting the product



WARNING **Falling objects**

Death or serious personal injury

- Secure the product during transportation to prevent it from tilting or falling down.



CAUTION **Crushing of feet**

Minor or moderate personal injury

- Wear safety shoes when moving the product.

5.2 Inspecting the product

Before you install the product, do the following:

1. Check that the product is as ordered.
2. Check that no visible parts have been damaged.

If parts are damaged or missing, contact your local Grundfos sales company.

6. Mechanical installation

6.1 Handling the product

Observe local regulations setting limits for manual lifting or handling. The motor weight is stated on the nameplate.



CAUTION

Back injury

Minor or moderate personal injury

- Use lifting equipment.



CAUTION

Crushing of feet

Minor or moderate personal injury

- Wear safety shoes and attach lifting equipment to the motor eyebolts when handling the product.



The product must be installed in a place with access control to prevent unauthorized access to the product.



Do not lift the product by the terminal box.

6.2 Mounting the product

CAUTION

Crushing of feet

Minor or moderate personal injury

- Secure the product to a solid foundation by bolts through the holes in the flange or the base plate.



In order to maintain the UL mark, additional requirements apply to the equipment. See page Installation in the USA and Canada.

Secure the pump to a solid foundation by bolts through the holes in the flange or the base plate.

Related information

[A.1. Installation in the USA and Canada](#)

[A.1. Installation in the USA and Canada](#)

6.3 Cable entries


See the size of the cable entries in the section on other technical data.

Related information

[29. Other technical data](#)

6.4 Ensuring motor cooling

Leave at least 50 mm between the end of the fan cover and a wall or other fixed objects.



Minimum distance, *D*, from the motor to a wall or other fixed objects

TM055236


6.5 Outdoor installation

If you install the motor outdoors, provide the motor with a cover and open the drain holes to avoid condensation on the electronic components.



When fitting a cover to the motor, observe the guidelines in section Ensuring motor cooling.

The cover must be sufficiently large to ensure that the motor is not exposed to direct sunlight, rain or snow. Grundfos does not supply covers. We therefore recommend that you have a cover built for the specific application. In areas with high humidity, we recommend that you connect the motor permanently to the mains supply and activate the built-in standstill heating function. See section "Standstill heating".



TM053496

Examples of covers, not supplied by Grundfos



In order to maintain the UL mark, additional requirements apply to the equipment. See page Installation in the USA and Canada.

Related information

[A.1. Installation in the USA and Canada](#)

[6.4 Ensuring motor cooling](#)


[6.6 Drain holes](#)

[13.20 "Standstill heating"](#)

6.6 Drain holes

When the motor is installed in moist surroundings or areas with high humidity, the bottom drain hole must be open. The enclosure class of the motor will then be lower. This helps prevent condensation in the motor as the motor becomes self-venting, and it allows water and humid air to escape.

The motor has a plugged drain hole on the drive side. You can turn the flange 90° to both sides or 180°.



TM029037

Drain holes

7. Electrical installation

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before you make any connections in the terminal box. Make sure that the power supply cannot be accidentally switched on.

DANGER

Electric shock

Death or serious personal injury



- Check that the supply voltage and frequency correspond to the values stated on the nameplate.
- If the power supply cable is damaged, it must be replaced by the manufacturer, the manufacturer's service partner or a similarly qualified person.

The user or the installer is responsible for the installation of correct earthing and protection according to local regulations. All operations must be carried out by a qualified electrician.

Carry out the electrical connection according to local regulations.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

7.1 Protection against electric shock, indirect contact

WARNING

Electric shock

Death or serious personal injury



- Connect the motor to protective earth and provide protection against indirect contact in accordance with local regulations.

Protective-earth conductors must always have a yellow and green, PE, or yellow, green and blue, PEN, colour marking.

7.1.1 Protection against mains voltage transients

The motor is protected against mains voltage transients in accordance with EN 61800-3.

7.1.2 Motor protection

The motor requires no external motor protection. The motor incorporates thermal protection against slow overloading and blocking.

Model H, I: The product includes load- and speed-sensitive motor-overload protection.

7.2 Cable requirements

7.2.1 Cable cross-section

DANGER

Electric shock

Death or serious personal injury



- Always comply with local regulations regarding cable cross-sections.

1 × 200-230 V

Power [kW]	Conductor type	Cross section	
		[mm ²]	[AWG]
0.25 - 1.5	Solid	1.5 - 2.5	16-12
	Stranded	1.5 - 2.5	16-12

3 × 380-500 V

Power [kW]	Conductor type	Cross section	
		[mm ²]	[AWG]
0.25 - 2.2	Solid	1.5 - 10	16-8
	Stranded	1.5 - 10	16-8
3.0 - 11	Solid	2.5 - 10	14-8
	Stranded	2.5 - 10	14-8

3 × 200-240 V

Power [kW]	Conductor type	Cross section	
		[mm ²]	[AWG]
1.1 - 1.5	Solid	1.5 - 10	16-8
	Stranded	1.5 - 10	16-8
2.2 - 5.5	Solid	2.5 - 10	14-8
	Stranded	2.5 - 10	14-8

7.2.2 Conductors

Type

The conductors are stranded or solid copper.

Temperature rating

Temperature rating for conductor insulation: 60 °C (140 °F).

Temperature rating for outer cable sheath: 75 °C (167 °F).

7.3 Mains supply

DANGER

Electric shock

Death or serious personal injury



- Use the recommended fuse size. See section Supply voltage.

Related information

[26.1 Supply voltage](#)

[27.1 Supply voltage](#)

7.3.1 Single-phase supply voltage

1 x 200-240 V-10 % / +10 %, 50/60 Hz, PE


Make sure the supply voltage and frequency correspond to the values stated on the nameplate.



If you want to supply the motor through an IT network, make sure you have a suitable motor variant. If you are in doubt, contact Grundfos.


The wires in the motor terminal box must be as short as possible. Excepted from this is the separated earth conductor which must be so long that it is the last one to be disconnected in case the cable is inadvertently pulled out of the cable entry.

For maximum backup fuse, see the section on supply voltage.



Example of a mains-connected motor with a main switch, backup fuse and additional protection

Pos.	Description
1	RCD, type B



Mains connection, single-phase motors

Related information

[26.1 Supply voltage](#)

7.3.2 Three-phase supply voltage

Three-phase motors are available for the voltages below:

- 3 x 380-500 V - 10 %/+ 10 %, 50/60 Hz, PE
- 3 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

The wires in the motor terminal box must be as short as possible. Excepted from this is the separated earth conductor which must be so long that it is the last one to be disconnected in case the cable is inadvertently pulled out of the cable entry.

In order to avoid loose connections, ensure that the terminal block for L1, L2 and L3 is pressed home in its socket when the supply cable has been connected.

For maximum backup fuse, see section Supply voltage.




If you want to supply the motor through an IT network, make sure that you have a suitable motor variant. If you are in doubt, contact Grundfos.

Only the following motors can be supplied through an IT network:

- Motors with speed of 1450-2000/2200 rpm and up to 1.5 kW
- Motors with speed of 2900-4000 rpm or 4000-5900 rpm and up to 2.2 kW.




Corner earthing is not allowed for supply voltages above 3 x 240 V and 3 x 480 V, 50/60 Hz.



Example of a mains-connected motor with mains switch, backup fuses and additional protection

Pos.	Description
1	RCD, type B



Mains connection, three-phase motors

Related information

27.1 Supply voltage

7.4 Additional protection

DANGER

Electric shock

Death or serious personal injury

- Only use residual-current circuit breakers (ELCB, GFCI, RCD) of type B.

The residual-current circuit breaker must be marked with the following symbol:



The total leakage current of all the electrical equipment in the installation must be taken into account. You find the leakage current of the motor in the sections on leakage current and leakage current (AC).

This product can cause a direct current in the protective earth conductor.

Overvoltage and undervoltage protection

Overvoltage and undervoltage may occur in case of unstable power supply or faulty installation. The motor stops if the voltage falls outside the permissible voltage range. The motor restarts automatically when the voltage is again within the permissible voltage range. Therefore, no additional protection relay is required.



The motor is protected against transients from the power supply according to EN 61800-3. In areas with high lightning intensity, we recommend external lightning protection.

Overload protection

If the upper load limit is exceeded, the motor automatically compensates for it by reducing the speed and stops if the overload condition persists.

The motor remains stopped for a set period. After this period, the motor automatically attempts to restart. The overload protection prevents damage to the motor. Consequently, no additional motor protection is required.

Overtemperature protection

The electronic unit has a built-in temperature sensor as an additional protection. When the temperature rises above a certain level, the motor automatically compensates for it by reducing the speed and stops if the temperature keeps rising. The motor remains stopped for a set period. After this period, the motor automatically attempts to restart.

Protection against phase unbalance

Three-phase motors must be connected to a power supply with a quality corresponding to IEC 60146-1-1, class C, to ensure correct motor operation at phase unbalance. This also ensures long life of the components.

Related information

26.2 Leakage current

27.2 Leakage current, AC

7.5 Connection terminals

The descriptions and terminal overviews in this section apply to both single-phase and three-phase motors.

For maximum torques, see section Torques.

Related information

29.1 Torques

7.5.1 Connection terminals, advanced functional module, FM 300

The advanced module has these connections:

- three analog inputs
- one analog output
- two dedicated digital inputs
- two configurable digital inputs or open-collector outputs
- Input and output for Grundfos Digital Sensor Not applicable for TPE, TPED, NBE, NBGE, NKE and NKGE pumps. The factory-fitted differential-pressure sensor for TPE, TPED, NBE, NKE Series 2000 is connected to this input.
- two Pt100/1000 inputs
- two LiqTec sensor inputs
- two signal relay outputs
- GENIbus connection.



Digital input 1 is factory-set to be start-stop input where open circuit results in stop. A jumper has been factory-fitted between terminals 2 and 6. Remove the jumper if digital input 1 is to be used as external start-stop or any other external function.

DANGER

Electric shock

Death or serious personal injury



- Make sure that the wires to be connected to the connection groups below are separated from each other by reinforced insulation in their entire lengths.

• Inputs and outputs

All inputs and outputs are internally separated from the mains-conducting parts by reinforced insulation and galvanically separated from other circuits.

All control terminals are supplied by protective extra-low voltage, PELV, thus ensuring protection against electric shock.

• Signal relay outputs

- Signal relay 1:



LIVE: You can connect supply voltages up to 250 VAC.

PELV: The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.

- Signal relay 2:

PELV: The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.

- Mains supply, terminals N, PE, L or L1, L2, L3, PE.



TM053509

*If you use an external supply source, make sure that there is a connection to GND.


Connection terminals, FM 300 (option)

Terminal	Type	Function
NC	Normally closed contact	Signal relay 1 LIVE or PELV
C1	Common	
NO	Normally open contact	
NC	Normally closed contact	Signal relay 2 PELV only
C2	Common	
NO	Normally open contact	
18	GND	Earth
11	DI4/OC2	Digital input and output, configurable. Open collector: Maximum 24 V resistive or inductive.
19	Pt100/1000 input 2	Pt100/1000 sensor input
17	Pt100/1000 input 1	Pt100/1000 sensor input
12	AO	Analog output: 0-20 mA / 4-20 mA 0-10 V
9	GND	Earth
14	AI3	Analog input: 0-20 mA / 4-20 mA 0-10 V
1	DI2	Digital input, configurable
21	LiqTec sensor input 1	LiqTec sensor input white conductor
20	GND	Earth brown and black conductors
22	LiqTec sensor input 2	LiqTec sensor input blue conductor
10	DI3/OC1	Digital input and output, configurable. Open collector: Maximum 24 V resistive or inductive.

Terminal	Type	Function
4	AI1	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0-5 V / 0-10 V
2	DI1	Digital input, configurable
5	+5 V	Supply to potentiometer and sensor
6	GND	Earth
A	GENIbus, A	GENIbus, A (+)
Y	GENIbus, Y	GENIbus, GND
B	GENIbus, B	GENIbus, B (-)
3	GND	Earth
15	+24 V	Supply
8	+24 V	Supply
26	+5 V	Supply to potentiometer and sensor
23	GND	Earth
25	GDS TX	Grundfos Digital Sensor output
24	GDS RX	Grundfos Digital Sensor input
7	AI2	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0-5 V / 0-10 V

7.6 Signal cables

- Use screened cables with a cross-sectional area of minimum 0.5 mm² and maximum 1.5 mm² for external on/off switch, digital inputs, setpoint and sensor signals.
- Connect the screens of the cables to frame at both ends with good connection. The screens must be as close as possible to the terminals.



Stripped cable with screen and wire connections

- Always tighten screws for frame connections whether a cable is fitted or not.
- The wires in the motor terminal box must be as short as possible.


7.7 Bus connection cable

7.7.1 New installations

For the bus connection, use a screened 3-core cable with a cross-sectional area of minimum 0.5 mm² and maximum 1.5 mm².

If the motor is connected to a unit with a cable clamp which is identical to the one on the motor, connect the screen to this cable clamp.

If the unit has no cable clamp, leave the screen unconnected at this end.




Connection with screened 3-core cable

Pos.	Description
M	Motor

7.7.2 Replacing a motor

- If you have used a screened 2-core cable in the existing installation, connect the cable as shown below.



Connection with screened 2-core cable

Pos.	Description
M	Motor

- If you have used a screened 3-core cable in the existing installation, follow the instructions in section New installation.

Related information

7.7.1 New installations

TM078987

TM021325

TM078986

8. Operating conditions

8.1 Maximum number of starts and stops

The number of starts and stops via the power supply must not exceed four times per hour.

When switched on via the power supply, the pump starts after approximately 5 seconds.

If a higher number of starts and stops is desired, use the input for external start-stop when starting or stopping the pump.

When started via an external on/off switch, the pump starts immediately.

8.2 Alternating operation of twin-head pumps

On twin-head pumps, the duty and backup pumps must be alternated on a regular basis, i.e. once a week, to ensure an even distribution of the operating hours on both pumps. The pumps alternate automatically. See section "Multipump setup" (Setup of multi-pump system).

If twin-head pumps are used for pumping domestic hot water, the duty and backup pumps must be alternated on a regular basis, i.e. once a day, to avoid blocking of the backup pump due to deposits such as calcareous deposits. As default, the pumps alternate automatically. See section "Multipump setup" (Setup of multi-pump system).

Related information

[13.43 "Multipump setup" \(Setup of multi-pump system\)](#)

8.3 Ambient temperature

8.3.1 Ambient temperature during storage and transportation

Minimum: -30 °C.

Maximum: 60 °C.

8.3.2 Ambient temperature during operation

	3 × 200-240 V	3 × 380-500 V
Minimum	-20 °C	-20 °C
Maximum	40 °C	50 °C

The motor can operate with the rated power output, P2, at 50 °C, but continuous operation at higher temperatures reduces the expected product life. If the motor is to operate at ambient temperatures between 50 and 60 °C, select an oversized motor. Contact Grundfos for further information.

8.4 Installation altitude


Installation altitude is the height of the installation site above sea level.

Motors installed up to 1000 m above sea level can be loaded 100 %.

The motors can be installed up to 3500 m above sea level.



Motors installed more than 1000 m above sea level must not be fully loaded due to the low density and consequent low cooling effect of the air.




Motor output power in relation to altitude

Pos. Description

X Altitude [m]

To maintain the galvanic isolation and ensure correct clearance according to EN 60664-1:2007, you must adapt the supply voltage to the altitude.




Supply voltage for three-phase motor in relation to altitude

Pos. Description

A Supply voltage [V]

B Altitude [m]



Supply voltage for single-phase motor in relation to altitude

Pos.	Description
A	Supply voltage [V]
B	Altitude [m]

8.5 Humidity

Maximum humidity: 95 %.

If the humidity is constantly high and above 85 %, one of the drain holes in the drive-end flange must be open. See section Drain holes.

Related information

[6.6 Drain holes](#)

8.6 Motor cooling

To ensure cooling of motor and electronics, observe the following:

- Position the motor in a way that ensures adequate cooling.
- The temperature of the cooling air must not exceed 50 °C.
- Keep the cooling fins and fan blades clean.

Related information

[6.4 Ensuring motor cooling](#)

9. User interfaces

WARNING Hot surface

Death or serious personal injury

- Only touch the buttons on the display as the product may be very hot.

WARNING Electric shock

Death or serious personal injury

- If the control panel is cracked or perforated, replace it immediately. Contact the nearest Grundfos sales company.

You can make the pump settings by means of the following user interfaces:

Control panels

- Standard control panel. See section Standard control panel.
- Advanced control panel. See section Advanced control panel.

Remote controls

- Grundfos GO. See section Grundfos GO.

If the power supply to the pump is switched off, the settings are stored.

Related information


[10. Standard control panel](#)

[11. Advanced control panel](#)

[12. Grundfos GO](#)

10. Standard control panel

Pump variant	Fitted as standard	Option
TPE, TPED	•	-
NBE, NBGE, NKE, NKGE & TPE, TPED, NBE, NKE Series 2000	-	-



Standard control panel

TM054848

Pos.	Symbol	Description
1		Grundfos Eye Shows the operating status of the pump. See section Grundfos Eye for further information.
2	-	Light fields for indication of setpoint.
3		Up and down. Changes the setpoint.
4		Allows radio communication with Grundfos GO and other products of the same type. When you try to establish radio communication between the pump and Grundfos GO or another pump, the green indicator light in Grundfos Eye on the pump flashes continuously. Press on the pump control panel to allow radio communication with Grundfos GO and other products of the same type.
5		Makes the pump ready for operation as well as starts and stops the pump. Start If you press the button when the pump is stopped, the pump only starts if no other functions with higher priority have been enabled. See section Priority of settings. Stop If you press the button when the pump is running, the pump always stops. The "Stop" text next to the button is on.

Related information

- 16. Priority of settings
- 17. Grundfos Eye


10.1 Setpoint setting

Set the desired setpoint of the pump by pressing **Up** or **Down**. The light fields on the control panel indicates the setpoint set.

10.1.1 Pump in differential-pressure control mode

The following example applies to a pump in an application where a pressure sensor gives a feedback to the pump. If you retrofit the sensor to the pump, set it manually as the pump does not automatically register a connected sensor.

The figure below shows that the light fields 5 and 6 are activated, indicating a desired setpoint of 3 m with a sensor measuring range from 0 to 6 m. The setting range is equal to the sensor measuring range.




Setpoint set to 3 m, differential-pressure control

TM06891-4

10.1.2 Pump in constant-curve control mode

In constant-curve control mode, the pump performance lies between the maximum and minimum curve of the pump. See the figure below.



Pump in constant-curve control mode


Setting to maximum curve:

- Press continuously to change over to the maximum curve of the pump. The top light field flashes. When the top light field is on, press for 3 seconds until the light field starts flashing.
- To change back, press continuously until the desired setpoint is indicated.

Example

Pump set to maximum curve.

The figure below shows that the top light field is flashing, indicating maximum curve.



Maximum-curve duty


Setting to minimum curve:

- Press continuously to change over to the minimum curve of the pump. The bottom light field flashes. When the bottom light field is on, press for 3 seconds until the light field starts flashing.
- To change back, press continuously until the desired setpoint is indicated.

Example

Pump set to minimum curve.

The figure below shows that the bottom light field is flashing, indicating minimum curve.



Minimum-curve duty

10.1.3 Start-stop of pump



If you have stopped the pump by pressing and the "Stop" text on the control panel is on, you can only give it free to operation by pressing again.

If you have stopped the pump by pressing , you can restart it by pressing or by using Grundfos GO.

Start the pump by pressing or by continuously pressing until the desired setpoint is indicated.

Stop the pump by pressing . When the pump is stopped, the "Stop" text next to the button is on. You can also stop the pump by continuously pressing until none of the light fields are on.

You can also stop the pump with the Grundfos GO or via a digital input set to **External stop**. See section Priority of settings.

Related information

16. Priority of settings


10.1.4 Resetting of fault indications

Reset a fault indication in one of the following ways:

- Via the digital input if it has been set to Alarm resetting.
- Briefly press or on the pump. This does not change the setting of the pump. You cannot reset a fault indication by pressing or if the buttons have been locked.
- Switch off the power supply until the indicator lights are off.
- Switch the external start-stop input off and on.
- With Grundfos GO.

11. Advanced control panel

Pump variant	Fitted as standard	Option
TPE, TPED	-	•
NBE, NBGE, NKE, NKGE & TPE, TPED, NBE, NKE Series 2000	•	-



Advanced control panel

Pos.	Symbol	Description
1		Grundfos Eye Shows the operating status of the pump. For further information, see section Grundfos Eye.
2	-	Graphical colour display.
3		Goes one step back.

Pos.	Symbol	Description
		Navigates between main menus, displays and digits. When you change the menu, the display always shows the top display of the new menu.
4		Navigates between submenus. Changes value settings. Note: If you have disabled the possibility to make settings with the Enable/disable settings function, then you can enable it again temporarily by pressing these buttons simultaneously for at least 5 seconds. See section Buttons of product (Enable/disable settings).
4	OK	Saves changed values, resets alarms and expands the value field. Enables radio communication with Grundfos GO and other products of the same type. When you try to establish radio communication between the pump and Grundfos GO or another pump, the green indicator light in Grundfos Eye flashes. A note also appears in the pump display stating that a wireless device wants to connect to the pump. Press OK on the pump control panel to allow radio communication with Grundfos GO and other products of the same type.
5		Makes the pump ready for operation and starts, and stops the pump. Start: If you press the button when the pump is stopped, the pump only starts if no other functions with higher priority have been enabled. See section Priority of settings. Stop: If you press the button when the pump is running, the pump is always stopped. When you stop the pump via this button, the icon appears in the bottom of the display.
6		Goes to the Home menu.


Related information

13.28 "Buttons on product" (Enable/disable settings)





16. Priority of settings





17. Grundfos Eye

11.1 Home display



Example of **Home** display

Pos.	Symbol	Description
1		Home This menu shows up to four user-defined parameters. You can select parameters shown as shortcut icon  , and when pressing OK you go directly to the "Settings" display for the selected parameter.
2	-	Status This menu shows the status of the pump and system as well as warnings and alarms.
3	-	Settings This menu gives access to all setting parameters. You can make detailed settings of the pump in this menu. See section Description of functions.
4	-	Assist This menu enables assisted pump setup, provides a short description of the control modes and offers fault advice. See section Selection of control mode.
5		Indicates that the pump has been stopped via the  button.

Pos.	Symbol	Description
6		Indicates that the pump is functioning as master pump in a multipump system.
7		Indicates that the pump is functioning as a slave pump in a multipump system.
8		Indicates that the pump is operating in a multipump system. See section Multi-pump setup (Setup of multi-pump system).
9		Indicates that the possibility to make settings has been disabled for protective reasons. See section Buttons on product (Enable/disable settings).

Related information

[13.28 "Buttons on product" \(Enable/disable settings\)](#)

[13.43 "Multipump setup" \(Setup of multi-pump system\)](#)

[14. Selection of control mode](#)

11.2 Startup guide

The function is only available in the HMI 300 operating panels.

The startup guide starts at the first startup and guides you through the settings needed for the product to operate in the given application. When the startup guide has been completed, the main menus appear in the display.

You can always run the startup guide at a later time.

Related information

[13.37 Run start-up guide](#)

11.3 Menu overview for advanced control panel

11.3.1 Main menus

Home	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system
	•	•	•
Status	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system
Operating status	•	•	•
Operating mode, from	•	•	•
Control mode	•	•	•
Pump performance	•	•	•
Actual controlled value	•	•	•
Resulting setpoint	•	•	•
Speed	•	•	•
Acc. flow and specific energy	•	•	•
Power and energy consumption	•	•	•
Measured values	•	•	•
Set date and time	•	•	•
Analog input 1	•	•	•
Analog input 2	•	•	•
Analog input 3	•	•	•
Pt100/1000 input 1	•	•	•
Pt100/1000 input 2	•	•	•
Analog output	•	•	•
Warning and alarm	•	•	•
Actual warning or alarm	•	•	•
Warning log	•	•	•
Alarm log	•	•	•
Operating log	•	•	•
Operating hours	•	•	•
Trend data	•	•	•
Fitted modules	•	•	•

Status	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system
Date and time	•	•	•
Product identification	•	•	•
Motor bearing monitoring	•	•	•
Multi-pump system	-	-	•
System operating status	-	-	•
System performance	-	-	•
System input power and energy	-	-	•
Pump 1, multi-pump system	-	-	•
Pump 2, multi-pump system	-	-	•
Pump 3, multi-pump system	-	-	•
Pump 4, multi-pump system	-	-	•

Settings	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section
Setpoint	•	•	•	<i>Setpoint</i>
Operating mode	•	•	•	<i>Operating mode</i>
Set manual speed	•	•	•	<i>Set manual speed</i>
"Set user-defined speed"	•	•	•	•
Control mode	•	•	•	<i>"Control mode"</i>
Analog inputs	•	•	•	<i>Analog inputs</i>
Analog input 1, setup	•	•	•	
Analog input 2, setup	•	•	•	
Analog input 3, setup	•	•	•	
Built-in Grundfos sensor	-	•	•*	<i>Built-in Grundfos sensor</i>
Pt100/1000 inputs	•	•	•	<i>Pt100/1000 inputs</i>
Pt100/1000 input 1, setup	•	•	•	
Pt100/1000 input 2, setup	•	•	•	
Digital inputs	•	•	•	<i>Digital inputs</i>
Digital input 1, setup	•	•	•	
Digital input 2, setup	•	•	•	

Settings	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section
Digital inputs/outputs	•	•	•	<i>Digital inputs/ outputs</i>
Digital input/output 3, setup	•	•	•	
Digital input/output 4, setup	•	•	•	
Relay outputs	•	•	•	<i>"Signal relays 1 and 2" (Relay outputs)</i>
Relay output 1	•	•	•	
Relay output 2	•	•	•	
Analog output	•	•	•	<i>Analog output</i>
Output signal	•	•	•	
Function of analog output	•	•	•	
"Controller settings"	•	•	•	<i>"Controller " ("Controll er settings")</i>
Operating range	•	•	•	<i>Operating range</i>
Setpoint influence	•	•	•	<i>"Predefine d setpoints"</i>
External setpoint function	•	•	•	
"Predefined setpoints"	•	•	•	
Monitoring functions	•	•	•	<i>Motor bearing monitoring</i>
Motor bearing monitoring	•	•	•	
Motor bearing maintenance	•	•	•	
Limit-exceeded function	•	•	•	<i>Limit- exceeded function</i>
"Special functions"	•		•	<i>"Pulse flowmeter setup"</i>
"Pulse flowmeter setup"	•	•	•	
"Ramps"	•	•	•	
"Standstill heating"	•	•	•	<i>"Standstill heating"</i>
Communication	•	•	•	<i>"Number" (Pump number)</i>
Pump number	•	•	•	

Settings	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section
Enable/disable radio comm.	•	•	•	"Radio communication" (Enable/disable radio comm.)
General settings	•	•	•	
Language	•	•	•	Language
Set date and time	•	•	•	"Date and time" (Set date and time)
Units	•	•	•	"Unit configuration" (Units)
Enable/disable settings	•	•	•	"Buttons on product" (Enable/disable settings)
Delete history	•	•	•	Delete history
Define Home display	•	•	•	Define Home display
Display settings	•	•	•	Display settings
Store actual settings	•	•	•	"Store settings" (Store actual settings)
Recall stored settings	•	•	•	"Recall settings" (Recall stored settings)
Run start-up guide	•	•	•	Run start-up guide

*Applies only to a multipump system with TPE, TPED, NBE, NKE Series 2000 pumps.


Assist	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section
Assisted pump setup	•	•	•	<i>Assisted pump setup</i>
Setup, analog input	•	•	•	<i>Setup, analog input</i>
Setting of date and time	•	•	•	<i>"Multipump setup" (Setup of multi-pump system)</i>
Setup of multi-pump system	•	•	•	<i>"Multipump setup" (Setup of multi-pump system)</i>
Description of control mode	•	•	•	<i>Description of control mode</i>
Assisted fault advice	•	•	•	<i>Assisted fault advice</i>

12. Grundfos GO

The pump is designed for wireless radio or infrared communication with Grundfos GO.

Grundfos GO enables setting of functions and gives access to status overviews, technical product information and actual operating parameters.

Grundfos GO offers the following mobile interfaces (MI).



TM066256

Grundfos GO communicating with the pump via radio or infrared connection, IR

12.1 Communication

When Grundfos GO initiates communication with the pump, the indicator light in the middle of Grundfos Eye flashes green. See section Grundfos Eye.

Furthermore, on pumps fitted with an advanced control panel a text appears in the display saying that a wireless device is trying to establish connection.

Press **OK** on the pump in order to establish connection with Grundfos GO or press **⬆** to reject connection.

Establish communication using one of these communication types:

- radio communication
- infrared communication.

Related information

[17. Grundfos Eye](#)

12.1.1 Radio communication

Radio communication can take place at distances up to 30 m. The first time Grundfos GO communicates with the pump, you must enable communication

by pressing **⌂** or **OK** on the pump control panel.

Later when communication takes place, the pump is recognized by Grundfos GO and you can select the pump from the **List** menu.

12.1.2 Infrared communication

When communicating via infrared light, Grundfos GO must be pointed at the pump control panel.

Pos.	Description
1	<p>Grundfos MI 204:</p> <p>Add-on module enabling radio or infrared communication. You can use MI 204 in conjunction with an Apple iPhone or iPod with Lightning connector, for example fifth generation or later iPhone or iPod.</p> <p>MI 204 is also available together with an Apple iPod touch and a cover.</p>
2	<p>Grundfos MI 301:</p> <p>Separate module enabling radio or infrared communication. You can use the module in conjunction with an Android or iOS-based smart device with Bluetooth connection.</p>

12.2 Menu overview for Grundfos GO

Dashboard	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system
	•	•	•
"Status"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system
"System mode"	-	-	•*
"Resulting setpoint"	•	•	
"Resulting system setpoint"	-	-	•*
"Actual controlled value"	•	•	•*
"Motor speed (rpm, %)"	•	•	-
"Power consumption"	•	•	-
"Power cons., sys."	-	-	•*
"Energy consumption"	•	•	
"Energy cons., sys."	-	-	•*
"Acc. flow, specific energy"	•	•	•*
"Operating hours"	•	•	
"Operating hours, system"	-	-	•*
"Analog input 1"	•	•	-
"Analog input 2"	•	•	-
"Analog input 3"	•	•	-
"Pt100/1000 input 1"	•	•	-
"Pt100/1000 input 2"	•	•	-
"Analog output"	•	•	-
"Digital input 1"	•	•	-
"Digital input 2"	•	•	-
"Digital in/output 3"	•	•	-
"Digital in/output 4"	•	•	-
"Fitted modules"	•	•	-
"Pump 1"	-	-	•*
"Pump 2"	-	-	•*

"Status"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system
"Pump 3"	-	-	•*
"Pump 4"	-	-	•*

*Only available if Grundfos GO is connected to a multipump system.

"Settings"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section
"Setpoint"	•	•	•	<i>Setpoint</i>
"Operating mode"	•	•	•	<i>Operating mode</i>
"Set user-defined speed"	•	•	•	13.4 User-defined speed
"Control mode"	•	•	•	<i>"Control mode"</i>
"Proportional-pressure setup"	-	•	-	<i>"Proportional-pressure setup"</i>
"Buttons on product"	•	•	•	<i>"Buttons on product" (Enable/disable settings)</i>
"Controller"	•	•	•	<i>"Controller" ("Controller settings")</i>
"Operating range"	•	•	•	<i>Operating range</i>
"Ramps"	•	•	-	<i>"Ramps"</i>
"Pump number"	•	•	-	<i>"Number" (Pump number)</i>
"Radio communication"	•	•	-	<i>"Radio communication" (Enable/disable radio comm.)</i>
"Analog input 1"	•	•	-	<i>Analog inputs</i>
"Analog input 2"	•	•	-	
"Analog input 3"	•	•	-	
"Built-in Grundfos sensor"	-	•	• ²⁾	<i>Built-in Grundfos sensor</i>
"Pt100/1000 input 1"	•	•	-	<i>Pt100/1000 inputs</i>
"Pt100/1000 input 2"	•	•	-	
"Digital input 1"	•	•	-	<i>Digital inputs</i>
"Digital input 2"	•	•	-	
"Digital in/output 3"	•	•	-	<i>Digital inputs/outputs</i>
"Digital in/output 4"	•	•	-	

"Settings"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section
"Predefined setpoint"	•	•	•	<i>"Predefined setpoints"</i>
"Analog output"	•	•	-	<i>Analog output</i>
"External setpoint funct."	•	•	-	<i>"Predefined setpoints"</i>
"Signal relay 1"	•	•	-	<i>"Signal relays 1 and 2" (Relay outputs)</i>
"Signal relay 2"	•	•	-	
"Limit 1 exceeded"	•	•	•	<i>Limit-exceeded function</i>
"Limit 2 exceeded"	•	•	•	
"Alternating operation, time"	-	-	• ¹⁾	<i>"Multipump setup" (Setup of multipump system)</i>
"Time for pump changeover"	-	-	• ¹⁾	
"Standstill heating"	•	•	-	<i>"Standstill heating"</i>
"Motor-bearing monitoring"	•	•	-	<i>Motor bearing monitoring</i>
"Service"	•	•	-	<i>"Service"</i>
"Date and time"	•	•	•	<i>"Date and time" (Set date and time)</i>
"Store settings"	•	•	-	<i>"Store settings" (Store actual settings)</i>
"Recall settings"	•	•	-	<i>"Recall settings" (Recall stored settings)</i>
"Undo"	•	•	•	<i>"Undo"</i>
"Pump name"	•	•	•	<i>"Pump name"</i>
"Connection code"	•	•	•	<i>"Connection code"</i>
"Unit configuration"	•	•	•	<i>"Unit configuration" (Units)</i>

¹⁾Only available if Grundfos GO is connected to a multipump system.

²⁾Applies only to a multipump system with TPE, TPED, NBE, NKE Series 2000 pumps.

"Alarms and warnings"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section	Page
"Alarm log"	•	•	•	<i>Alarm log</i>	<i>Alarm log</i>

"Alarms and warnings"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section	Page
"Warning log"	•	•	•	<i>Warning log</i>	<i>Warning log</i>
"Reset alarm" button	•	•	•		

"Assist"	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Multipump system	Section	Page
"Assisted pump setup"	•	•		<i>Assisted pump setup</i>	<i>Assisted pump setup</i>
"Assisted fault advice"	•	•	•	<i>Assisted fault advice</i>	<i>Assisted fault advice</i>
"Multipump setup"	•	•	•	<i>"Multipump setup" (Setup of multi-pump system)</i>	<i>"Multipump setup" (Setup of multi-pump system)</i>

13. Description of functions

13.1 Setpoint

Pump variant	Setpoint
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can set the setpoint for all control modes in this submenu when you have selected the desired control mode. See section Control mode.

Factory setting

See section Factory setting.

Related information

[13.5 "Control mode"](#)

[30. Factory settings](#)


13.2 Operating mode

Pump variant	Operating mode
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Possible operating modes:

- **Normal** The pump runs according to the selected control mode.
- **Stop** The pump stops.
- **Min.** Use the minimum-curve mode in periods in which a minimum flow is required.
- **Max.** Use the maximum-curve mode in periods in which a maximum flow is required. This operating mode is for instance suitable for systems with hot-water priority.
- **Manual** The pump is operating at a manually set speed. In **Manual** the setpoint via bus is overruled. See section Set manual speed.
- "User-defined speed" The motor is operating at a speed set by the user. See section Set user-defined speed.

All operating modes are illustrated in the figure below.



TM064 024

Operating modes

Pos.	Description
1	Normal
2	Normal
3	Manual

Related information

[13.3 Set manual speed](#)

[13.4 User-defined speed](#)

13.3 Set manual speed

Pump variant	Set manual speed
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel. With Grundfos GO, you set the speed via the **Setpoint** menu.

You can set the pump speed in % of the maximum speed. When you have set the operating mode to **Manual**, the pump starts running at the set speed. The speed can then be changed manually via Grundfos GO or via the advanced control panel.

Factory setting

See section Factory setting.

Related information

[30. Factory settings](#)

13.4 User-defined speed

Use this function to set the motor speed in percentage of the maximum speed. When you have set the operating mode to **User-defined speed**, the pump starts running at the set speed.

13.5 "Control mode"

Pump variant	"Control mode"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Possible control modes:

- **Prop. pressure** (proportional pressure)
- **Const. pressure** (constant pressure)
- **Const. temp.** (constant temperature)
- **Con. diff. press.** (constant differential pressure)
- **Con. diff. temp.** (constant differential temperature)
- **Const. flow rate** (constant flow rate)
- **Const. level** (constant level)
- **Const. other val.** (constant other value)
- **Const. curve** (constant curve).



The operating mode must be set to **Normal** before a control mode can be enabled.

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.5.1 "Proportional pressure"


Pump variant	"Proportional pressure"
TPE, TPED, NBE, NBGE, NKE, NKGE	-
TPE, TPED, NBE, NKE Series 2000	•

The head of the pump is reduced at decreasing water demand and increased at rising water demand.

This control mode is especially suitable in systems with relatively large pressure losses in the distribution pipes. The head of the pump increases proportionally to the flow in the system to compensate for the large pressure losses in the distribution pipes.

The setpoint can be set with an accuracy of 0.1 metre. The head against a closed valve is half the setpoint.


For more information about settings, see section "Proportional pressure".



"Proportional pressure"

Example

- Factory-fitted differential-pressure sensor.



"Proportional pressure"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").

Related information


[13.6 "Proportional-pressure setup"](#)

[13.14 "Controller" \("Controller settings"\)](#)

13.5.2 "Constant pressure"

Pump variant	"Constant pressure"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

We recommend this control mode if the pump is to deliver a constant pressure, independently of the flow in the system. The pump maintains a constant pressure independently of the flow rate.




TM057901

"Constant pressure"

This control mode requires an external pressure sensor as shown in the examples below. You can set the pressure sensor in the **Assist** menu. See section "Assisted pump setup".

Examples

- One external pressure sensor.



"Constant pressure"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").

Related information


[13.14 "Controller" \("Controller settings"\)](#)

[13.41 Assisted pump setup](#)

13.5.3 "Constant temperature"

Pump variant	"Constant temperature"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This control mode ensures a constant temperature. Constant temperature is a comfort control mode that you can use in domestic hot-water systems to control the flow to maintain a constant temperature in the system. See fig. "Constant temperature".




TM057900

"Constant temperature"

This control mode requires an external temperature sensor. See the examples below.

Examples

- One external temperature sensor.



"Constant temperature"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").


Related information

[13.14 "Controller" \("Controller settings"\)](#)

13.5.4 "Constant differential pressure"

Pump variant	"Constant differential pressure"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The pump maintains a constant differential pressure, independently of the flow in the system. This control mode is primarily suitable for systems with relatively small pressure losses.




"Constant differential pressure"



This control mode requires either an internal or external differential-pressure sensor or two external pressure sensors. See the examples below.

Examples


- Factory-fitted differential-pressure sensor, only TPE, TPED, NBE, NKE Series 2000.



One external differential-pressure sensor. The pump uses the input from the sensor to control the differential pressure. You can set the sensor manually or by using the **Assist** menu. See section "Assisted pump setup".



Two external pressure sensors. Constant differential-pressure control is achievable with two pressure sensors. The pump uses the inputs from the two sensors and calculates the differential pressure. The sensors must have the same unit and must be set as feedback sensors. You can set the sensors manually, sensor by sensor, or by using the **Assist** menu. See section "Assisted pump setup".



"Constant differential pressure"

Controller settings

For recommended controller settings, see section "Controller ("Controller settings")".

Related information


[13.14 "Controller" \("Controller settings"\)](#)

[13.41 Assisted pump setup](#)

13.5.5 "Constant differential temperature"

Pump variant	"Constant differential temperature"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The pump maintains a constant differential temperature in the system and the pump performance is controlled according to this.




TM057954

"Constant differential temperature"

This control mode requires either two external temperature sensors or one external differential-temperature sensor. See the examples below.


Examples

- Two external temperature sensors.



TM057894

- One external differential-temperature sensor.



TM057931

"Constant differential temperature"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").


Related information

[13.14 "Controller" \("Controller settings"\)](#)

13.5.6 "Constant flow rate"

Pump variant	"Constant flow rate"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The pump maintains a constant flow in the system, independently of the head.




TM057955

"Constant flow rate"

This control mode requires an external flow sensor. See the example below.

Example

- One external flow sensor.



TM057895

"Constant flow rate"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").


Related information

[13.14 "Controller" \("Controller settings"\)](#)

13.5.7 "Constant level"

Pump variant	"Constant level"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The pump maintains a constant level, independently of the flow rate.



"Constant level"


This control mode requires an external level sensor. The pump can control the level in a tank in two ways:

- as an emptying function where the pump draws the liquid from the tank.
- as a filling function where the pump pumps the liquid into the tank.


The type of level control function depends on the setting of the built-in controller. See section "Controller" ("Controller settings").

Examples

- One external level sensor. emptying function.



- One external level sensor. filling function.



"Constant level"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").

Related information

[13.14 "Controller" \("Controller settings"\)](#)

13.5.8 "Constant other value"

Pump variant	"Constant other value"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•


Any other value is kept constant.

13.5.9 "Constant curve"

Pump variant	"Constant curve"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can set the pump to operate according to a constant curve, like an uncontrolled pump.

You can set the desired speed in % of the maximum speed in the range from 25 to 100 % (110 %).



TM057957

"Constant curve"

Controller settings

For recommended controller settings, see section "Controller" ("Controller settings").

Related information

[13.14 "Controller" \("Controller settings"\)](#)

13.6 "Proportional-pressure setup"

Pump variant	"Proportional-pressure setup"
TPE, TPED, NBE, NBGE, NKE, NKGE	-
TPE, TPED, NBE, NKE Series 2000	•

"Control-curve function"

You can set the curve either to quadratic or linear.

"Zero-flow head"

You can set this value in % of the setpoint. With a setting of 100 %, the control mode is equal to constant differential pressure.

13.7 Analog inputs

Pump variant	Analog inputs
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Function	Terminal*
Analog input 1, setup	4
Analog input 2, setup	7
Analog input 3, setup	14

*See section Connection terminals, advanced functional module, FM 300.

Set the analog input for a feedback sensor via the **Assisted pump setup** menu. See section "Assisted pump setup".

If you want to set an analog input for other purposes, you can do this manually.

You can set the analog inputs via the **Setup, analog input** menu. See section "Setup, analog input".

If you perform the manual setting via Grundfos GO, you need to enter the menu for the analog input under the **Settings** menu.



Function

You can set the analog inputs to these functions:

- **Not active.**
- **Feedback sensor.**
- **Ext. setpoint infl..** See section "Setpoint influence".
- **Other function.**

Measured parameter

Select one of the parameters, such as the parameter to be measured in the system by the sensor connected to the actual analog input.



TM062328

Overview of sensor locations

Sensor function, measured parameter	Pos.
Inlet pressure	1
Diff. press., inlet	2
Liquid temp.	3
Diff. press.,outlet	4
Diff. press.,pump	5
Operating mode	6
Press. 2, external	7
Diff. press., ext.	8
Storage tank level	9
Feed tank level	10
Pump flow	11
Flow, external	12
Liquid temp.	13
Temperature 1	14
Temperature 2	15
Diff. temp., ext.	16
Ambient temp.	Not shown
Other parameter	Not shown

Unit

Available measuring units:

Parameter	Possible measuring units
Pressure	bar, m, kPa, psi, ft
Level	m, ft, in
Flow rate	m ³ /h, l/s, yd ³ /h, gpm
Liquid temp.	°C, °F
Other parameter	%

"Electrical signal"

Select signal type:

- 0.5-3.5 V
- 0-5 V
- 0-10 V
- 0-20 mA
- 4-20 mA.

Sensor range, minimum value

Set the minimum value of the connected sensor.

Sensor range, maximum value

Set the maximum value of the connected sensor.

Factory setting

See section Factory settings.

Related information

[7.5.1 Connection terminals, advanced functional module, FM 300](#)

[13.16.1 Setpoint influence](#)

[13.41 Assisted pump setup](#)

[13.42 Setup, analog input](#)

[30. Factory settings](#)

13.7.1 Setting two sensors for differential measurement

To measure the difference of a parameter between two points, set the corresponding sensors as follows:

Parameter	Analog input for sensor 1	Analog input for sensor 2
Pressure, option 1	Differential pressure, inlet	Differential pressure, outlet
Pressure, option 2	Pressure 1, external	Pressure 2, external
Flow	Pump flow	Flow, external
Temperature	Temperature 1	Temperature 2



If you want to use the control mode Constant differential pressure, you must choose the function **Feedback sensor** for the analog input of both sensors.

13.8 Built-in Grundfos sensor

Pump variant	Built-in Grundfos sensor
TPE, TPED, NBE, NBGE, NKE, NKGE	-
TPE, TPED, NBE, NKE Series 2000	•

You can select the function of the built-in sensor in the **Built-in Grundfos sensor** menu.

Set the **Built-in Grundfos sensor** via the **Assisted pump setup** menu. See section "Assisted pump setup".

If you perform the setting manually in the advanced control panel, you must enter the **Analog inputs** menu under the **Settings** menu in order to access the **Built-in Grundfos sensor** menu.

If you perform the setting manually via Grundfos GO, you need to enter the menu for the **Built-in Grundfos sensor** under the **Settings** menu.

Function

You can set the built-in sensor to these functions:

- **Grundfos diff.-pressure sensor - Not active - Feedback sensor - Setpoint influence - Other function.**

Factory setting

See section Factory settings.

Related information

[13.41 Assisted pump setup](#)

[30. Factory settings](#)

13.9 Pt100/1000 inputs

Pump variant	Pt100/1000 inputs
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Function	Terminal*
Pt100/1000 input 1, setup	17 and 18
Pt100/1000 input 2, setup	18 and 19

*See section [Connection terminals, advanced functional module, FM 300](#).

Set the Pt100/1000 input for a feedback sensor via the **Assisted pump setup** menu. See section "Assisted pump setup".

If you want to set a Pt100/1000 input for other purposes, you can do this manually.

You can set the analog inputs via the **Setup, analog input** menu. See section "Setup, analog input".

If you perform the manual setting via Grundfos GO, you need to enter the menu for the Pt100/1000 input under the **Settings** menu.


Function

You can set the Pt100/1000 inputs to these functions:

- **Not active**
- **Feedback sensor**
- **Ext. setpoint infl.** See section "Setpoint influence".
- **Other function.**

Measured parameter

Select one of the parameters, such as the parameter to be measured in the system by the Pt100/1000 sensor connected to the actual Pt100/1000 input.



Overview of Pt100/1000 sensor locations

Parameter	Pos.
Liquid temp.	1
Temperature 1	2
Temperature 2	3
Ambient temp.	Not shown

Measuring range

-50 to 204 °C.

Factory setting

See section Factory settings.

Related information

[7.5.1 Connection terminals, advanced functional module, FM 300](#)

[13.16.1 Setpoint influence](#)

[13.41 Assisted pump setup](#)

[13.42 Setup, analog input](#)

[30. Factory settings](#)

13.10 Digital inputs

Pump variant	Digital inputs
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Function	Terminal*
Digital input 1, setup	2 and 6
Digital input 2, setup	1 and 9

*See section Connection terminals, advanced functional module, FM 300.

To set a digital input, make the settings below.

Function

Select one of these functions:

- **Not active**
When set to **Not active**, the input has no function.
- **External stop**
When the input is deactivated, open circuit, the pump stops.
- **Min.**
(minimum speed) When the input is activated, the pump runs at the set minimum speed.
- **Max.**
(maximum speed) When the input is activated, the pump runs at the set maximum speed.
- "User-defined speed"
When the input is activated, the motor runs at a speed set by the user.
- **External fault**
When the input is activated, a timer is started. If the input is activated for more than 5 seconds, the pump stops and a fault is indicated. This function depends on input from external equipment.
- **Alarm resetting**
When the input is activated, a possible fault indication is reset.
- **Dry running**
When this function has been selected, lack of inlet pressure or water shortage can be detected. When lack of inlet pressure or water shortage, dry running, is detected, the pump stops. The pump cannot restart as long as the input is activated. This requires the use of an accessory, such as:
 - a pressure switch installed on the inlet side of the pump
 - a float switch installed on the inlet side of the pump.
- **Accumulated flow**

When this function has been selected, the accumulated flow can be registered. This requires the use of a flowmeter which gives a feedback signal as a pulse per defined flow of water. See section "Pulse flowmeter setup".

- **Predefined setpoint digit 1**, applies only to digital input 2. When digital inputs are set to predefined setpoint, the pump operates according to a setpoint based on the combination of the activated digital inputs. See section "Predefined setpoint".

The priority of the selected functions in relation to each other appears from section Priority of settings. A stop command always has the highest priority.

Activation delay

Select the activation delay, T1.

It is the time between the digital signal and the activation of the selected function.

Range: 0 to 6000 seconds.

Duration timer mode


Select the mode.

- **Not active**
- active with interrupt, mode A
- active without interrupt, mode B
- active with after-run, mode C.

Select the duration time, T2.

It is the time which, together with the mode, determines how long the selected function is active.

Range: 0 to 15,000 seconds.



Duration timer function of digital inputs

Pos.	Description
A	Mode C
B	Mode B
C	Mode A
DI	Digital input

Factory setting

See section Factory settings.

Related information

7.5.1 *Connection terminals, advanced functional module, FM 300*

13.16.2 *"Predefined setpoints"*

13.18 *"Pulse flowmeter setup"*

16. *Priority of settings*

30. *Factory settings*


13.11 Digital inputs/outputs

Pump variant	Digital inputs/outputs
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Function	Terminal*
Digital input/output 3, setup	10 and 16
Digital input/output 4, setup	11 and 18

*See section Connection terminals, advanced functional module, FM 300.

You can select if the interface must be used as input or output. The output is an open collector and you can connect it to for example an external relay or controller such as a PLC.



Example of configurable digital inputs or outputs

Pos.	Description
1	External controller

To set a digital input or output, make the settings below.

Mode

You can set the digital input or output 3 and 4 to act as digital input or digital output:

- **Digital input**
- **Digital output.**

Function

You can set the digital input or output 3 and 4 to these functions:

Possible functions, digital input or output 3

Function if input See details in section Digital inputs	Function if output See details in section "Signal relays 1 and 2" (Relay output)
Not active	
External stop	Not active
Min.	Ready
Max.	Alarm
"User-defined speed"	Operation
External fault	Pump running
Alarm resetting	Warning
Dry running	Limit 1 exceeded
Accumulated flow	Limit 2 exceeded
"Predefined setpoint digit 2"	

Possible functions, digital input or output 4

Function if input See details in section Digital inputs	Function if output See details in section "Signal relays 1 and 2" (Relay outputs)
Not active	
External stop	Not active
Min.	Ready
Max.	Alarm
"User-defined speed"	Operation
External fault	Pump running
Alarm resetting	Warning
Dry running	Limit 1 exceeded
Accumulated flow	Limit 2 exceeded
"Predefined setpoint digit" 3"	

Activation delay

Select the activation delay, T1.

It is the time between the digital signal and the activation of the selected function.

Range: 0 to 6000 seconds.


Duration timer mode

Select the mode.

- **Not active**
- active with interrupt, mode A
- active without interrupt, mode B
- active with after-run, mode C.

Select the duration time, T2.

It is the time which, together with the mode, determines how long the selected function is active. Range: 0 to 15,000 seconds.



Duration timer function of digital inputs

Pos.	Description
A	Mode C
B	Mode B
C	Mode A
DI	Digital input

Factory setting

See section Factory setting.

Related information

[7.5.1 Connection terminals, advanced functional module, FM 300](#)

[13.10 Digital inputs](#)

[13.10 Digital inputs](#)

[13.12 "Signal relays 1 and 2" \(Relay outputs\)](#)

[30. Factory settings](#)

13.12 "Signal relays 1 and 2" (Relay outputs)

Pump variant	"Signal relays 1 and 2"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Function	Terminal*
Relay output 1	NC, C1, NO

Function	Terminal*
Relay output 2	NC, C2, NO

*See section Connection terminals, advanced functional module, FM 300.

The pump incorporates two signal relays for potential-free signalling. For further information, see section Signal relays.

Function

You can configure the signal relays to be activated by one of the following incidents:

- **Not active.**
- **Ready**
The pump can be running or is ready to run and no alarms are present.
- **Alarm**
There is an active alarm and the pump is stopped.
- **"Operating" (Operation)**
"Operating" equals "Running" but the pump is still in operation when it has been stopped due to a warning.
- **"Running" (Pump running)**
- **Warning**
There is an active warning.
- **Limit 1 exceeded**
When the **Limit 1 exceeded** function is activated, the signal relay is activated. See section "Limit-exceeded function".
- **Limit 2 exceeded**
When the **Limit 2 exceeded** function is activated, the signal relay is activated. See section "Limit-exceeded function".
- **Relubricate**
- **"External fan control" (Control of external fan)**
When you select "External fan control", the relay is activated if the internal temperature of the motor electronics reach a preset limit value.

Factory setting

See section Factory settings.

Related information

[7.5.1 Connection terminals, advanced functional module, FM 300](#)

[13.17 Limit-exceeded function](#)

[18. Signal relays](#)

[30. Factory settings](#)

13.13 Analog output

Pump variant	Analog output
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Function	Terminal*
Analog output	12

*See section Connection terminals, advanced functional module, FM 300.

The analog output enables the transfer of certain operating data to external control systems.

To set the analog output, make the settings below.

Output signal

- 0-10 V
- 0-20 mA
- 4-20 mA.

Function of analog output

- Actual speed.

Signal range [V, mA]	Actual speed [%]		
	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of nominal speed.

- Actual value

Signal range [V, mA]	Actual value	
	Sensor _{min}	Sensor _{max}
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the range between sensor_{min} and sensor_{max}.

- Resulting setpoint

Signal range [V, mA]	Resulting setpoint [%]	
	0	100
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the external setpoint range.

- Motor load

Signal range [V, mA]	Motor load [%]	
	0	100
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the maximum permissible load at the actual speed.

- Motor current

Signal range [V, mA]	Motor current [%]		
	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the rated current.

- Limit 1 exceeded and Limit 2 exceeded

Signal range [V, mA]	Limit-exceeded function	
	Output not active	Output active
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The **Limit-exceeded function** is typically used for monitoring of secondary parameters in the system. If the limit is exceeded, an output, warning or alarm is activated.

- Flow rate

Signal range [V, mA]	Flow rate [%]		
	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the nominal flow.

Factory setting

See section Factory settings.

Related information

[7.5.1 Connection terminals, advanced functional module, FM 300](#)

[30. Factory settings](#)

13.14 "Controller" ("Controller settings")

Pump variant	"Controller"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The pumps have a factory setting of gain, K_p , and integral time, T_i .





However, if the factory setting is not the optimum setting, you can change the gain and the integral time.

- Set the gain within the range from 0.1 to 20.
- Set the integral time within the range from 0.1 to 3600 seconds. If you select 3600 seconds, the controller functions as a P controller.



Furthermore, you can set the controller to inverse control. This means that if the setpoint is increased, the speed is reduced. In the case of inverse control, the gain must be set within the range from -0.1 to -20.

Guidelines for setting of PI controller

The tables below show the recommended controller settings:

"Differential-pressure control"	K_p	T_i
 TM057886	0.5	0.5
 TM057888		
 TM056495	0.5	$L1 < 5 \text{ m: } 0.5$ $L1 > 5 \text{ m: } 3$ $L1 > 10 \text{ m: } 5$
 TM056494		



$L1$: distance in metres between pump and sensor.

"Temperature control"	K_p		T_i
	Heating system ¹⁾	Cooling system ²⁾	
 TM0564881	0.5	-0.5	$10 + 5L2$
 TM056491	0.5	-0.5	$30 + 5L2$


¹⁾In heating systems, an increase in pump performance results in a rise in temperature at the sensor.



²⁾In cooling systems, an increase in pump performance results in a drop in temperature at the sensor.



$L2$: distance in metres between heat exchanger and sensor.

"Differential-temperature control"	K_p	T_i
 TM057937	-0.5	10 + 5L2
 TM057936		

L2: distance in metres between heat exchanger and sensor.

"Flow control"	K_p	T_i
 TM057895	0.5	0.5

"Constant pressure control"	K_p	T_i
 TM057881	0.5	0.5
 TM057882	0.1	0.5

"Level control"	K_p	T_i
 TM057896	-2.5	100
 TM057965	2.5	100

Rules of thumb

If the controller is too slow-reacting, increase the gain.

If the controller is hunting or unstable, dampen the system by reducing the gain or increasing the integral time.

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.15 Operating range


Pump variant	Operating range
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Set the operating range as follows:

- Set the minimum speed within the range from fixed minimum speed to user-set maximum speed.
- Set the maximum speed within the range from user-set minimum speed to fixed maximum speed.

The range between the user-set minimum and maximum speeds is the operating range.

Speeds below 25 % may result in noise from the shaft seal.



Example of minimum and maximum settings

TM006785

Pos.	Description
1	Fixed maximum speed
2	User-set maximum speed
3	"Operating range"
4	User-set minimum speed
5	Fixed minimum speed

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.16 External setpoint function

Pump variant	External setpoint function
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can influence the setpoint by an external signal, either via one of the analog inputs or, if an advanced functional module is fitted, via one of the Pt100/1000 inputs.



Before you can enable the **External setpoint function**, you must set one of the analog inputs or Pt100/1000 inputs to **Setpoint influence**.


See sections "Analog inputs" and "Pt100/1000 inputs".

If more than one input has been set to **Setpoint influence**, the function selects the analog input with the lowest number, for example **Setting of pump**, and ignores the other inputs, for example **Analog input 3** or "Pt100/1000 input 1".

Example with constant pressure with linear influence

Actual setpoint: actual input signal x (setpoint - sensor min.) + sensor min.

At a lower sensor value of 0 bar, a setpoint of 2 bar and an external setpoint of 60 %, the actual setpoint is $0.60 \times (2 - 0) + 0 = 1.2$ bar.



TM064165


Example of setpoint influence with sensor feedback

Pos.	Description
A	Actual input signal, 60 %
B	External setpoint signal
SP	Setpoint
S _{max}	Sensor max.
S _{min}	Sensor min.
SP _a	Actual setpoint

Example with constant curve with linear influence

Actual setpoint: actual input signal x (setpoint - user-set minimum speed) + user-set minimum speed.

At a user-set minimum speed of 25 %, a setpoint of 85 % and an external setpoint of 60 %, the actual setpoint is $0.60 \times (85 - 25) + 25 = 61\%$.



Example of setpoint influence with constant curve

Pos.	Description
A	External setpoint signal
S%	Speed [%]
B	Fixed maximum speed
C	Actual input signal, 60 %
D	User-set minimum. speed
SP	Setpoint
SP _a	Actual setpoint

Factory setting

See section Factory settings.

Related information

[13.7 Analog inputs](#)

[13.9 Pt100/1000 inputs](#)

[30. Factory settings](#)

13.16.1 Setpoint influence


Pump variant	Setpoint influence
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The table below gives an overview of the types of setpoint influence and the availability depending on pump type.

Setpoint influence	Pump type	
	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000
Not active	•	•
Linear function	•	•
Linear with Stop	•	•
Influence table	•	•

You can select these functions:

- **Not active** When set to **Not active**, the setpoint is not influenced from any external function.
- **Linear function** The setpoint is influenced linearly from 0 to 100 %.




Linear function

Digital inputs			Setpoint
2	3	4	
0	0	0	Normal setpoint or stop
1	0	0	Predefined setpoint 1
0	1	0	Predefined setpoint 2
1	1	0	Predefined setpoint 3
0	0	1	Predefined setpoint 4
1	0	1	Predefined setpoint 5
0	1	1	Predefined setpoint 6
1	1	1	Predefined setpoint 7

0: Open contact
1: Closed contact

Example

The figure below shows how you can use the digital inputs to set seven predefined setpoints. Digital input 2 is open and digital inputs 3 and 4 are closed. If you compare with the table above, you can see that "Predefined setpoint 6" is activated.



Principle sketch showing how predefined setpoints function

Pos.	Description
SP	Set point
DI	Digital input
SP _a	Actual set point
SP _n	Normal set point

If all digital inputs are open, the pump either stops or runs at the normal setpoint. Set the desired action with Grundfos GO or with the advanced control panel.

Factory setting

See section Factory settings.

Related information

30. Factory settings

13.17 Limit-exceeded function

Pump variant	Limit-exceeded function
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This function can monitor a measured parameter or one of the internal values such as speed, motor load or motor current. If a set limit is reached, a selected action can take place. You can set two limit-exceeded functions meaning that you can monitor two parameters or two limits of the same parameter simultaneously.

The function requires setting of the following:

Measured

Here you set the measured parameter to be monitored.

"Limit"

Here you set the limit which activates the function.

"Hysteresis band"

Here you set the hysteresis band.

"Limit exceeded when"

Here you can set the function to be activated when the selected parameter exceeds or drops below the set limit.

- "Above limit" The function is activated if the measured parameter exceeds the set limit.
- "Below limit" The function is activated if the measured parameter drops below the set limit.

Action

If the value exceeds a limit, you can define an action. You can select the following actions:

- "No action" The pump remains in its current state. Use this setting if you only want to have a relay output when the limit is reached. See section "Signal relays 1 and 2" (Relay outputs).
- "Warning/alarm" There is a warning.
- **Stop** The pump stops.
- **Min.** The pump reduces speed to minimum.
- **Max.** The pump increases speed to maximum.
- "User-defined speed" The pumps runs at a speed set by the user.

"Detection delay"


You can set a detection delay which ensures that the monitored parameter stays above or below a set limit in a set time before the function is activated.

"Resetting delay"

The resetting delay is the time from which the measured parameter differs from the set limit including the set hysteresis band and until the function is reset.

Example

The function is to monitor the outlet pressure of a pump. If the pressure is below 5 bar for more than 5 seconds, a warning must be given. If the outlet pressure is above 7 bar for more than 8 seconds, you must reset the warning.



TM064603

"Limit exceeded" (example)

Pos.	Setting parameter	Setting
1	Measured	"Outlet pressure"
2	"Limit"	5 bar
3	"Hysteresis band"	2 bar
4	"Limit exceeded when"	"Below limit"
5	"Detection delay"	5 seconds
6	"Resetting delay"	8 seconds
A	Limit-exceeded function active	-
-	"Action"	"Warning"

Factory setting

See section Factory settings.

Related information

[13.12 "Signal relays 1 and 2" \(Relay outputs\)](#)

[30. Factory settings](#)

13.18 "Pulse flowmeter setup"

Pump variant	"Pulse flowmeter setup"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can connect an external pulse flowmeter to one of the digital inputs in order to register the actual and accumulated flows. Based on this, you can also calculate the specific energy.

To enable a pulse flowmeter, set one of the digital-input functions to **Accumulated flow** and set the pumped volume per pulse. See section "Digital inputs".

Factory setting

See section Factory settings.

Related information

[13.10 Digital inputs](#)

[30. Factory settings](#)

13.19 "Ramps"

Pump variant	"Ramps"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The ramps determine how quickly the motor can accelerate and decelerate, respectively, during start-stop or setpoint changes.


You can set the following:

- acceleration time, 0.1 to 300 seconds
- deceleration time, 0.1 to 300 seconds.

The times apply to the acceleration from 0 rpm to fixed maximum speed and the deceleration from fixed maximum speed to 0 rpm.

At short deceleration times, the deceleration of the motor may depend on load and inertia as there is no possibility of actively braking the motor.

If the power supply is switched off, the deceleration of the motor only depends on load and inertia.



Ramp-up and ramp-down

Pos.	Description
1	Fixed maximum
2	User set maximum
3	User set minimum
4	Fixed initial ramp
5	Fixed final ramp
6	User set ramp-up
7	User set ramp-down
A	Speed
B	Time

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.20 "Standstill heating"

Pump variant	"Standstill heating"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can use this function to avoid condensation in humid environments. When you set the function to "Active" and the pump is in operating mode **Stop**, a low AC voltage is applied to the motor windings. The voltage is not high enough to make the motor rotate but ensures that sufficient heat is generated to avoid condensation in the motor including the electronic parts in the drive.



Remember to remove the drain plugs and fit a cover over the motor.

13.21 Motor bearing monitoring

Pump variant	Motor bearing monitoring
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can set the motor bearing monitoring function to these values:

- "Active"
- **Not active**

When the function is set to "Active", a counter in the controller starts counting the mileage of the bearings.

When the function is changed to "Active" again, the accumulated mileage is again used to calculate the replacement time.

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.22 "Service"

Pump variant	"Service"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

"Time until next service" (Motor bearing service)

This display shows when to replace the motor bearings. The controller monitors the operating pattern of the motor and calculates the period between bearing replacements.

Displayable values:

- "in 2 years"
- "in 1 year"
- "in 6 months"
- "in 3 months"
- "in 1 month"
- "in 1 week"
- "Now"

"Bearing replacements"

Indicates the number of bearing replacements that have been done during the lifetime of the motor.

Bearings replaced (Motor bearing maintenance)

When the bearing monitoring function is active, the controller gives a warning when the motor bearings are to be replaced.

When you have replaced the motor bearings, confirm this action by pressing [Bearings replaced].

13.23 "Number" (Pump number)

Pump variant	"Number"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can allocate a unique number to the pump. This makes it possible to distinguish between pumps in connection with bus communication.

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.24 "Radio communication" (Enable/disable radio comm.)

Pump variant	"Radio communication"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can set the radio communication to either enabled or disabled. You can use this function in areas where radio communication is not allowed. IR communication remains active.

Factory setting

See section Factory settings.

Related information

[30. Factory settings](#)

13.25 Language

Pump variant	Language
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel.

In this menu you can select the desired language. A number of languages is available.

13.26 "Date and time" (Set date and time)

Pump variant	"Date and time"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

You can set date and time as well as how they are to be shown in the display:

- **Select date format:** YYYY-MM-DD DD-MM-YYYY MM-DD-YYYY.
- **Select time format:** HH:MM 24-hour clock
HH:MM am/pm 12-hour clock.
- **Set date**
- **Set time.**

Factory setting

See section Factory settings.

Related information

30. Factory settings

13.27 "Unit configuration" (Units)

Pump variant	"Unit configuration"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

In this menu you can select between SI and US units. The setting can be made generally for all parameters or customised for each parameter.

Factory setting

See section Factory settings.

Related information

30. Factory settings

13.28 "Buttons on product" (Enable/disable settings)

Pump variant	"Buttons on product"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

In this display, you can disable the possibility of making settings.

Grundfos GO

If you set the buttons to "Not active", the buttons on the standard control panel are disabled. If you set the buttons to "Not active" on pumps with an advanced control panel, see below.

Advanced control panel

If you have disabled the settings, you can still use the buttons to navigate through the menus but you cannot make changes in the **Settings** menu.

When you have disabled the possibility to make settings, the **ⓘ** symbol appears in the display.

The **ⓘ** button always remains active but you can only unlock all other buttons on the pump with Grundfos GO.

Factory setting

See section Factory settings.

Related information

30. Factory settings

13.29 Delete history

Pump variant	Delete history
TPE, TPED, NBE, NBGE, NKE, NKGE	-
TPE, TPED, NBE, NKE Series 2000	-

In this menu, you can delete the following historic data:

- "Delete operating log".
- "Delete heat energy data".
- "Delete energy consumption".

13.30 Define Home display

Pump variant	Define Home display
TPE, TPED	-
NBE, NBGE, NKE, NKGE & TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel.

In this menu, you can set the **Home** display to show up to four user-set parameters.

13.31 Display settings

Pump variant	Display settings
TPE, TPED	-
NBE, NBGE, NKE, NKGE & TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel.

In this menu you can adjust the display brightness and set whether or not the display is to turn off if no buttons have been activated for a period of time.

13.32 "Store settings" (Store actual settings)

Pump variant	"Store settings"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Grundfos GO

In this menu, you can store the actual settings for later use in the same pump or in other pumps of the same type.

Advanced control panel

In this menu, you can store the actual settings for later use in the same pump.

13.33 "Recall settings" (Recall stored settings)

Pump variant	"Recall settings"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

Grundfos GO

In this menu, you can recall stored settings from a number of previously stored settings that the pump then uses.

Advanced control panel

In this menu, you can recall the last stored settings that the pump then uses.

13.34 "Undo"

Pump variant	"Undo"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in Grundfos GO.

In this display, you can undo all settings that have been made with Grundfos GO in the current communication session. You cannot undo a **Recall stored settings** action.

13.35 "Pump name"

Pump variant	"Pump name"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in Grundfos GO.

In this display, you can give the pump a name. In this way, you can easily identify the pump when connecting with Grundfos GO.

Factory setting

See section Factory setting.

Related information

[30. Factory settings](#)

13.36 "Connection code"

Pump variant	"Connection code"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in Grundfos GO.

You can set a connection code to avoid having to press the connection button each time and to restrict remote access to the product.

Setting the code in the product using Grundfos GO

1. Connect Grundfos GO to the product.
2. In the product dashboard, select "Settings".
3. Choose "Connection code".
4. Enter the wanted code and press [OK]. The code must be a character string, ASCII. You can always modify the code. The old code is not needed.

Setting the code in Grundfos GO

You can set a default connection code in Grundfos GO so that it automatically attempts to connect to the selected product via this code.

When you select a product with the same connection code in Grundfos GO, Grundfos GO automatically connects to the product and you do not have to press the connection button on the module.

Set the default code in Grundfos GO in this way:

1. In the main menu, under "General", select "Settings".
2. Choose "Remote".
3. Enter the connection code in the field "Preset connection code". The field now says "Connection code set".

You can always modify the default connection code by pressing [Delete] and entering a new one.

If Grundfos GO fails to connect and ask you to press the connection button on the product, it means that the product has no connection code or has a different connection code. In this case, you can only establish connection via the connection button.

After setting a connection code, you must switch off the product until the light in Grundfos Eye turns off before you can use the new connection code.

Factory setting

See section Factory settings.

Related information

30. Factory settings

13.37 Run start-up guide

Pump variant	Run start-up guide
TPE, TPED	•
NBE, NBGE, NKE, NKGE & TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel.

The startup guide automatically starts when you start the pump for the first time.

You can always run the startup guide later via this menu.

The startup guide guides you through the general settings of the pump.

- **Language.** See section "Language".
- **Select date format.** See section "Date and time" (Set date and time).
- **Set date.** See section "Date and time" (Set date and time).
- **Select time format.** See section "Date and time" (Set date and time).
- **Set time.** See section "Date and time" (Set date and time).
- **Setting of pump**
 - **Go to Home**
 - **Run with Constant curve/Run with Constant pressure.** See section "Control mode"
 - **Go to "Assisted pump setup".** See section "Assisted pump setup".
 - **Return to factory settings.**

*Applies only for pumps with advanced functional module, FM 300. For further information, see section Identification of functional module.

Related information

13.5 "Control mode"

13.25 Language

13.26 "Date and time" (Set date and time)

13.41 Assisted pump setup

20. Identification of the functional module

13.38 Alarm log

Pump variant	Alarm log
TPE, TPED, NBE, NBGE, NKE, NKGE	•

Pump variant	Alarm log
TPE, TPED, NBE, NKE Series 2000	•

This menu contains a list of logged alarms from the product. The log shows the name of the alarm, when the alarm occurred and when it was reset.

13.39 Warning log

Pump variant	Warning log
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu contains a list of logged warnings from the product. The log shows the name of the warning, when the warning occurred and when it was reset.

13.40 Assist

Pump variant	Assist
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The menu consist of functions which take you through the steps needed to set the pump.

13.41 Assisted pump setup

Pump variant	Assisted pump setup
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The menu guides you through the following:



Setting of pump

- Selection of control mode. See section "Control mode".
- Configuration of feedback sensors.
- Adjusting the setpoint. See section Setpoint.
- Controller settings. See section "Controller" ("Controller settings").
- Summary of settings.

Example of how to use the Assisted pump setup for setting up the pump to constant pressure:

Grundfos GO

1. Open the **Assist** menu.
2. Select **Assisted pump setup**.
3. Select the control mode "Constant pressure".
4. Read the description of this control mode.
5. Select which analog input to use as sensor input.
6. Select sensor function according to where the sensor is installed in the system.



TM/062328

Overview of sensor locations

7. Select electrical input signal according to the sensor specifications.
8. Select measuring unit according to the sensor specifications.
9. Set the minimum and maximum sensor values according to the sensor specifications.
10. Set the desired setpoint.
11. Set the controller settings K_p and T_i . See the recommendations in section "Controller" ("Controller settings").
12. Type the pump name.
13. Check the summary of settings and confirm them.

Advanced control panel

1. Open the **Assist** menu.
2. Select **Assisted pump setup**.
3. Select the control mode **Const. pressure**.
4. Select which analog input to be used as sensor input.
5. Select the measured parameter to be controlled.
6. Select measuring unit according to the sensor specifications.
7. Set the minimum and maximum sensor values according to the sensor specifications.
8. Select electrical input signal according to the sensor specifications.
9. Set the setpoint.

10. Set the controller settings K_p and T_i . See recommendations in section "Controller" ("Controller settings").
11. Check the summary of settings and confirm them by pressing [OK].

Related information

- [13.1 Setpoint](#)
- [13.5 "Control mode"](#)
- [13.7 Analog inputs](#)
- [13.14 "Controller" \("Controller settings"\)](#)

13.42 Setup, analog input

Pump variant	Setup, analog input
TPE, TPED	-
NBE, NBGE, NKE, NKGE & TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel.

The menu guides you through the following:

Setup, analog input

- Analog inputs 1 to 3. See page Analog inputs.
- Pt100/1000 input 1 and 2. See page Pt100/1000 inputs.
- Adjusting the setpoint. See section Setpoint.
- Summary.

Related information

- [13.1 Setpoint](#)
- [13.7 Analog inputs](#)
- [13.9 Pt100/1000 inputs](#)

13.43 "Multipump setup" (Setup of multi-pump system)

Pump variant	"Multipump setup"
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

The multipump function enables the control of two pumps connected in parallel without the use of external controllers. The pumps in a multipump system communicate with each other via the wireless GENIair connection or the wired GENI connection. A multipump system is set via a selected pump, i.e. the master pump, which is the first selected pump.

If two pumps in the system are configured with an outlet-pressure sensor, both pumps can function as master pumps and take over the master pump function if the other fails. This provides additional redundancy in the multipump system.

The multipump functions are described in the following sections.

13.43.1 Alternating operation

Alternating operation functions as a duty/standby operating mode and is possible with two pumps of same size and type connected in parallel. The main purpose of the function is to ensure an even amount of running hours and to ensure that the standby pump takes over if the running pump stops due to an alarm.

Each pump requires a non-return valve in series with the pump.

You can choose between two alternating operation modes:

- "Alternating operation, time"
Pump changeover to the other is based on time.
- "Alternating operation, energy"
Pump changeover to the other is based on energy consumption.

If the duty pump fails, the other pump takes over automatically.

13.43.2 Backup operation

Backup operation is possible with two pumps of same size and type connected in parallel. Each pump requires a non-return valve in series with the pump.

One pump is operating continuously. The backup pump is operated for a short time each day to prevent seizing up. If the duty pump stops due to a fault, the backup pump starts automatically.

13.43.3 Cascade operation

Cascade operation ensures that the pump performance is automatically adapted to the consumption by switching pumps on or off. The system thus runs as energy-efficiently as possible with a constant pressure and a limited number of pumps.

All pumps in operation run at equal speed. Pump changeover is automatic and depends on energy, operating hours and fault.

If the pump system consists of two to four single-head pumps connected in parallel, the pumps must be of the same type and size. Each pump requires a non-return valve in series with the pump.

Set the control mode to "Constant pressure" or "Constant curve".

This function is available with up to 4 motors installed in parallel. The motors must be of the same size and the pumps must be of the same model.

- The performance is adjusted to the demand through cutting pumps in or out and through parallel control of the pumps in operation.

- The controller maintains a constant pressure through continuous adjustment of the speed of the pumps.
- Pump changeover is automatic and depends on load, operating hours and fault detection.
- All pumps in operation run at the same speed.
- The number of pumps in operation also depends on the energy consumption of the pumps. If only one pump is required, two pumps will run at a lower speed if this results in a lower energy consumption.
- If several motors in the system have a sensor, they can all function as master and take over the master function if the other motors fail.

13.43.4 Setting a multipump system


You can set a multipump system in the following ways:

- Grundfos GO and wireless pump connection
- Grundfos GO and wired pump connection
- Advanced control panel and wireless pump connection
- Advanced control panel and wired pump connection

See step-by-step descriptions below.

Grundfos GO and wireless pump connection


1. Power on both pumps.
2. Establish contact to one of the pumps with Grundfos GO.
3. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section "Assisted pump setup".
4. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
5. Disconnect Grundfos GO from the pump.
6. Establish contact to the other pump.
7. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section "Assisted pump setup".
8. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
9. Select the "Assist" menu and "Multipump setup".
10. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
11. Press [→] to continue.

12. Set the time for pump changeover such as the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
13. Press [>] to continue.
14. Select "Radio" as the communication method to be used between the two pumps.
15. Press [>] to continue.
16. Press "Select pump 2".
17. Select the pump from the list. Use the [OK] or  button to identify the pump.
18. Press [>] to continue.
19. Confirm the multipump setup by pressing [Send].
20. Press [Finish] in the "Setup complete" dialog box.
21. Wait for the green indicator light in the middle of Grundfos Eye to light up.

The multipump system has now been set.

Grundfos GO and wired pump connection

1. Connect the two pumps with each other with a 3-core screened cable between the GENIbus terminals A, Y, B.
2. Power on both pumps.
3. Establish contact to one of the pumps with Grundfos GO.
4. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section "Assisted pump setup".
5. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
6. Assign pump number 1 to the pump. See section "Number" (Pump number).
7. Disconnect Grundfos GO from the pump.
8. Establish contact to the other pump.
9. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section "Assisted pump setup".
10. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
11. Assign pump number 2 to the pump. See section "Number" (Pump number).
12. Select the "Assist" menu and choose "Multipump setup".
13. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
14. Press [>] to continue.

15. Set the time for pump changeover such as the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
16. Press [>] to continue.
17. Select "BUS cable" as the communication method to be used between the two pumps.
18. Press [>] to continue.
19. Press "Select pump 2".
20. Select the additional pump from the list. Use the [OK] or  button to identify the additional pump.
21. Press [>] to continue.
22. Press [Send].
23. Press [Finish] in the "Setup complete" dialog box.
24. Wait for the green indicator light in the middle of Grundfos Eye to light up.

The multipump system has now been set.

Advanced control panel and wireless pump connection

1. Power on both pumps.
2. On both pumps, set the needed analog and digital inputs according to the connected equipment and the required functionality. See section "Assisted pump setup".
3. Select the **Assist** menu on one of the pumps and choose **Setup of multi-pump system**.
4. Press [>] to continue.
5. Select **Wireless** as the communication method to be used between the two pumps.
6. Press [>] to continue.
7. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
8. Press [>] three times to continue.
9. Press [OK] to search for other pumps. The green indicator light in the middle of Grundfos Eye flashes on the other pumps.
10. Press the connect button on the pump which is to be added to the multipump system.
11. Press [>] to continue.
12. Set the time for pump changeover i.e. the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
13. Press [>] to continue.
14. Press [OK]. The multipump function icons appear in the bottom of the control panels.

The multipump system has now been set.

Advanced control panel and wired pump connection

1. Connect the two pumps with each other with a 3-core screened cable between the GENIbus terminals A, Y, B.

2. Set the needed analog and digital inputs according to the connected equipment and the required functionality. See section "Assisted pump setup".
3. Assign pump number 1 to the first pump. See section "Number" (Pump number).
4. Assign pump number 2 to the other pump. See section "Number" (Pump number).
5. Select the **Assist** menu on one of the pumps and choose **Setup of multi-pump system**.
6. Press [>] to continue.
7. Select **Wired GENibus** as the communication method to be used between the two pumps.
8. Press [>] twice to continue.
9. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
10. Press [>] to continue.
11. Press [OK] to search for other pumps.
12. Select the additional pump from the list.
13. Press [>] to continue.
14. Set the time for pump changeover i.e. the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
15. Press [>] to continue.
16. Press [OK]. The multipump function icons appear in the bottom of the control panels.

The multipump system has now been set.

Disabling the multipump function via Grundfos GO

1. Select the "Assist" menu.
2. Select "Multipump setup".
3. Select "Disable".
4. Press [>] to continue.
5. Confirm the multipump setup by pressing [Send].
6. Press [Finish].

The multipump function has now been disabled.

Disabling a multipump via advanced control panel

1. Select the **Assist** menu.
2. Select **Setup of multi-pump system**.
3. Press [>] to continue.
4. Confirm **No multi-pump function** by pressing [OK].
5. Press [>] to continue.
6. Press [OK].

The multipump system has now been disabled.

Related information

[13.23 "Number" \(Pump number\)](#)

[13.35 "Pump name"](#)

[13.41 Assisted pump setup](#)

[13.43.1 Alternating operation](#)

[13.43.2 Backup operation](#)

[13.43.3 Cascade operation](#)

13.44 Description of control mode

Pump variant	Description of control mode
TPE, TPED, NBE, NBGE, NKE, NKGE	-
TPE, TPED, NBE, NKE Series 2000	•

This menu is only available in the advanced control panel.

This menu describes each of the possible control modes. See also section "Control mode".

Related information





[13.5 "Control mode"](#)



13.45 Assisted fault advice

Pump variant	Assisted fault advice
TPE, TPED, NBE, NBGE, NKE, NKGE	•
TPE, TPED, NBE, NKE Series 2000	•

This menu gives guidance and corrective actions in case of pump failures.

14. Selection of control mode

System application	Select this control mode
<p>In systems with relatively large pressure losses in the distribution pipes and in air-conditioning and cooling systems.</p> <ul style="list-style-type: none"> Two-pipe heating systems with thermostatic valves and the following: <ul style="list-style-type: none"> very long distribution pipes strongly throttled balancing valves differential-pressure regulators large pressure losses in those parts of the system through which the total quantity of water flows, for example boiler, heat exchanger and distribution pipe up to the first branching. Primary circuit pumps in systems with large pressure losses in the primary circuit. Air-conditioning systems with the following: <ul style="list-style-type: none"> heat exchangers, fan coils cooling ceilings cooling surfaces. 	<p>Proportional pressure</p>  <p>TM057904</p>
<p>In systems with relatively small pressure losses in the distribution pipes.</p> <ul style="list-style-type: none"> Two-pipe heating systems with thermostatic valves and the following: <ul style="list-style-type: none"> sized for natural circulation small pressure losses in those parts of the system through which the total quantity of water flows, for example boiler, heat exchanger and distribution pipe up to the first branching, or modified to a high differential temperature between flow pipe and return pipe, for example district heating. Underfloor heating systems with thermostatic valves. One-pipe heating systems with thermostatic valves or pipe balancing valves. Primary circuit pumps in systems with small pressure losses in the primary circuit. 	<p>Constant differential pressure</p>  <p>TM057905</p>
<p>In systems with a fixed system characteristic.</p> <p>Examples:</p> <ul style="list-style-type: none"> one-pipe heating systems boiler shunts systems with three-way valves domestic hot-water circulation. 	<p>Constant temperature and constant differential temperature</p>  <p>TM057906</p>
<p>If an external controller is installed, the pump is able to change from one constant curve to another, depending on the value of the external signal. You can also set the pump to operate according to the maximum or minimum curve, like an uncontrolled pump:</p> <ul style="list-style-type: none"> Use the maximum-curve mode in periods in which a maximum flow is required. This operating mode is for instance suitable for systems with hot-water priority. Use the minimum-curve mode in periods in which a minimum flow is required. 	<p>Constant curve</p>  <p>TM057907</p>

System application	Select this control mode
<p>In systems requiring a constant flow, independently of pressure drop.</p> <p>Examples:</p> <ul style="list-style-type: none"> • chillers for air-conditioning • heating surfaces • cooling surfaces. 	<p>Constant flow rate</p>  <p>TM057956</p>
<p>In systems requiring a constant tank level, independently of the flow rate.</p> <p>Examples:</p> <ul style="list-style-type: none"> • process-water tanks • boiler-condensate tanks. 	<p>Constant level</p>  <p>TM057906</p>
<p>In systems with pumps operating in parallel.</p> <p>The multipump function enables the control of two to four single-head pumps connected in parallel and twin-head pumps without the use of external controllers. The pumps in a multipump system communicate with each other via the wireless GENlair connection or the wired GENI connection.</p>	<p>Assist menu Setup of multi-pump system</p>

15. Bus signal

The pump supports serial communication via an RS-485 input. The communication is carried out according to the Grundfos GENlbus protocol and enables connection to other pumps as well as a building management system or another external control system.

Via a bus signal, you can remote-set pump operating parameters, such as setpoint and operating mode. At the same time, the pump can, via the bus, provide status information about important parameters, such as actual value of control parameter, input power and fault indications.

Contact Grundfos for further information.



If you use a bus signal, the number of settings available via Grundfos GO are reduced.

16. Priority of settings

You can always set the pump to stop by pressing ☹ on the pump control panel. When the pump is not in **Stop** mode, you can always set the pump to stop by continuously pressing ☹. Furthermore, you can set the pump to maximum speed by continuously pressing ☺. You can always set the pump to operation at maximum speed or to stop with Grundfos GO.

If two or more functions are enabled at the same time, the pump operates according to the function with the highest priority.

Example

If you have set the pump to maximum speed via the digital input, the pump control panel or Grundfos GO can only set the pump to **Manual** or **Stop**.


The priority of the settings appears from the table below.

Priority	Start-stop button	Grundfos GO or control panel on pump	Digital input	Bus communication
1	Stop			
2		Stop*		
3		Manual		
4		"Max. speed"*/ "User-defined speed"		
5			Stop	
6			"User-defined speed"	
7				Stop
8				"Max. speed"
9				"Min. speed"
10				"Start"
11			"Max. speed"	
12		"Min. speed"		
13			"Min. speed"	
14			"Start"	
15		"Start"		

*"Stop" and "Max. speed" settings made with Grundfos GO or on the motor control panel can be overruled by another operating-mode command sent from a bus, for example "Start". If the bus communication is interrupted, the motor resumes its previous operating mode, for example "Stop", selected with Grundfos GO or on the motor control panel.

17. Grundfos Eye










The operating condition of the pump is indicated by the Grundfos Eye on the control panel.



TM055993

Grundfos Eye

Grundfos Eye	Indication	Description
	No lights are on.	The power is off. The pump is not running.
	The two opposite green indicator lights are rotating in the direction of rotation of the pump when seen from the non-drive end.	The power is on. The pump is running.
	The two opposite green indicator lights are permanently on.	The power is on. The pump is not running.
	One yellow indicator light is rotating in the direction of rotation of the pump when seen from the non-drive end.	Warning. The pump is running.
	One yellow indicator light is permanently on.	Warning. The pump has stopped.
	The two opposite red indicator lights flash simultaneously.	Alarm. The pump has stopped.











































Grundfos Eye	Indication	Description
	<p>The green indicator light in the middle flashes quickly four times.</p> 	<p>This is a feedback signal which the pump gives in order to ensure identification of itself.</p>
	<p>The green indicator light in the middle flashes continuously.</p> 	<p>Grundfos GO or another pump is trying to communicate with the pump. Press  on the pump control panel to allow communication.</p>
	<p>The green indicator light in the middle is permanently on.</p> 	<p>Remote control with Grundfos GO via radio. The pump is communicating with Grundfos GO via radio connection.</p>
	<p>The green indicator light in the middle flashes quickly while Grundfos Go is exchanging data with the pump. It takes a few seconds.</p> 	<p>Remote control with Grundfos GO via infrared light. The pump is receiving data from Grundfos GO via infrared communication.</p>






















18. Signal relays

The pump has two outputs for potential-free signals via two internal relays.

You can set the signal outputs to **Operation**, **Pump running**, **Ready**, **Alarm** and **Warning**.

The functions of the two signal relays appear from the table below.

Description	Grundfos Eye	Contact position of signal relays when activated					Operating mode
		Operation	Running	Ready	Alarm	Warning	
The power is off.		TM054835 	TM043100 	TM043100 	TM043100 	TM043100 	-
Off							
The pump runs in "Normal" mode.		TM054839 	TM043099 	TM043099 	TM043099 	TM043100 	"Normal", "Min." or "Max."
Green, rotating							
The pump runs in "Manual" mode.		TM054839 	TM043099 	TM043099 	TM043100 	TM043100 	"Manual"
Green, rotating							
The pump is in operating mode "Stop".		TM054840 	TM043100 	TM043100 	TM043099 	TM043100 	"Stop"
Green, steady							
Warning, but the pump is running.		TM054842 	TM043099 	TM043099 	TM043099 	TM043100 	"Normal", "Min." or "Max."
Yellow, rotating							
Warning, but the pump runs in "Manual" mode.		TM054842 	TM043099 	TM043099 	TM043100 	TM043100 	"Manual"
Yellow, rotating							
Warning, but the pump was stopped via a "Stop" command.		TM054841 	TM043100 	TM043100 	TM043099 	TM043100 	"Stop"
Yellow, steady							

Description	Grundfos Eye	Contact position of signal relays when activated					Operating mode	
		Operation	Running	Ready	Alarm	Warning		
Alarm, but the pump is running.		TM054839 	TM043099 	TM043099 	TM043100 	TM043099 	TM043100 	"Normal", "Min." or "Max."
Alarm, but the pump runs in "Manual" mode.		TM054839 	TM043099 	TM043099 	TM043100 	TM043099 	TM043100 	"Manual"
The pump has stopped due to an alarm.		TM054838 	TM043100 	TM043100 	TM043100 	TM043099 	TM043100 	"Stop"

19. Installing a communication interface module

DANGER

Electric shock


Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.

Always use an antistatic service kit when handling electronic components. This prevents static electricity from damaging the components.


When unprotected, place the component on the antistatic cloth.



TM064462

Antistatic service kit


1. Loosen the four screws (A) and remove the terminal box cover (B).



TM064081

Removing the terminal box cover


2. Remove the CIM cover (A) by pressing the locking tab (B) and lifting the end of the cover (C). Then lift the cover off the hooks (D).



TM064084

Removing the CIM cover


3. Remove the securing screw (A).



TM064082

Removing the securing screw

4. Fit the CIM module by aligning it with the three plastic holders (A) and the connecting plug (B). Press home the module using your fingers.




TM064083

Fitting the CIM module

5. Fit and tighten the securing screw (A) to 1.3 Nm.
6. Make the electrical connections to the CIM module as described in the instructions delivered with the module.


7. Connect the cable screens of the bus cables to earth via one of the earth clamps (A).



TM064195

Connecting the cable screens to earth

8. Route the wires for the CIM module. See the example below.




TM064085

Example of wire routing

9. Fit the CIM cover.

10. If the CIM module is supplied with an FCC label, then place this on the terminal box.



TM057028

FCC label

11. Fit the terminal box cover (B) and cross-tighten the four mounting screws (A) to 6 Nm.



Make sure that the terminal box cover is aligned with the control panel. See section Changing the position of the control panel.

Related information

[22. Changing the position of the control panel](#)

22. Changing the position of the control panel

DANGER

Electric shock


Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.


You can turn the control panel 180°. Follow the instructions below.

1. Loosen the four screws, TX25, of the terminal box cover.




Loosening the screws

2. Remove the terminal box cover.



Removing the terminal box cover

3. Press and hold in the two locking tabs, A, while gently lifting the plastic cover, B.




Lifting the plastic cover

4. Turn the plastic cover 180°.




Do not twist the cable more than 90°.



Turning the plastic cover

5. Position the plastic cover correctly on the four rubber pins, C. Make sure that the locking tabs, A are placed correctly.



Positioning the plastic cover

6. Fit the terminal box cover, and make sure that it is also turned 180° so that the buttons on the control panel are aligned with the buttons on the plastic cover.
7. Tighten the four screws, TX25, with 5 Nm.


TM055353

TM055354

TM055351

TM055352

TM055355



Fitting the terminal box cover

23. Servicing the product

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be switched on accidentally.

DANGER

Magnetic field

Death or serious personal injury



- Do not handle the motor or rotor if you have a pacemaker.

23.1 Motor

If service is needed on the product, contact Grundfos Service.

23.2 Pump

Service documentation is available in Grundfos Product Center (<http://product-selection.grundfos.com/>).

If you have any questions, contact the nearest Grundfos company or service workshop.

24. Cleaning the product

WARNING

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and the signal relays. Confirm that the terminal box cover is intact before spraying water on the product.

To avoid condensation in the motor, let the motor cool down before spraying it with cold water.

25. Megging



Megging of an installation incorporating MGE motors is not allowed, as the built-in electronics may be damaged.

26. Technical data, single-phase motors

26.1 Supply voltage

- 1 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

Recommended fuse size

Motor size [kW]	Min. [A]	Max. [A]
0.12 - 0.75	6	10
1.1 - 1.5	10	16

You can use standard as well as quick-blow or slow-blow fuses.

26.2 Leakage current

Earth leakage current must be less than 3.5 mA, AC.

Earth leakage current must be less than 10 mA, DC.

The leakage currents are measured in accordance with EN 61800-5-1:2007.

TM055356

27. Technical data, three-phase motors

27.1 Supply voltage

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

Recommended fuse size

- 3 x 380-500 V - 10 %/+ 10 %, 50/60 Hz, PE.

Motor size [kW]	Minimum [A]	Maximum [A]
0.25 - 1.1	6	6
1.5	6	10
2.2	6	16
3	10	16
4	13	16
5.5	16	32
7.5	20	32
11	32	32

- 3 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Motor size [kW]	Minimum [A]	Maximum [A]
1.1	10	20
1.5	10	20
2.2	13	35
3	16	35
4	25	35
5.5	32	35

You can use standard as well as quick-blow or slow-blow fuses.

27.2 Leakage current, AC

Speed [min ⁻¹]	Power [kW]	Mains voltage [V]	Leakage current [mA]
1400-2000 1450-2200	0.25 - 1.5	≤ 400	< 3.5
		> 400	< 5
	2.2 - 4	≤ 400	< 3.5
		> 400	< 3.5
2900-4000	5.5 - 7.5	≤ 400	< 3.5
		> 400	< 5
	0.25 - 2.2	≤ 400	< 3.5
		> 400	< 5
	3 - 5.5	≤ 400	< 3.5
		> 400	< 3.5
	7.5 - 11	≤ 400	< 3.5
		> 400	< 5
4000-5900	0.25 - 2.2	≤ 400	< 3.5
		> 400	< 5
	3 - 5.5	≤ 400	< 3.5
		> 400	< 3.5
	7.5 - 11	≤ 400	< 3.5
		> 400	< 5

The leakage currents are measured without any load on the shaft and in accordance with EN 61800-5-1:2007.

28. Inputs and outputs

Ground reference, GND

All voltages refer to GND.
All currents return to GND.

Absolute maximum voltage and current limits

Exceeding the following electrical limits may result in severely reduced operating reliability and motor life:

Relay 1:

Maximum contact load: 250 VAC, 2 A or 30 VDC, 2 A.

Relay 2:

Maximum contact load: 30 VDC, 2 A.

GENI terminals: -5.5 to 9.0 VDC or less than 25 mADC.

Other input and output terminals: -0.5 to 26 VDC or less than 15 mADC.

Digital inputs, DI

Internal pull-up current greater than 10 mA at V_i equal to 0 VDC.

Internal pull-up to 5 VDC; currentless for V_i greater than 5 VDC).

Low logic level: V_i less than 1.5 VDC.

High logic level: V_i greater than 3.0 VDC.

Hysteresis: No.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Open-collector digital outputs, OC

Current sinking capability: 75 mADC, no current sourcing.

Load types: Resistive or/and inductive.

Low-state output voltage at 75 mADC: Maximum 1.2 VDC.

Low-state output voltage at 10 mADC: Maximum 0.6 VDC.

Overcurrent protection: Yes.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Analog inputs, AI

Voltage signal ranges:

- 0.5 - 3.5 VDC, AL AU.
- 0-5 VDC, AU.
- 0-10 VDC, AU.

Voltage signal: R_i greater than 100 k Ω at 25 °C.

Leak currents may occur at high operating temperatures. Keep the source impedance low.

Current signal ranges:

- 0-20 mADC, AU.
- 4-20 mADC, AL AU.

Current signal: R_i equal to 292 Ω .

Current overload protection: Yes. Change to voltage signal.

Measurement tolerance: - 0/+ 3 % of full scale (maximum-point coverage).

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m, excl. potentiometer.

Potentiometer connected to +5 V, GND, any AI:

Use maximum 10 k Ω .

Maximum cable length: 100 m.

Analog output, AO

Current sourcing capability only.

Voltage signal:

- Range: 0-10 VDC.
- Minimum load between AO and GND: 1 k Ω .
- Short-circuit protection: Yes.

Current signal:

- Ranges: 0-20 and 4-20 mADC.
- Maximum load between AO and GND: 500 Ω .
- Open-circuit protection: Yes.

Tolerance: - 0/+ 4 % of full scale (maximum-point coverage).

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Pt100/1000 inputs, PT

Temperature range:

- Minimum -30 °C. 88 Ω /882 Ω .
- Maximum 180 °C. 168 Ω /1685 Ω .

Measurement tolerance: \pm 1.5 °C.

Measurement resolution: < 0.3 °C.

Automatic range detection, Pt100 or Pt1000: Yes.

Sensor fault alarm: Yes.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Use Pt100 for short wires.

Use Pt1000 for long wires.

LiqTec sensor inputs*

Use Grundfos LiqTec sensor only.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Grundfos Digital Sensor input and output, GDS*

Use Grundfos Digital Sensor only.

*Not applicable for TPE, TPED, NBE, NBGE, NKE and NKGE pumps. The factory-fitted differential-pressure sensor for TPE, TPED, NBE, NKE Series 2000 is connected to this input.

Power supplies

+5 V:

- Output voltage: 5 VDC - 5 %/+ 5 %.
- Maximum current: 50 mADC, sourcing only.
- Overload protection: Yes.

+24 V:

- Output voltage: 24 VDC - 5 %/+ 5 %.
- Maximum current: 60 mADC, sourcing only.
- Overload protection: Yes.

Digital outputs, relays

Potential-free changeover contacts.

Minimum contact load when in use: 5 VDC, 10 mA.

Screened cable: 0.5 - 2.5 mm², 28-12 AWG.

Maximum cable length: 500 m.

Bus input

Grundfos GENIbus protocol, RS-485.

Screened 3-core cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

29. Other technical data**EMC (electromagnetic compatibility)**

Standard used: EN 61800-3.

The table below shows the emission category of the motor.

C1 fulfils the requirements for residential areas.

Note: When connected to a public network, 11 kW motors do not comply with the partial weighted harmonic distortion (PWHD) requirements of EN 61000-3-12. If required by the distribution network operator, compliance can be obtained in the following way:

The impedance of the mains cables between the motor and the point of common coupling (PCC) must be equivalent to the impedance of a 50 m cable with a cross-section of 0.5 mm.

C3 fulfils the requirements for industrial areas.

Note: When the motors are installed in residential areas, supplementary measures may be required as the motors may cause radio interference.

Motor [kW]	Emission category	
	1450-2000 min ⁻¹	2900-4000 min ⁻¹ 4000-5900 min ⁻¹
0.25	C1	C1
0.37	C1	C1
0.55	C1	C1
0.75	C1	C1
1.1	C1	C1
1.5	C1	C1
2.2	C1	C1
3	C1	C1
4	C1	C1
5.5	C3/C1*	C1
7.5	C3/C1*	C3/C1*
11	-	C3/C1*

*C1, if equipped with an external Grundfos EMC filter.

Immunity: The motor fulfils the requirements for industrial areas.

Contact Grundfos for further information.**Enclosure class**

Standard: IP55 (IEC 34-5).

Optional: IP66 (IEC 34-5).

Insulation class

F (IEC 85).

Standby power consumption

5-10 W.

Cable entries

Motor [kW]	Number and size of cable entries		
	1400-2000 1450-2200 [min ⁻¹]	2900-4000 [min ⁻¹]	4000-5900 [min ⁻¹]
0.25 - 1.5	4xM20	4xM20	4xM20
2.2	1xM25 + 4xM20	4xM20	4xM20
3.0 - 4.0	1xM25 + 4xM20	1xM25 + 4xM20	1xM25 + 4xM20
5.5	1xM32 + 5xM20	1xM25 + 4xM20	1xM25 + 4xM20
7.5 - 11	1xM32 + 5xM20	1xM32 + 5xM20	1xM32 + 5xM20

29.1 Torques

Terminal	Thread size	Maximum torque [Nm]
L1, L2, L3, L, N	M4	2.35
NC, C1, C2, NO	M2.5	0.5
1 to 26 and A, Y, B	M2	0.5

29.2 Sound pressure level

Motor [kW]	Maximum speed stated on nameplate rpm	Speed rpm	Sound pressure level ISO 3743 [dB(A)]	
			1-phase motors	3-phase motors
0.25 - 0.75	2000	1500	37	37
		2000	43	43
	4000	3000	50	50
		4000	60	60
	5900	4000	58	58
		5900	68	68
1.1	2000	1500	-	37
		2000	-	43
	4000	3000	50	50
		4000	60	60
	5900	4000	58	58
		5900	68	68
1.5	2000	1500	-	42
		2000	-	47
	4000	3000	57	57
		4000	64	64
	5900	4000	58	58
		5900	68	68
2.2	2000	1500	-	48
		2000	-	55
	4000	3000	-	57
		4000	-	64
	5900	4000	-	58
		5900	-	68
3	2000	1500	-	48
		2000	-	55
	4000	3000	-	60
		4000	-	69
	5900	4000	-	64
		5900	-	74

Motor [kW]	Maximum speed stated on nameplate rpm	Speed rpm	Sound pressure level ISO 3743 [dB(A)]	
			1-phase motors	3-phase motors
4	2000	1500	-	48
		2000	-	55
	4000	3000	-	61
		4000	-	69
	5900	4000	-	64
		5900	-	74
5.5	2000	1500	-	58
		2000	-	61
	4000	3000	-	61
		4000	-	69
	5900	4000	-	64
		5900	-	74
7.5	2000	1500	-	58
		2000	-	61
	4000	3000	-	66
		4000	-	73
	5900	4000	-	69
		5900	-	79
11	4000	3000	-	66
		4000	-	73
	5900	4000	-	69
		5900	-	79

Fields marked with a dash (-) indicate that the motor is not available in this MGE motor range.

30. Factory settings

- Function is enabled.
- Function is disabled.
- Function is not available.

Settings	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Function description on page
Setpoint	67 %	58 %	<i>Setpoint</i>
Operating mode	Normal	Normal	<i>Operating mode</i>
Control mode	Const. curve	Prop. pressure	<i>"Control mode"</i>
Date and time	•	•	
"Buttons on product"	•	•	<i>"Buttons on product" (Enable/disable settings)</i>
"Controller" ("Controller settings")			<i>"Controller" ("Controller settings")</i>
"T _i "	0.5	0.5	
"K _p "	0.5	0.5	
Operating range			<i>Operating range</i>
"Min."	25 %	25 %	
"Max."	100 %	110 %	
"Ramps"	○	○	<i>"Ramps"</i>
"Ramp-up"	1 second	1 second	
"Ramp-down"	3 seconds	3 seconds	
"Number" (Pump number)	1	1	<i>"Number" (Pump number)</i>
"Radio communication"	•	•	<i>"Radio communication" (Enable/disable radio comm.)</i>
Analog input 1	○	○	<i>Analog inputs</i>
Analog input 2	○	○	
Analog input 3	○	○	
Built-in Grundfos sensor	-	•	<i>Built-in Grundfos sensor</i>
Pt100/1000 input 1	○	○	<i>Pt100/1000 inputs</i>
Pt100/1000 input 2	○	○	
"Digital input 1"	○	○	<i>Digital inputs</i>
"Digital input 2"	○	○	
"Digital in/output 3"	○	○	<i>Digital inputs/outputs</i>
"Digital in/output 4"	○	○	

Settings	TPE, TPED, NBE, NBGE, NKE, NKGE	TPE, TPED, NBE, NKE Series 2000	Function description on page
"Pulse flowmeter"	○	○	<i>"Pulse flowmeter setup"</i>
"Predefined setpoints"	○	○	<i>"Predefined setpoints"</i>
Analog output	○	○	<i>Analog output</i>
External setpoint function	○	○	<i>"Predefined setpoints"</i>
Relay output 1	○	○	<i>"Signal relays 1 and 2" (Relay outputs)</i>
Relay output 2	○	○	
Limit 1 exceeded	○	○	<i>Limit-exceeded function</i>
Limit 2 exceeded	○	○	
"Standstill heating"	○	○	<i>"Standstill heating"</i>
Motor bearing monitoring	○	○	<i>Motor bearing monitoring</i>
"Pump name"	Grundfos	Grundfos	<i>"Pump name"</i>
"Connection code"	-	-	<i>"Connection code"</i>
"Unit configuration"	SI	SI	<i>"Unit configuration" (Units)</i>

31. Disposing of the product

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Appendix A

A.1. Installation in the USA and Canada



In order to maintain the cURus approval, follow these additional installation instructions. The UL approval is according to UL 1004-1.

Outdoor installation

According to UL 778/C22.2 No 108-14, pumps intended for outdoor use must be marked enclosure type 3 and the product must be tested at a surface temperature down to -35 °C. The MLE enclosure is approved for type 3 or 4 and is rated at a surface temperature down to 0 °C, thus it is only for indoor use in UL 778/C22.2 No 108-14 pump applications.

For more information about ambient temperature during operation, see section Ambient temperature during operation.

Canadian Interference-Causing Equipment Standard

This product complies with the Canadian ICES-003 Class B specifications. This Class B device meets all the requirements of the Canadian interference-causing equipment regulations.

A.1.1. Electrical codes

For USA

This product complies with the Canadian Electrical Code and the US National Electrical Code.

This product has been tested according to the national standards for Electronically Protected Motors:

- CSA 22.2 100-14: 2014 (applies to Canada only).
- UL 1004-1: 2015 (applies to USA only).

Pour le Canada

Codes de l'électricité

Ce produit est conforme au Code canadien de l'électricité et au Code national de l'électricité américain.

Ce produit a été testé selon les normes nationales s'appliquant aux moteurs protégés électroniquement:

CSA 22.2 100.04: 2009 (s'applique au Canada uniquement).

UL 1004-1: Juin 2011 (s'applique aux États-Unis uniquement).

A.1.2. Radio communication

For USA

This device complies with part 15 of the FCC rules and RSS210 of IC rules.

Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

Users are cautioned that changes or modifications not expressly approved by Grundfos could void the user's authority to operate the equipment.

Pour le Canada

Communication radio

Ce dispositif est conforme à la partie 15 des règles de la FCC et aux normes RSS210 de l'IC.

Son fonctionnement est soumis aux deux conditions suivantes:

- Ce dispositif ne doit pas provoquer de brouillage préjudiciable.
- Il doit accepter tout brouillage reçu, y compris le brouillage pouvant entraîner un mauvais fonctionnement.

A.1.3. Identification numbers

For USA

Grundfos Holding A/S

Contains FCC ID: OG3-RADIOM01-2G4.

For Canada

Grundfos Holding A/S

Model: RADIOMODULE 2G4

Contains IC: 10447A-RA2G4M01.

Pour le Canada


Numéros d'identification

Grundfos Holding A/S


Modèle: RADIOMODULE 2G4

Contient IC: 10447A-RA2G4M01.

Location of identification numbers



Identification numbers (1)



Identification numbers (1)

A.1.4. Electrical connection

A.1.4.1. Conductors

See the section on cable cross-section.

A.1.4.2. Torques

Maximum tightening torques for the terminals can be found in the section on torques.

A.1.4.3. Line reactors

Maximum line reactor size must not exceed 1.5 mH. Maximum line reactor size in front of the drive must not exceed the following values:

P2 [kW]	Maximum line reactor [mH]	
	1450-2000 rpm 1450-2200 rpm	2900-4000 rpm 4000-5900 rpm
0.25 - 3	1.5	1.5
4	0.7	0.7
5.5	0.9	0.3
7.5	0.6	0.6
11	0.3	0.3

Exceeding these values will create resonance between the reactor and the drive, which will reduce the lifetime of the product.

Short circuit current

If a short circuit occurs, the pump can be used on a mains supply delivering not more than 5000 RMS symmetrical amperes, 600 V maximum.

Fuses

Fuses used for motor protection must be rated for minimum 500 V.

Motors up to and including 10 hp require class K5 UL-listed fuses. Any UL-listed fuse can be used for motors of 15 hp.

Branch circuit protection

When the pump is protected by a circuit breaker, this must be rated for a maximum voltage of 480 V. The circuit breaker must be of the "inverse time" type.

Overload protection

Degree of overload protection provided internally by the drive, in percent of full-load current: 102 %.

Appendix B

B.1. 中国 RoHS

产品中有害物质的名称及含有信息表

部件名称	有害物质									
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价 铬 (Cr6+)	多溴 联苯 (PBBs)	多溴二 苯醚 (PBDEs)	邻苯二甲 酸二正丁 酯 (DBP)	邻苯二甲 酸二 异丁酯 (DIBP)	邻苯二甲 酸丁基酯 (BBP)	邻苯二甲 酸二(2- 乙基)己 酯 (DEHP)
泵壳	X	O	O	O	O	O	O	O	O	O
印刷电路板	X	O	O	O	O	O	O	O	O	O
紧固件	X	O	O	O	O	O	O	O	O	O
管件	X	O	O	O	O	O	O	O	O	O
定子	X	O	O	O	O	O	O	O	O	O
转子	X	O	O	O	O	O	O	O	O	O

注 1: O: 表示该有害物质在该部件所有均质材料中的含量均不超出电器电子产品有害物质限制使用国家标准要求。
X: 表示该有害物质至少在该部件的某一均质材料中含量超出电器电子产品有害物质限制使用国家标准要求。
注 2: 以上未列出的部件, 表明其有害物质含量均不超出电器电子产品有害物质限制使用国家标准要求。



Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Industrias
1619 - Garin Pcia. de B.A.
Tel.: +54-3327 414 444
Fax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Tel.: +61-8-8461-6111
Fax: +61-8-8340-0155

Austria

GRUNDFOS Pumpen Vertrieb
Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Fax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomsesteenweg 81-83
B-2630 Aartselaar
Tel.: +32-3-870 7300
Fax: +32-3-870 7301

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A
BiH-71000 Sarajevo
Tel.: +387 33 592 480
Fax: +387 33 590 465
www.ba.grundfos.com
E-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo
Branco, 630
CEP 09850 - 300
São Bernardo do Campo - SP
Tel.: +55-11 4393 5533
Fax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztocna Tangenta street no. 100
BG - 1592 Sofia
Tel.: +359 2 49 22 200
Fax: +359 2 49 22 201
E-mail: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Tel.: +1-905 829 9533
Fax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106 PRC
Tel.: +86 21 612 252 22
Fax: +86 21 612 253 33

Colombia

GRUNDFOS Colombia S.A.S.
Km 1.5 vía Siberia-Cota Conj. Potrero
Chico,
Parque Empresarial Arcos de Cota Bod.
1A.
Cota, Cundinamarca
Tel.: +57(1)-2913444
Fax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Tel.: +385 1 6595 400
Fax: +385 1 6595 499
www.hr.grundfos.com

Czech Republic

GRUNDFOS Sales Czechia and Slovakia
s.r.o.
Čajkovského 21
779 00 Olomouc
Tel.: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tel.: +45-87 50 50 50
Fax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel.: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikuja 1
FI-01360 Vantaa
Tel.: +358-(0) 207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tel.: +33-4 74 82 15 15
Fax: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Fax: +49-(0) 211 929 69-3799
E-mail: infoservice@grundfos.de
Service in Deutschland:
kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Tel.: +0030-210-66 83 400
Fax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor, Siu Wai Industrial
Centre
29-33 Wing Hong Street & 68 King Lam
Street, Cheung Sha Wan
Kowloon
Tel.: +852-27861706 / 27861741
Fax: +852-27858664

Hungary

GRUNDFOS South East Europe Kft.
Tópark u. 8
H-2045 Törökbálint
Tel.: +36-23 511 110
Fax: +36-23 511 111

India

GRUNDFOS Pumps India Private
Limited
118 Old Mahabalipuram Road
Thoraiakkam
Chennai 600 097
Tel.: +91-44 2496 6800

Indonesia

PT GRUNDFOS Pompa
Graha intirub Lt. 2 & 3
Jln. Cililitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Tel.: +62 21-469-51900
Fax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Tel.: +353-1-4089 800
Fax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Fax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku
Hamamatsu
431-2103 Japan
Tel.: +81 53 428 4760
Fax: +81 53 428 5005

Kazakhstan

Grundfos Kazakhstan LLP
7' Kyz-Zhibek Str., Kok-Tobe micr.
KZ-050020 Almaty Kazakhstan
Tel.: +7 (727) 227-98-55/56

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Tel.: +82-2-5317 600
Fax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava ielā 60
LV-1035, Rīga,
Tel.: + 371 714 9640, 7 149 641
Fax: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel.: +370 52 395 430
Fax: +370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam UI/25
Glenmarie Industrial Park
40150 Shah Alam, Selangor
Tel.: +60-3-5569 2922
Fax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México
S.A. de C.V.
Boulevard TLC No. 15
Parque industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Tel.: +52-81-8144 4000
Fax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Fax: +31-88-478 6332
E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Tel.: +64-9-415 3240
Fax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tel.: +47-22 90 47 00
Fax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznań
PL-62-081 Przeźmierowo
Tel.: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 00
Fax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
S-PARK BUSINESS CENTER, Clădirea
A2, etaj 2
Str. Tipografilor, Nr. 11-15, Sector 1, Cod
013714
București, Romania
Tel.: 004 021 2004 100
E-mail: romania@grundfos.ro

Serbia

Grundfos Srbija d.o.o.
Ormladinskih brigada 90b
11070 Novi Beograd
Tel.: +381 11 2258 740
Fax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Tel.: +65-6681 9688
Fax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D 821 09 BRATISLAVA
Tel.: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
Leskoškova 9e, 1122 Ljubljana
Tel.: +386 (0) 1 568 06 10
Fax: +386 (0) 1 568 06 19
E-mail: tehnika-si@grundfos.com

South Africa

GRUNDFOS (PTY) LTD
16 Lascelles Drive, Meadowbrook Estate
1609 Germiston, Johannesburg
Tel.: (+27) 10 248 6000
Fax: (+27) 10 248 6002
E-mail: lgradidge@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Camino de la Fuentecilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Fax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunnagårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Fax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Fax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Tel.: +886-4-2305 0868
Fax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloe Phrakiat Rama 9 Road
Dokmai, Pravej, Bangkok 10250
Tel.: +66-2-725 8999
Fax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd.
Stl.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi
2. yol 200, Sokak No. 204
41490 Gebze/ Kocaeli
Tel.: +90 - 262-679 7979
Fax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

ТОВ "ГРУНДФОС УКРАЇНА"
Бізнес Центр Європа
Столичне шосе, 103
м. Київ, 03131, Україна
Tel.: (+38 044) 237 04 00
Fax: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone, Dubai
Tel.: +971 4 8815 166
Fax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Tel.: +44-1525-850000
Fax: +44-1525-850011

U.S.A.

Global Headquarters for WU
856 Koomey Road
Brookshire, Texas 77423 USA
Phone: +1-630-236-5500

Uzbekistan

Grundfos Tashkent, Uzbekistan
The Representative Office of Grundfos
Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Tel.: (+998) 71 150 3290 / 71 150 3291
Fax: (+998) 71 150 3292

98476024 05.2025

ECM: 1423163
