

JP

Installation and operating instructions



GRUNDFOS X

English (GB) Installation and operating instructions

Original installation and operating instructions.

CONTENTS

	Page
1. Symbols used in this document	2
2. General information	2
3. Applications	2
4. Identification	3
5. Installation	3
5.1 Handle	3
5.2 Ejector valve	3
6. Electrical connection	4
6.1 Checking the direction of rotation (three-phase motors)	4
7. Startup	5
7.1 Filling the pump with water	5
7.2 Shaft seal run-in	5
8. Maintenance	5
8.1 Cleaning the pump	5
8.2 Frost protection	6
9. Technical data	7
10. Fault finding	8
11. Disposal	9



Warning

Prior to installation, read these installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.



Warning

The use of this product requires experience with and knowledge of the product.

Persons with reduced physical, sensory or mental capabilities must not use this product, unless they are under supervision or have been instructed in the use of the product by a person responsible for their safety.

Children must not use or play with this product.

1. Symbols used in this document



Warning

If these safety instructions are not observed, it may result in personal injury.



Warning

If these instructions are not observed, it may lead to electric shock with consequent risk of serious personal injury or death.



Warning

When pumping hot liquids, make sure that persons cannot accidentally come into contact with hot surfaces.



If these safety instructions are not observed, it may result in malfunction or damage to the equipment.



Notes or instructions that make the job easier and ensure safe operation.

2. General information

These instructions apply to JP 5 and JP 6 pumps in material variants A and B.

3. Applications

The Grundfos jet pumps, type JP, are horizontal, self-priming centrifugal pumps designed for pumping water and other thin, non-aggressive and non-explosive liquids, not containing solid particles or fibres.

If the pump has been used for dirty liquids, e.g. pool water, flush it through with clean water immediately after use.



Warning


Do not use the pump for flammable liquids, such as diesel oil and petrol.



Warning

Do not use the pump for aggressive liquids, such as acids and seawater.

4. Identification



TM05 1797 3711

Fig. 1 Nameplate

Pos.	Description
1	Type
2	Model
3	Supply voltage
4	Maximum current
5	Frequency
6	Maximum pressure
7	Maximum head
8	Country of origin
9	Rated head
10	Enclosure class
11	Input power
12	Rated flow rate
13	Maximum ambient temperature
14	Maximum liquid temperature
15	Efficiency class
16	Production company

5. Installation

The pump must be installed horizontally.


When the suction pipe is longer than 10 metres or the suction lift is greater than 4 metres, the diameter of the suction pipe must be larger than 1". If there is a suction lift, we recommend that you fit a non-return valve to the suction pipe.

If a hose is used as a suction pipe, it must be non-collapsible.

To prevent solids from entering the pump, a filter can be fitted to the suction pipe.

Make sure that the pump is not stressed by the pipework.

Connect the discharge pipe to the pump discharge port (T). See fig. 2. H = maximum 7 metres.



TM05 1796 3711

Fig. 2 Pipe connection

Installation dimensions can be found on page [206](#).

5.1 Handle

It is not necessary to fit the handle supplied on permanently installed pumps.

On portable pumps the handle can be fitted lengthwise or crosswise depending on the material variant.

5.2 Ejector valve

The ejector valve is supplied separate with the pump.

Remove the plug (V), see fig. 5, and fit the ejector valve into the hole.

The O-ring must be fitted to the ejector valve.


Note

Tighten the valve using fingers only.

5.2.1 Ejector valve setting

The ejector valve in the plug hole (V) can be turned to two positions. See fig. 4.

Figure 3 shows an example of how the ejector valve position may affect the QH curve.



TM00 7474 1396

Fig. 3 QH curve and ejector valve positions

Pos. 1

Turn the valve to the left (out).

Select pos. 1 when the suction pipe is empty and the pump is to be primed.

Select also pos. 1 when a small quantity of water and a high pressure are required.

Pos. 2

Turn the valve to the right (in).

Select pos. 2 when the pump has been primed, and a large quantity of water and a low pressure are required.

Warning

This position must only be used for high flow rates and constant water consumption.

Pos.	Ejector valve	Direction	
1		Left (out)	TM04 2299 2308
2		Right (in)	TM04 2300 2308

Fig. 4 Ejector valve positions

6. Electrical connection

Carry out the electrical connection according to local regulations.



Warning

During electrical installation, make sure that the power supply cannot be accidentally switched on.



Warning

The pump must be connected to an external mains switch with a minimum contact gap of 3 mm in all poles.

As a precaution, the pump must be connected to a socket with earth connection.

We recommend that you fit the permanent installation with an earth leakage circuit breaker (ELCB) with a tripping current ≤ 30 mA.

Single-phase motors incorporate a thermal switch and require no additional motor protection.

Three-phase motors must be connected to an external mains switch and a motor-protective circuit breaker.

Carry out the electrical connection as shown in the diagram on the inside of the terminal box cover.

6.1 Checking the direction of rotation (three-phase motors)



Warning

Do not start the pump until it has been filled with liquid.

Arrows on the motor fan cover indicate the correct direction of rotation.

If the direction of rotation is wrong, switch off the power supply and interchange any two of the incoming supply wires.

7. Startup



Warning


Do not start the pump until it has been filled with liquid.



The pump must not run without delivering water for more than four minutes.

7.1 Filling the pump with water

1. Remove the plug (P). See fig. 5.
 2. Fill the pump with water.
 3. Refit the plug and tighten it using fingers only.
- The pump can now be started.



TM00 5495 4995

Fig. 5 Filling the pump with water

If there is a suction lift, up to four minutes may pass from the moment the pump is started until it delivers water. This period depends on the length and diameter of the suction pipe.

When the pump is delivering water without air, you may turn the ejector valve to position 2. See fig. 4.

7.2 Shaft seal run-in

The seal faces are lubricated by the pumped liquid, meaning that there may be a certain amount of leakage from the shaft seal.

When the pump is started up for the first time, or when a new shaft seal is installed, a certain run-in period is required before the leakage is reduced to an acceptable level. The time required for this depends on the operating conditions, i.e. every time the operating conditions change, a new run-in period will be started.

Under normal conditions, the leaking liquid will evaporate. As a result, no leakage will be detected.

8. Maintenance

If the pump has been used for dirty liquids, e.g. pool water, it must be flushed through with clean water immediately after use.

8.1 Cleaning the pump

It is only necessary to clean the pump if it does not work as intended and flushing it with clean water did not eliminate the problem.



Warning

Before starting work on the product, switch off the power supply. Make sure that the power supply cannot be accidentally switched on.

The position numbers mentioned in the following sections refer to fig. 6.

8.1.1 Dismantling

1. Pumps with ejector valve: Turn the ejector valve to pos. 1. See fig. 4.
2. Drain the pump by removing plug (pos. 25) or ejector valve (pos. 25a).



Warning

Make sure that the escaping hot or cold liquid does not cause injury to persons or damage to the equipment.

3. Remove screw (pos. 93) and clamp (pos. 92) holding pump sleeve (pos. 16).
4. Push pump sleeve (pos. 16) free of the motor stool with a screwdriver and take it off.
5. Pull ejector (pos. 14) out of the pump sleeve.
6. Clean the ejector and the pump sleeve using a soft brush or a water jet.
7. Check if impeller (pos. 49) is dirty. If that is the case, clean the impeller (in place) using a soft brush or a water jet. See fig. 7.
To prevent the impeller and shaft from rotating, hold the motor fan blades.



Caution Do not use a high-pressure jet cleaner.

8.1.2 Assembly

1. Moisten O-ring (pos. 13) with soapy water and fit it into the recess of the suction port of ejector (pos. 14).
2. Fit the ejector into pump sleeve (pos. 16). Check that O-ring (pos. 13) is positioned correctly on the collar of the suction port of the sleeve.
3. Moisten O-ring (pos. 31) with soapy water and place it on the ejector.
4. Moisten seal ring (pos. 91) with soapy water, fit it into the recess of the ejector and turn it against the stop.
5. Fit the pump sleeve with the ejector to the motor stool. Check that O-ring (pos. 31) is positioned correctly.
6. Place clamp (pos. 92) on the pump sleeve, and fit and tighten the screw and nut.
7. Refit plug (pos. 25) or ejector valve (pos. 25a). Check that the ejector valve is in position 1. See fig. 4. Tighten the plug or ejector valve using fingers only.

In orders for spare parts, please mention the position number in fig. 6 and the pump data marked on the pump nameplate.




Fig. 6 Exploded view of jet pump

Note The pump illustrated in fig. 6 may differ from the actual pump version.




Fig. 7 Cleaning the impeller

TM05 1803 3811

8.2 Frost protection

Caution If the pump is not used during periods of frosts, it must be drained to avoid damage.

To drain the pump, remove the plug (P) and the plug or the ejector valve (V). See fig. 8.




Fig. 8 Draining the pump

TM00 5497 4995

Warning

Make sure that the escaping hot or cold liquid does not cause injury to persons or damage to the equipment.

Refit the plugs and tighten them using fingers only.

TM05/536 3411

9. Technical data

Ambient temperature

Maximum +40 °C.

Storage temperature

Minimum -20 °C.

Maximum +70 °C.

Liquid temperature

See pump nameplate.

System pressure

Maximum 6 bar.

Inlet pressure

At inlet pressures above 1.5 bar the discharge pressure must be at least 2.5 bar.

Supply voltage

1 x 220-240 V, 50 Hz.

3 x 220-240/380-415 V, 50 Hz.

Insulation class

F.

Enclosure class

IP44.

Relative air humidity

Maximum 95 %.

Dimensions

See page [206](#).

Sound power level

The sound power level of the pump is lower than 72 dB(A).

Start/stop frequency

Maximum 100 per hour.

10. Fault finding



Warning

Before starting fault finding, switch off the power supply. Make sure that the power supply cannot be accidentally switched on.

Fault	Cause	Remedy
1. The pump does not start.	a) Supply failure. b) Pump blocked by impurities. c) Motor defective. d) Three-phase motors: The motor-protective circuit breaker has tripped.	Cut in the circuit breaker or replace the fuses. If the new fuses also blow, check the electric installation. Clean the pump. Check or replace the strainer in the suction pipe. Repair or replace the motor.* Cut in the motor-protective circuit breaker. If the problem still persists, check these two possible causes: • Impeller stuck. Clean the pump according to section 8.1. • Motor defective. Repair or replace the motor.*
2. The pump runs, but gives no water or delivers a reduced quantity of water.	a) Pump is not filled with water. b) Suction pipe blocked by impurities. c) Pump blocked by impurities. d) Suction lift is too high (over 7 metres). e) Suction pipe is too long. f) Diameter of suction pipe is too small. g) Suction pipe is not immersed deeply enough. h) Suction pipe is leaking. i) Ejector valve setting is incorrect (only pumps fitted with ejector valve). j) Direction of rotation is incorrect (three-phase pumps).	Prime the pump. See section 7. Clean the pump. Check or replace the strainer in the suction pipe. Clean the pump. Check or replace the strainer in the suction pipe. Change the position of the pump. Change the position of the pump. Replace the suction pipe. Make sure that the suction pipe is immersed sufficiently. Repair or replace the pipe. Set the valve. See section 5.2. Interchange two phases.
3. The pump runs, but gives no water or delivers a reduced quantity of water at high pressure.	a) Discharge pipe blocked.	Clean pipe or open isolating valves, if fitted. Check that no additional work is being carried out in the system.

Fault	Cause	Remedy
4. The motor cuts out during operation.	<p>a) Single-phase motors: The thermal switch in the motor has tripped due to overheating.</p> <p>b) Three-phase motors: Motor-protective circuit breaker has tripped.</p>	<p>The thermal switch will cut in automatically when the motor has cooled sufficiently. If the problem still persists, check these two possible causes:</p> <ul style="list-style-type: none"> • Impeller stuck. Clean the pump according to section 8.1. • Motor defective. Repair or replace the motor.* <p>Cut in the motor-protective circuit breaker. If the problem still persists, check these two possible causes:</p> <ul style="list-style-type: none"> • Impeller stuck. Clean the pump according to section 8.1. • Motor defective. Repair or replace the motor.*

* Or contact the nearest Grundfos company or service workshop.


11. Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Appendix

Material variant A




TM04 2346 2308

Pump type

Dimensions [mm]

Pump type	A	B	C
JP 5, material variant A	300	364	240
JP 6, material variant A	300	401	240

Material variant B



TM04 2347 2308

Pump type

Dimensions [mm]

Pump type	A	B	C
JP 5, material variant B	306	364	240
JP 6, material variant B	306	401	240

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Centro
Industrial Garín
1619 Garín Pcia. de B.A.
Phone: +54-3327 414 444
Telefax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Phone: +61-8-8461-4611
Telefax: +61-8-8340 0155

Austria

GRUNDFOS Pumpen Vertrieb
Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Telefax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomsesteenweg 81-83
B-2630 Aartselaar
Tél.: +32-3-870 7300
Télécopie: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в
Минске
220125, Минск
ул. Шаффарнянская, 11, оф. 56, БЦ
«Порт»
Тел.: +7 (375 17) 286 39 72/73
Факс: +7 (375 17) 286 39 71
E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A,
BH-71000 Sarajevo
Phone: +387 33 592 480
Telefax: +387 33 590 465
www.ba.grundfos.com
e-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castello
Branco, 630
CEP 09850 - 300
São Bernardo do Campo - SP
Phone: +55-11 4393 5533
Telefax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztochna Tangenta street no. 100
BG - 1592 Sofia
Tel. +359 2 49 22 200
Fax. +359 2 49 22 201
email: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada Inc.
2941 Brighton Road
Oakville, Ontario
L6H 8C9
Phone: +1-905 829 9533
Telefax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106
PRC
Phone: +86 21 612 252 22
Telefax: +86 21 612 253 33

COLOMBIA

GRUNDFOS Colombia S.A.S.
Km 1.5 vía Siberia-Cota Conj. Potrero
Chico,
Parque Empresarial Arcos de Cota Bod.
1A.
Cota, Cundinamarca
Phone: +57(1)-2913444
Telefax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Phone: +385 1 6595 400
Telefax: +385 1 6595 499
www.hr.grundfos.com

GRUNDFOS Sales Czechia and

Slovakia s.r.o.

Čajkovského 21
779 00 Olomouc
Phone: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tlf.: +45-87 50 50 50
Telefax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel: +372 606 1690
Fax: +372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikuja 1
FI-01360 Vantaa
Phone: +358-(0) 207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnés
57, rue de Malacobre
F-38290 St. Quentin Fallavier (Lyon)
Tél.: +33-4 74 82 15 15
Télécopie: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlütersstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Telefax: +49-(0) 211 929 69-3799
e-mail: infoservice@grundfos.de
Service in Deutschland:
e-mail: kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Phone: +0030-210-66 83 400
Telefax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor
Siu Wai Industrial Centre
29-33 Wing Hong Street &
68 King Lam Street, Cheung Sha Wan
Kowloon
Phone: +852-27861706 / 27861741
Telefax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Tópark u. 8
H-2045 Törökbalint,
Phone: +36-23 511 110
Telefax: +36-23 511 111

India

GRUNDFOS Pumps India Private
Limited
118 Old Mahabalipuram Road
Thoraipakkam
Chennai 600 096
Phone: +91-44 2496 6800

Indonesia

PT. GRUNDFOS POMPA
Graha Intirub Lt. 2 & 3
Jln. Ciliilitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Phone: +62 21-469-51900
Telefax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Phone: +353-1-4089 800
Telefax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Telefax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku,
Hamamatsu
431-2103 Japan
Phone: +81 53 428 4760
Telefax: +81 53 428 5005

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Ajou Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Phone: +82-2-5317 600
Telefax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava ielā 60, LV-1035, Riga,
Tāl.: + 371 714 9640, 7 149 641
Fakss: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam U1/25
Glenmarie Industrial Park
40150 Shah Alam
Selangor
Phone: +60-3-5569 2922
Telefax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México S.A. de C.V.
Boulevard TLC No. 15
Parque Industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Phone: +52-81-8144 4000
Telefax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Telefax: +31-88-478 6332
E-mail: info_gni@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrix Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Phone: +64-9-415 3240
Telefax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tlf.: +47-22 90 47 00
Telefax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznania
PL-62-081 Przeźmierowo
Tel: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet da Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 00
Telefax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
Bd. Biruintei, nr 103
Pantelimon county Ilfov
Phone: +40 21 200 4100
Telefax: +40 21 200 4101
E-mail: romania@grundfos.ro

Russia

ООО Grundfos Россия
ул. Школьная, 39-41
Москва, RU-109544, Russia
Тел. (+7) 495 564-88-00 (495) 737-30-00
Факс (+7) 495 564 8811
E-mail grundfos.moscow@grundfos.com

Serbia

Grundfos Srbija d.o.o.
Omladinskih brigada 90b
11070 Novi Beograd
Phone: +381 11 2258 740
Telefax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Phone: +65-6681 9688
Telefax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D
821 09 BRATISLAVA
Phone: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
Leskoškova 9e, 1122 Ljubljana
Phone: +386 (0) 1 568 06 10
Telefax: +386 (0) 1 568 06 19
E-mail: tehnika-si@grundfos.com

South Africa

GRUNDFOS (PTY) LTD
Corner Mountjoy and George Allen
Roads
Wilbart Ext. 2
Bedfordview 2008
Phone: (+27) 11 579 4800
Fax: (+27) 11 455 6066
E-mail: lsmart@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Caminillo de la Fuentecilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Telefax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunnagårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Telefax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Telefax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Phone: +886-4-2305 0868
Telefax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloem Phrakiat Rama 9 Road,
Dokmai, Pravej, Bangkok 10250
Phone: +66-2-725 8999
Telefax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi,
2. yol 200, Sokak No. 204
41490 Gebze/ Kocaeli
Phone: +90 - 262-679 7979
Telefax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

Бізнес Центр Європа
Столичне шосе, 103
м. Київ, 03131, Україна
Телефон: (+38 044) 237 04 00
Факс: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone
Dubai
Phone: +971 4 8815 166
Telefax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Phone: +44-1525-850000
Telefax: +44-1525-850011

U.S.A.

GRUNDFOS Pumps Corporation
17100 West 118th Terrace
Olathe, Kansas 66061
Phone: +1-913-227-3400
Telefax: +1-913-227-3500

Uzbekistan

Grundfos Tashkent, Uzbekistan The Representative Office of Grundfos Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Телефон: (+998) 71 150 3290 / 71 150 3291
Факс: (+998) 71 150 3292

Addresses Revised 14.03.2018

be think innovate

460510 0418

ECM: 1223105

www.grundfos.com

GRUNDFOS 

The name Grundfos, the Grundfos logo, and **be think innovate** are registered trademarks owned by Grundfos Holding A/S or Grundfos A/S, Denmark. All rights reserved worldwide.

© Copyright Grundfos Holding A/S