

ALPHA2 / ALPHA3 ALPHA SOLAR

Installation and operating instructions



English (GB) Installation and operating instructions

Original installation and operating instructions

These installation and operating instructions describe ALPHA2, ALPHA3 and ALPHA SOLAR.

Sections 1-5 give the information necessary to be able to unpack, install and start up the product in a safe way.

Sections 6-17 give important information about the product, as well as information on service, fault finding and disposal of the product.

CONTENTS

	Page
1. General information	2
1.1 Target group	2
1.2 Symbols used in this document	3
2. Receiving the product	3
2.1 Inspecting the product	3
2.2 Scope of delivery	3
3. Installing the product	4
3.1 Mechanical installation	4
3.2 Control box positions, ALPHA2, ALPHA3	4
3.3 Control box positions, ALPHA SOLAR	5
3.4 Insulating the pump housing	6
4. Electrical installation	6
4.1 Assembling the plug	7
4.2 Dismantling the plug	8
4.3 Electrical installation, ALPHA SOLAR	9
4.4 Power supply connection, ALPHA SOLAR	9
4.5 Control signal connection, ALPHA SOLAR	9
5. Starting up the product	9
5.1 Before startup	9
5.2 First startup	9
5.3 Venting the pump	10
5.4 Venting the heating system	10
6. Product introduction	11
6.1 Product description	11
6.2 Applications	12
6.3 Pumped liquids	12
6.4 Identification	13
7. Control functions	13
7.1 Elements on the control panel	13
7.2 Display	14
7.3 Light fields indicating the pump setting	14
7.4 Light field indicating the status of automatic night setback	14
7.5 Button for enabling or disabling of automatic night setback	14
7.6 Button for selection of pump setting	14
7.7 Control modes	15
7.8 Pump performance	17
7.9 Bypass valve	18
8. Operating the product	18
8.1 Using automatic night setback	18
8.2 Function of automatic night setback	19
8.3 Setting manual summer mode	19
8.4 Dry-running protection	19
8.5 ALPHA Reader	19
8.6 High-torque start	19
9. Fault finding the product	20
10. Technical data	21
10.1 Data and operating conditions	21
10.2 Dimensions, ALPHA2 and ALPHA3, XX-40, XX-50, XX-60, XX-80	22
10.3 Dimensions, ALPHA2 and ALPHA3, 25-40 A, 25-60 A	23
11. Performance curves	24
11.1 Guide to performance curves	24
11.2 Curve conditions	24
11.3 Performance curves, ALPHA2 and ALPHA3, XX-40 (N)	25
11.4 Performance curves, ALPHA2 and ALPHA3, XX-50 (N)	26
11.5 Performance curves, ALPHA2 and ALPHA3, XX-60 (N)	27
11.6 Performance curves, ALPHA2 and ALPHA3, 25-40 A	28

11.7 Performance curves, ALPHA2 and ALPHA3, 25-60 A	29
11.8 Performance curves, ALPHA2 and ALPHA3, XX-80 (N)	30
12. Accessories	31
12.1 Unions and valve kits	31
12.2 Insulating shells, ALPHA2, ALPHA3	31
12.3 ALPHA plugs	32
12.4 ALPHA Reader	32
13. ALPHA SOLAR	32
13.1 Product introduction	32
13.2 Operating the product	33
13.3 Setting by means of the control panel	33
13.4 Operating and alarm status	33
13.5 Fault finding the product	34
14. External PWM control mode and signals	35
15. Digital signal converter	35
16. Technical data	35
17. Disposing of the product	37

1. General information

1.1 Target group



Read this document and the quick guide before installing the product. Installation and operation must comply with local regulations and accepted codes of good practice.



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

1.2 Symbols used in this document

1.2.1 Warnings against hazards involving risk of death or personal injury



DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The text accompanying the three hazard symbols DANGER, WARNING and CAUTION is structured in the following way:



SIGNAL WORD

Description of hazard

Consequence of ignoring the warning.
- Action to avoid the hazard.

1.2.2 Other important notes



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

2. Receiving the product

2.1 Inspecting the product

Check that the product received is in accordance with the order.

Check that the voltage and frequency of the product match voltage and frequency of the installation site. See section [6.4.1 Nameplate](#).

2.2 Scope of delivery

The box contains the following items:

- ALPHA2, ALPHA3 or ALPHA SOLAR pump
- ALPHA plug
- insulating shells
- two gaskets
- quick guide.

ALPHA SOLAR is delivered without insulating shells but with a plug designed for ALPHA SOLAR.

3. Installing the product

3.1 Mechanical installation



3.1.1 Mounting the product




Fig. 1 Mounting ALPHA2 or ALPHA3

The arrows on the pump housing indicate the flow direction through the pump. See fig. 1, pos. A.

See section [10.2 Dimensions, ALPHA2 and ALPHA3, XX-40, XX-50, XX-60, XX-80](#) or section [10.3 Dimensions, ALPHA2 and ALPHA3, 25-40 A, 25-60 A](#).

1. Fit the two gaskets when you mount the pump in the pipe. See fig. 1, pos. B.
2. Install the pump with a horizontal motor shaft. See fig. 1, pos. C. See also section [3.2 Control box positions, ALPHA2, ALPHA3](#).
3. Tighten the fittings.

3.2 Control box positions, ALPHA2, ALPHA3




Fig. 2 Control box positions

Always install the pump with a horizontal motor shaft.

- Pump installed correctly in a vertical pipe. See fig. 2, pos. A.
- Pump installed correctly in a horizontal pipe. See fig. 2, pos. B.
- Do not install the pump with a vertical motor shaft. See fig. 2, pos. C and D.

3.2.1 Positioning of the control box in heating and domestic hot-water systems

You can position the control box in position 3, 6 and 9 o'clock. See fig. 3.



Fig. 3 Control box positions, heating and domestic hot-water systems

TM05 3057 0612

TM05 3146 0912

3.2.2 Positioning the control box in air-conditioning and cold-water systems

Position the control box with the plug pointing downwards. See fig. 4.



Fig. 4 Control box position, air-conditioning and cold-water systems

3.2.3 Changing the control box position




Fig. 5 Changing the control box position
You can turn the control box in steps of 90 °.

CAUTION Hot surface



Minor or moderate personal injury.
- Position the pump so that persons cannot accidentally come into contact with hot surfaces.

CAUTION Pressurised system



Minor or moderate personal injury.
- Before dismantling the pump, drain the system or close the isolating valve on either side of the pump. The pumped liquid may be scalding hot and under high pressure.



If you change the position of the control box, fill the system with the liquid to be pumped or open the isolating valves.

1. Remove the four screws.
2. Turn the pump head to the desired position.
3. Insert and cross-tighten the screws.

3.3 Control box positions, ALPHA SOLAR



Fig. 6 Control box positions, ALPHA SOLAR

Always install the pump with horizontal motor shaft. Position the control box in position 9 o'clock. See fig. 7.




Fig. 7 Position of the ALPHA SOLAR control box

You can turn the control box in steps of 90 °.

3.4 Insulating the pump housing



Fig. 8 Insulating the pump housing

You can reduce the heat loss from the ALPHA2 or ALPHA3 pump by insulating the pump housing with the insulating shells supplied with the pump. See fig. 8.



Do not insulate the control box or cover the control panel.

TMI05 3058 0912

4. Electrical installation



DANGER

Electric shock

Death or serious personal injury
- Switch off the power supply before starting any work on the product. Make sure that the power supply cannot be accidentally switched on.



DANGER

Electric shock

Death or serious personal injury
- Connect the pump to earth.
Connect the pump to an external main switch with a minimum contact gap of 3 mm in all poles.



DANGER

Electric shock


Death or serious personal injury
- If national legislation requires a Residual Current Device (RCD) or equivalent in the electrical installation, or if the pump is connected to an electric installation where an RCD is used as an additional protection, this must be type A or better, due to the nature of the pulsating DC leakage current. The RCD must be marked with the symbol shown below;



Carry out the electrical connection and protection in accordance with local regulations.

- The motor requires no external motor protection.
- Check that the supply voltage and frequency correspond to the values stated on the nameplate. See section [6.4.1 Nameplate](#).
- Connect the pump to the power supply with the plug supplied with the pump. See steps 1 to 7.

4.2 Dismantling the plug

Step	Action	Illustration
1	Loosen the cable gland and remove it from the plug.	
2	Pull off the plug cover while pressing on both sides.	
3	Add the conductor guide plate to loosen all three cable conductors at the same time. If the guide plate is missing, then loosen the cable conductors one by one by pressing a screwdriver gently into the terminal clip.	
4	The plug has now been removed from the power supply plug.	

TM05 5545 3812

TM05 5546 3812

TM05 5547 3812

TM05 5548 3812

4.3 Electrical installation, ALPHA SOLAR



Fig. 9 Control box connections

TM06 5819 0216

4.4 Power supply connection, ALPHA SOLAR

Connect the pump to the power supply with the Superseal power connector.



Fig. 10 Superseal power connector

TM06 9076 2617

DANGER

Electric shock

Death or serious personal injury

- Connect the pump to earth.
- Connect the pump to an external main switch with a minimum contact gap of 3 mm in all poles.



DANGER

Electric shock

Death or serious personal injury

- If national legislation requires a Residual Current Device (RCD) or equivalent in the electrical installation, or if the pump is connected to an electric installation where an RCD is used as an additional protection, this must be type A or better, due to the nature of the pulsating DC leakage current. The RCD must be marked with the symbol shown below;



4.5 Control signal connection, ALPHA SOLAR

If you do not need the signal connection, cover it with a blanking plug. See fig. 9.

You can control the pump with a low-voltage PWM (pulse-width modulation) signal.

The PWM signal is a method for generating an analog signal using a digital source.

The control signal connection has three conductors: signal input, signal output and signal reference. See fig. 11. Connect the cable to the control box with a Mini Superseal plug. The signal cable can be supplied with the pump as an accessory.



Fig. 11 Mini Superseal plug

TM06 9076 2617

5. Starting up the product

5.1 Before startup

Do not start the pump until the system has been filled with liquid and vented. Make sure that the required minimum inlet pressure is available at the pump inlet. See section 10. *Technical data*. For instructions on how to vent the system, see sections 5.3 *Venting the pump* and 5.4 *Venting the heating system*.

5.2 First startup

After installing the product, see section 3. *Installing the product*, turn on the power supply. The light in the control panel shows that the power supply has been switched on. See fig. 12.

The pump is factory set to AUTO_{ADAPT}.




Fig. 12 Starting up the pump



TM05 3058 0912

5.3 Venting the pump



Fig. 13 Venting the pump

The pump is self-venting through the system. You do not have to vent the pump before startup.

Air in the pump may cause noise. This noise ceases when the pump has run for a few minutes.

You obtain quick venting of the pump by setting the pump to speed III for a short period. How fast the pump is vented depends on the system size and design.

When you have vented the pump, i.e. when the noise has ceased, set the pump according to the recommendations. See section 7. *Control functions*.



The pump must not run dry.

You cannot vent the system through the pump. See section 5.4 *Venting the heating system*.

TM05 3075 0912

5.4 Venting the heating system




Fig. 14 Venting of the heating system

Vent the heating system as follows:

- via a vent valve installed above the pump (1)
- via a pump housing with air separator (2).

In heating systems that often contain much air, we recommend that you install pumps with pump housing with air separator, i.e. ALPHA2 or ALPHA3 XX-XX A.

When the heating system has been filled with liquid, do as follows:

1. Open the vent valve.
2. Set the pump to speed III.
3. Let the pump run for a short period
4. Set the pump according to the recommendations. See section 7. *Control functions*.

Repeat the procedure, if necessary.



The pump must not run dry.

TM03 8931 2707

6. Product introduction



6.1 Product description




Fig. 15 Pumped liquids, warnings and operating conditions

ALPHA2 and ALPHA3 are a complete range of circulator pumps.

6.1.1 Model type

These installation and operating instructions cover ALPHA2 model B, C, D and E, and ALPHA3 model A. The model type is stated on the packaging and nameplate. See figs 16 and 17.



Fig. 16 Model type on the packaging



Fig. 17 Model type on the nameplate

TM06 45820 2515

TM06 1716 2614

The table below shows the ALPHA2 and ALPHA3 models with built-in functions and features.

Functions/features	ALPHA2 model B	ALPHA2 model C	ALPHA2 model D	ALPHA2 model E	ALPHA3 model A
Starts from	PC 12xx*	PC 14xx*	PC 15xx*	PC 17xx*	PC 15xx*
AUTO _{ADAPT}	•	•	•	•	•
Proportional pressure	•	•	•	•	•
Constant pressure	•	•	•	•	•
Constant curve	•	•	•	•	•
Automatic night setback	•	•	•	•	•
Manual summer mode		•	•	•	•
Dry-running protection			•	•	•
ALPHA Reader compatible				•	•
High-torque start			•	•	•
ALPHA2/3XX-40	•	•	•	•	•
ALPHA2/3XX-50**	•	•	•	•	•
ALPHA2/3XX-60	•	•	•	•	•
ALPHA2/3XX-80		•	•	•	•

* Production code (Year-Week).

** Not available in all countries.

6.2 Applications

The ALPHA2 and ALPHA3 circulator pumps are designed for the circulation of water in heating systems, domestic hot-water systems as well as air-conditioning and cold-water systems.

Cold-water systems are defined as systems where the ambient temperature is higher than the temperature of the pumped liquid.

ALPHA2 and ALPHA3 are the best choices for the following systems:

- underfloor heating systems
- one-pipe systems
- two-pipe systems.

ALPHA2 and ALPHA3 are suitable for the following:

- Systems with constant or variable flow rates where you want to optimise the setting of the pump duty point.
- Systems with variable flow-pipe temperature.
- Systems where you want automatic night setback.
- Balancing of domestic heating systems.

6.3 Pumped liquids

In heating systems, the water must meet the requirements of accepted standards on water quality in heating systems, for example the German standard VDI 2035.

The pump is suitable for the following liquids:

- Thin, clean, non-aggressive and non-explosive liquids, not containing solid particles or fibres.
 - Cooling liquids, not containing mineral oil.
 - Domestic hot water
 - Maximum: 14 °dH
 - Maximum: 65 °C
 - Maximum peak: 70 °C.
- For water with a higher degree of hardness, we recommend that you use a direct-coupled TPE pump.
- Softened water.

The kinematic viscosity of water is 1 mm²/s (1 cSt) at 20 °C. If the pump is used for a liquid with a higher viscosity, the hydraulic performance of the pump will be reduced.

Example: 50 % glycol at 20 °C means a viscosity of approx. 10 mm²/s (10 cSt) and a reduction of the pump performance by approx. 15 %.

Do not use additives that can or will disturb the functionality of the pump.

When selecting a pump, take the viscosity of the pumped liquid into consideration.

For more information about the pumped liquids, warnings and operating conditions, see fig. 15.

CAUTION

Flammable material



Minor or moderate personal injury.

- Do not use the pump for flammable liquids, such as diesel oil and petrol.

WARNING

Biological hazard



Death or serious personal injury.

- In domestic hot-water systems, the temperature of the pumped liquid must always be above 50 °C due to the risk of legionella.

WARNING

Biological hazard



Death or serious personal injury.

- In domestic hot-water systems, the pump is permanently connected to the mains water. Therefore, do not connect the pump by a hose.

CAUTION

Corrosive substance



Minor or moderate personal injury.

- Do not use the pump for aggressive liquids, such as acids and seawater.

6.4 Identification

6.4.1 Nameplate




Fig. 18 Nameplate

Pos.	Description
1	Pump type
2	Rated current [A]: • Min.: Minimum current [A] • Max.: Maximum current [A]
3	CE mark and approvals
4	EEL: Energy Efficiency Index Part, according to EEL
5	Voltage [V]
6	Product number
7	Serial number
8	Model
9	Country of origin
10	Input power P1 [W]: • Min.: Minimum input power P1 [W] • Max.: Maximum input power P1 [W]
11	Maximum system pressure [MPa]
12	Enclosure class
13	Temperature class
14	Production code: • 1st and 2nd figures: year • 3rd and 4th figures: week
15	Frequency [Hz]
16	Data matrix code

6.4.2 Type key

Example	ALPHA2/3	25	-40	N	180
Pump type					
[]: Standard version					
Nominal diameter (DN) of inlet and outlet ports [mm]					
Maximum head [dm]					
[]: Cast-iron pump housing					
A: Pump housing with air separator					
N: Stainless-steel pump housing					
Port-to-port length [mm]					

7. Control functions

7.1 Elements on the control panel



Fig. 19 Control panel

Pos.	Description
1	Display showing the actual power consumption in watt or the actual flow rate in m ³ /h.
2	Nine light fields indicating the pump setting. See section 7.3 <i>Light fields indicating the pump setting</i> .
3	Light field indicating the status of automatic night setback.
4	Button for enabling or disabling of automatic night setback and manual summer mode.
5	Button for selection of pump setting.
6	Button for selection of parameter to be shown in the display, i.e. actual power consumption in watt or actual flow rate in m ³ /h.
7	Connectivity symbol.

7.2 Display

The display (1) is on when you have switched on the power supply.

The display shows the actual pump power consumption in watt or the actual flow rate in m³/h in steps of 0.1 m³/h during operation.

Faults preventing the pump from operating properly, for example a blocked rotor, are indicated in the display by fault codes. See section 9. [Fault finding the product](#).

If a fault is indicated, correct the fault and reset the pump by switching the power supply off and on.

If the pump impeller is rotated, for example when filling the pump with water, sufficient energy can be generated to light up the display even if the power supply has been switched off.

7.3 Light fields indicating the pump setting

The pump has ten performance settings which you can select with the button (5). See fig. 19.

The pump setting is indicated by nine light fields in the display. See fig. 20.



TMO5 3061 0912

Fig. 20 Nine light fields

Button presses	Active light fields	Description
0	factory setting AUTO ADAPT	AUTO _{ADAPT}
1		Lowest proportional-pressure curve, PP1
2		Intermediate proportional-pressure curve, PP2
3		Highest proportional-pressure curve, PP3
4		Lowest constant-pressure curve, CP1
5		Intermediate constant-pressure curve, CP2
6		Highest constant-pressure curve, CP3
7	III	Constant curve/constant speed III
8	II	Constant curve/constant speed II
9	I	Constant curve/constant speed I
10	AUTO ADAPT	AUTO _{ADAPT}

For information about the function of the settings, see section 7.7 [Control modes](#).

7.4 Light field indicating the status of automatic night setback

Light in shows that automatic night setback is active. See fig. 19, pos. 3. See also section 7.5 [Button for enabling or disabling of automatic night setback](#).

7.5 Button for enabling or disabling of automatic night setback

The button enables and disables automatic night setback. See fig. 19, pos. 4.

Automatic night setback is only relevant for heating systems prepared for this function. See section 9. [Fault finding the product](#).

The light field is on when automatic night setback is active. See fig. 19, pos. 3.

Factory setting: automatic night setback is not active.

If you have set the pump to speed I, II or III, you cannot select automatic night setback.

7.6 Button for selection of pump setting

Every time you press the button , the pump setting is changed. See fig. 19, pos. 5.

A cycle is ten button presses. See section 7.3 [Light fields indicating the pump setting](#).

7.7 Control modes



7.7.1 Pump setting for two-pipe heating systems




Fig. 21 Selection of pump setting for system type

Factory setting: AUTO_{ADAPT}.

Recommended and alternative pump settings according to fig. 21:

Heating system	Pump setting	
	Recommended	Alternative
Two-pipe system	AUTO _{ADAPT} *	Proportional-pressure curve, PP1, PP2 or PP3*

* See section 11.1 Guide to performance curves.

AUTO_{ADAPT}

The AUTO_{ADAPT} function adjusts the pump performance to the actual heat demand in the system. As the performance is adjusted gradually, we recommend that you leave the pump in the AUTO_{ADAPT} mode at least one week before changing the pump setting.

If the power supply fails or is disconnected, the pump stores the AUTO_{ADAPT} setting in an internal memory and resumes the automatic adjustment when the power supply has been restored.

Proportional-pressure curve, PP1, PP2 or PP3

Proportional-pressure control adjusts the pump performance to the actual heat demand in the system, but the pump performance follows the selected performance curve, PP1, PP2 or PP3. See fig. 22 where PP2 has been selected. For further information, see section 11.1 Guide to performance curves.




Fig. 22 Three proportional-pressure curves/settings

The selection of the proportional-pressure setting depends on the characteristics of the heating system and the actual heat demand.

7.7.2 Pump setting for one-pipe heating systems





Fig. 23 Selection of pump setting for system type

Factory setting: AUTO_{ADAPT}.

Recommended and alternative pump settings according to fig. 23:

Heating system	Pump setting	
	Recommended	Alternative
One-pipe system	Constant curve/constant speed, I, II or III*	Constant-pressure curve CP1, CP2 or CP3*

* See section 11.1 Guide to performance curves.

Constant-pressure curve, CP1, CP2 or CP3

Constant-pressure control adjusts the pump performance to the actual heat demand in the system, but the pump performance follows the selected performance curve, CP1, CP2 or CP3. See fig. 24 where CP1 has been selected. For further information, see section 11.1 Guide to performance curves.




Fig. 24 Three constant-pressure curves and settings

The selection of the constant-pressure setting depends on the characteristics of the heating system and the actual heat demand.

TM05 3063 0912

TM05 3065 0912

TM05 3064 0912

TM05 3066 0912

7.7.3 Pump setting for underfloor heating systems





Fig. 25 Selection of pump setting for system type

Factory setting: AUTO_{ADAPT}.

Recommended and alternative pump settings according to fig. 25:

System type	Pump setting	
	Recommended	Alternative
Underfloor heating	Constant-pressure curve, CP1, CP2 or CP3*	Constant curve/constant speed, I, II or III

* See section 11.1 Guide to performance curves.

Constant-pressure curve, CP1, CP2 or CP3

The constant-pressure control adjusts the flow rate to the actual heat demand in the system keeping a constant pressure at the same time. The pump performance follows the selected performance curve, CP1, CP2 or CP3. See fig. 26 where CP1 has been selected. For further information, see section 11.1 Guide to performance curves.




Fig. 26 Three constant-pressure curves or settings

The selection of the constant-pressure setting depends on the characteristics of the heating system and the actual heat demand.

7.7.4 Pump setting for domestic hot-water systems




Fig. 27 Selection of pump setting for system type

Factory setting: AUTO_{ADAPT}.

Recommended and alternative pump settings according to fig. 27:

System type	Pump setting	
	Recommended	Alternative
Domestic hot water	Constant curve/constant speed, I, II or III	Constant-pressure curve, CP1, CP2 or CP3*

* See section 11.1 Guide to performance curves.

Constant curve/constant speed, I, II or III

At constant-curve/constant-speed operation, the pump runs at a constant speed, independently of the actual flow rate demand in the system. The pump performance follows the selected performance curve, I, II or III. See fig. 28 where II has been selected. For further information, see section 11.1 Guide to performance curves.




Fig. 28 Three constant curve/constant speed settings

The selection of the constant-curve/constant-speed setting depends on the characteristics of the heating system and the number of taps likely to be opened at the same time.

7.7.5 Changing from recommended to alternative pump setting

Heating systems are relatively slow systems that cannot be set to the optimum operation within minutes or hours.

If the recommended pump setting does not give the desired distribution of heat in the rooms of the house, change the pump setting to the shown alternative.

7.8 Pump performance

Relation between pump setting and pump performance.

Figure 29 shows the relation between pump setting and pump performance by means of curves. See also section 11. [Performance curves](#).




Fig. 29 Pump setting in relation to pump performance

Setting	Pump curve	Function
AUTO _{ADAPT} factory setting	Highest to lowest proportional-pressure curve	The AUTO _{ADAPT} function enables the pump to control the pump performance automatically within a defined performance range. See fig. 29. <ul style="list-style-type: none"> Adjusting the pump performance to the size of the system. Adjusting the pump performance to the variations in load over time. In AUTO _{ADAPT} , the pump is set to proportional-pressure control.
PP1	Lowest proportional-pressure curve	The duty point of the pump will move up or down on the lowest proportional-pressure curve, depending on the heat demand. See fig. 29. The head is reduced at falling heat demand and increased at rising heat demand.
PP2	Intermediate proportional-pressure curve	The duty point of the pump will move up or down on the intermediate proportional-pressure curve, depending on the heat demand. See fig. 29. The head is reduced at falling heat demand and increased at rising heat demand.
PP3	Highest proportional-pressure curve	The duty point of the pump will move up or down on the highest proportional-pressure curve, depending on the heat demand. See fig. 29. The head is reduced at falling heat demand and increased at rising heat demand.
CP1	Lowest constant-pressure curve	The duty point of the pump will move out or in on the lowest constant-pressure curve, depending on the heat demand in the system. See fig. 29. The head is kept constant, irrespective of the heat demand.
CP2	Intermediate constant-pressure curve	The duty point of the pump will move out or in on the intermediate constant-pressure curve, depending on the heat demand in the system. See fig. 29. The head is kept constant, irrespective of the heat demand.
CP3	Highest constant-pressure curve	The duty point of the pump will move out or in on the highest constant-pressure curve, depending on the heat demand in the system. See fig. 29. The head is kept constant, irrespective of the heat demand.
III	Speed III	The pump runs on a constant curve which means that it runs at a constant speed. In speed III, the pump is set to run on the maximum curve under all operating conditions. See fig. 29. You obtain quick venting of the pump by setting the pump to speed III for a short period. See section 5.3 Venting the pump .
II	Speed II	The pump runs on a constant curve which means that it runs at a constant speed. In speed II, the pump is set to run on the intermediate curve under all operating conditions. See fig. 29.
I	Speed I	The pump runs on a constant curve which means that it runs at a constant speed. In speed I, the pump is set to run on the minimum curve under all operating conditions. See fig. 29.
	Automatic night setback or manual summer mode	The pump changes to the curve for automatic night setback, i.e. absolute minimum performance and power consumption, provided that certain conditions are met. In manual summer mode, the pump is stopped to save energy and only the electronics are running. To avoid lime precipitation and blocking of the pump, the pump is started frequently in a short period. See section 9. Fault finding the product .

TM05 2771 2817

7.9 Bypass valve




Fig. 30 Systems with bypass valve

The purpose of the bypass valve is to ensure that the heat from the boiler can be distributed when all valves in the underfloor-heating circuits and/or thermostatic radiator valves are closed.

System elements:

- bypass valve
- flowmeter, pos. A.

The minimum flow must be available when all valves are closed. The pump setting depends on the type of bypass valve used, i.e. manually operated or thermostatically controlled.

7.9.1 Setting the bypass valve

Manually operated

1. Adjust the bypass valve with the pump in setting I (speed I).
2. Observe the minimum flow rate of the system. See the manufacturer's instructions.
3. After setting the bypass valve, set the pump according to [7. Control functions](#).

Automatically operated, thermostatically controlled

1. Adjust the bypass valve with the pump in setting I (speed I).
2. Observe the minimum flow rate for the system. Consult the manufacturer's instructions.

After adjusting the bypass valve, set the pump to the lowest or highest constant-pressure curve. For further information about pump settings in relation to performance curves, see section [9. Fault finding the product](#).

8. Operating the product

8.1 Using automatic night setback



Fig. 31 Automatic night setback activated



Do not use automatic night setback when the pump is installed in the return pipe of the heating system.

If you select speed I, II or III, automatic night setback is disabled. You do not have to re-enable automatic night setback if the power supply has been switched off.

If the power supply is switched off when the pump is running on the curve for automatic night setback, the pump starts in normal operation. See section [9. Fault finding the product](#).

The pump changes back to the curve for automatic night setback when the condition for automatic night setback is fulfilled again. See section [8.2 Function of automatic night setback](#).

If there is insufficient heat in the heating system, check whether automatic night setback has been enabled. If yes, disable the function.

To ensure the optimum function of automatic night setback, the following conditions must be fulfilled:

- The pump must be installed in the flow pipe. See [fig. 31](#).
- The boiler must incorporate automatic control of the liquid temperature.

Enable automatic night setback by pressing . See section [7.5 Button for enabling or disabling of automatic night setback](#).

Light in means that automatic night setback is active.

TM05 3076 0912

TM06 1251 2014

8.2 Function of automatic night setback

Once you have enabled automatic night setback, the pump automatically changes between normal duty and automatic night setback. See section 9. [Fault finding the product](#).

Changeover between normal duty and automatic night setback depends on the flow-pipe temperature.

The pump automatically changes over to automatic night setback when a flow-pipe temperature drop of more than 10 to 15 °C within approx. two hours is registered. The temperature drop must be at least 0.1 °C/min.

Changeover to normal duty takes place without a time lag when the flow-pipe temperature has increased by approx. 10 °C.

8.3 Setting manual summer mode

Manual summer mode is available as from ALPHA2 model C and ALPHA3 model A.

In manual summer mode, the pump is stopped to save energy. To avoid lime precipitation and blocking of the pump, the pump is started frequently in a short period. This is an alternative to shutting down the pump if there is a risk of lime deposit.



There is a risk of lime deposit in case of a long standstill period.

In manual summer mode, the pump starts frequently at low speed to avoid blocking the rotor. The display is turned off.

If any alarms occur during manual summer mode, no alarms will be shown. When manual summer mode is deactivated again, only the actual alarms will be displayed.

If the automatic night setback mode is enabled before setting the manual summer mode, the pump will return to automatic night setback mode after manual summer mode.

8.3.1 Activating manual summer mode

Activate the manual summer mode by pressing the automatic night setback button 3 to 10 seconds. See fig. 31. The green light field flashes quickly. After a short while the display turns off and the green light field  flashes slowly.



Fig. 32 Automatic night setback button

8.3.2 Deactivating manual summer mode

Deactivate the manual summer mode by pressing any of the buttons. Then the pump returns to the previous mode and setting.

8.4 Dry-running protection

The dry-running protection protects the pump against dry running during start and normal operation. See section 9. [Fault finding the product](#).

During first startup and in case of dry-run, the pump will operate for 30 minutes before stopping. During this period the pump displays the error code "E4 - - -".

Dry-running protection is available as from ALPHA2 model D and ALPHA3 model A.

8.5 ALPHA Reader



The ALPHA Reader is compatible as from ALPHA2 model E and ALPHA3 model A only. A connectivity symbol on the pump indicates compatibility with the ALPHA Reader. See fig. 33.

The ALPHA Reader provides safe readout of internal data from the pump to an Android or iOS-based mobile device via Bluetooth. Together with the Grundfos GO Balance app the ALPHA Reader allows you to balance two-pipe radiators and underfloor heating systems in a fast and safe way. For further information, see section 12.4 [ALPHA Reader](#).



Fig. 33 ALPHA Reader

8.5.1 Activating and deactivating the ALPHA Reader mode on the pump

1. Press [W/m³/h]  and hold it for 3 seconds.
2. ALPHA Reader is either activated or deactivated, depending on the previous state. When ALPHA Reader is active, the unit indicator in the display [W/m³/h] flashes rapidly.



You can activate and deactivate the ALPHA Reader mode in all pump modes.

For further information on how to set the ALPHA Reader and perform hydronic balancing, see the ALPHA Reader documentation in Grundfos Product Center on www.grundfos.com.

8.6 High-torque start

If the shaft is blocked and you cannot start the pump, the display indicates the alarm "E1 - - -", with a delay of 20 minutes.

The pump attempts to restart until the pump is powered off.

During the start attempts, the pump vibrates due to the high-torque load.

High-torque start is available as from ALPHA2 model D and ALPHA3 model A.

TM05 3149 1112

TM06 4452 2315

9. Fault finding the product

DANGER

Electric shock



Death or serious personal injury

- Switch off the power supply before starting any work on the product. Make sure that the power supply cannot be accidentally switched on.

CAUTION

Pressurised system



Minor or moderate personal injury

- Before dismantling the pump, drain the system or close the isolating valves on either side of the pump. The pumped liquid may be scalding hot and under high pressure.

Fault	Control panel	Cause	Remedy	
1. The pump does not run.	Light off.	a) A fuse in the installation is blown.	Replace the fuse.	
		b) The current-operated or voltage-operated circuit breaker has tripped.	Cut in the circuit breaker.	
		c) The pump is defective.	Replace the pump.	
		Changes between "- -" and "E 1".	a) The rotor is blocked.	Remove the impurities.
		Changes between "- -" and "E 2".	a) Insufficient supply voltage.	Make sure that the supply voltage falls within the specified range.
Changes between "- -" and "E 3".	a) Electrical fault.	Replace the pump.		
Changes between "- -" and "E 4".	a) Dry-running protection.	Make sure that there is sufficient liquid in the pipe system. Reset the warning by pressing any button or switch off the power supply.		
2. Noise in the system.	No warning is indicated on the display.	a) Air in the system.	Vent the system. See section 5.4 Venting the heating system .	
		b) The flow rate is too high.	Reduce the suction head.	
3. Noise in the pump.	No warning is indicated on the display.	a) Air in the pump.	Let the pump run. The pump vents itself over time. See section 5.3 Venting the pump .	
		b) The inlet pressure is too low.	Increase the inlet pressure, or make sure that the air volume in the expansion tank is sufficient, if installed.	
4. Insufficient heat.	No warning is indicated on the display.	a) The pump performance is too low.	Increase the suction head.	

10. Technical data

10.1 Data and operating conditions

Supply voltage	1 x 230 V ± 10 %, 50/60 Hz, PE	
Motor protection	The pump requires no external motor protection.	
Enclosure class	IPX4D	
Insulation class	F	
Relative humidity	Maximum 95 % RH	
System pressure	Maximum 1.0 MPa, 10 bar, 102 m head	
Inlet pressure	Liquid temperature	Minimum inlet pressure
	≤ 75 °C	0.005 MPa, 0.05 bar, 0.5 m head
	90 °C	0.028 MPa, 0.28 bar, 2.8 m head
	110 °C	0.108 MPa, 1.08 bar, 10.8 m head
EMC (electromagnetic compatibility)	EMC Directive (2014/30/EU). Standards used: EN 55014-1:2006/A1:2009/A2:2011, EN 55014-2:2015, EN 61000-3-2:2014 and EN 61000-3-3:2013.	
Sound pressure level	The sound pressure level of the pump is lower than 43 dB(A).	
Ambient temperature	0-40 °C	
Temperature class	TF110 to CEN 335-2-51	
Surface temperature	The maximum surface temperature will not exceed 125 °C.	
Liquid temperature	2-110 °C	
Power consumption in manual summer mode	< 0.8 watt	
Specific EEI values	ALPHA2/3 XX-40: EEI ≤ 0.15	
	ALPHA2/3 XX-50: EEI ≤ 0.16	
	ALPHA2/3 XX-60: EEI ≤ 0.17	
	ALPHA2/3 XX-80: EEI ≤ 0.18	
	ALPHA2/3 XX-40 A: EEI ≤ 0.18	
	ALPHA2/3 XX-60 A: EEI ≤ 0.20	

To avoid condensation in the control box and stator, the liquid temperature must always be higher than the ambient temperature.

Ambient temperature [°C]	Liquid temperature	
	Min. [°C]	Max. [°C]
0	2	110
10	10	110
20	20	110
30	30	110
35	35	90
40	40	70

WARNING

Biological hazard

Death or serious personal injury.

- In domestic hot-water systems, we recommend that you keep the liquid temperature below 65 °C to eliminate the risk of lime precipitation. The temperature of the pumped liquid must always be above 50 °C due to the risk of legionella. Recommended boiler temperature: 60 °C.



If the temperature of the pumped liquid is lower than the ambient temperature, make sure that the pump is installed with the pump head and plug in position 6 o'clock.

10.2 Dimensions, ALPHA2 and ALPHA3, XX-40, XX-50, XX-60, XX-80

Dimensional sketches and table of dimensions.




Fig. 34 ALPHA2 and ALPHA3, XX-40, XX-50, XX-60, XX-80

TM05 2364 5011

Pump type	Dimensions								
	L1	B1	B2	B3	B4	H1	H2	H3	G
ALPHA2/3 15-40 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1
ALPHA2/3 15-50 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1*
ALPHA2/3 15-60 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1*
ALPHA2/3 15-80 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1
ALPHA2/3 25-40 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1 1/2
ALPHA2/3 25-40 N 130	130	54	54	44.5	44.5	36.8	103.5	47	G 1 1/2
ALPHA2/3 25-50 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1 1/2
ALPHA2/3 25-50 N 130	130	54	54	44.5	44.5	36.8	103.5	47	G 1 1/2
ALPHA2/3 25-60 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1 1/2
ALPHA2/3 25-60 N 130	130	54	54	44.5	44.5	36.8	103.5	47	G 1 1/2
ALPHA2/3 25-80 130	130	54	54	44.5	44.5	35.8	103.5	47	G 1 1/2
ALPHA2/3 25-80 N 130	130	54	54	44.5	44.5	36.8	103.5	47	G 1 1/2
ALPHA2/3 25-40 180	180	54	54	44.5	44.5	35.9	103.5	47	G 1 1/2
ALPHA2/3 25-40 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 1 1/2
ALPHA2/3 25-50 180	180	54	54	44.5	44.5	35.9	103.5	47	G 1 1/2
ALPHA2/3 25-50 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 1 1/2
ALPHA2/3 25-60 180	180	54	54	44.5	44.5	35.9	103.5	47	G 1 1/2
ALPHA2/3 25-60 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 1 1/2
ALPHA2/3 25-80 180	180	54	54	44.5	44.5	35.9	103.5	47	G 1 1/2
ALPHA2/3 25-80 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 1 1/2
ALPHA2/3 32-40 180	180	54	54	44.5	44.5	35.9	103.5	47	G 2
ALPHA2/3 32-40 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 2
ALPHA2/3 32-50 180	180	54	54	44.5	44.5	35.9	103.5	47	G 2
ALPHA2/3 32-50 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 2
ALPHA2/3 32-60 180	180	54	54	44.5	44.5	35.9	103.5	47	G 2
ALPHA2/3 32-60 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 2
ALPHA2/3 32-80 180	180	54	54	44.5	44.5	35.9	103.5	47	G 2
ALPHA2/3 32-80 N 180	180	54	54	44.5	44.5	36.9	103.5	47	G 2

* UK version: ALPHA2 and ALPHA3, 15-50/60 G 1 1/2.

10.3 Dimensions, ALPHA2 and ALPHA3, 25-40 A, 25-60 A

Dimensional sketches and table of dimensions.




Fig. 35 ALPHA2 and ALPHA3, 25-40 A, 25-60 A

TM05 2574 0212

Pump type	Dimensions								
	L1	B1	B2	B3	B4	H1	H2	H3	G
ALPHA2/3 25-40 A 180	180	63.5	98	32	63	50	124	81	G 1 1/2
ALPHA2/3 25-60 A 180	180	63.5	98	32	63	50	124	81	G 1 1/2

11. Performance curves

11.1 Guide to performance curves

Each pump setting has its own performance curve. However, $AUTO_{ADAPT}$ covers a performance range.

A power curve, P1, belongs to each performance curve. The power curve shows the pump power consumption in watt at a given performance curve.

The P1 value corresponds to the value that you can read from the pump display. See fig. 36.




Fig. 36 Performance curves in relation to pump setting

Setting	Pump curve
$AUTO_{ADAPT}$ factory setting	Setpoint within the marked area
PP1	Lowest proportional-pressure curve
PP2	Intermediate proportional-pressure curve
PP3	Highest proportional-pressure curve
CP1	Lowest constant-pressure curve
CP2	Intermediate constant-pressure curve
CP3	Highest constant-pressure curve
III	Constant curve/constant speed III
II	Constant curve/constant speed II
I	Constant curve/constant speed I
	Curve for automatic night setback/manual summer mode

For further information about pump settings, see this section:
[7. Control functions](#)

11.2 Curve conditions

The guidelines below apply to the performance curves on the following pages:

- Test liquid: airless water.
- The curves apply to a density of 83.2 kg/m^3 and a liquid temperature of $60 \text{ }^\circ\text{C}$.
- All curves show average values and must not be used as guarantee curves. If a specific minimum performance is required, individual measurements must be made.
- The curves for speeds I, II and III are marked.
- The curves apply to a kinematic viscosity of $0.474 \text{ mm}^2/\text{s}$ (0.474 cSt).
- The conversion between head H [m] and pressure p [kPa] has been made for water with a density of 1000 kg/m^3 . For liquids with other densities, for example hot water, the outlet pressure is proportional to the density.
- Curves are obtained according to EN 16297.

11.3 Performance curves, ALPHA2 and ALPHA3, XX-40 (N)




Fig. 37 ALPHA2 and ALPHA3, XX-40

Setting	P1 [W]	$I_{1/1}$ [A]
AUTO_{ADAPT}	3-18	0.04 - 0.18
Min.	3	0.04
Max.	18	0.18

TM05 1672 4111

11.4 Performance curves, ALPHA2 and ALPHA3, XX-50 (N)




Fig. 38 ALPHA2 and ALPHA3, XX-50

Setting	P1 [W]	$I_{1/1}$ [A]
AUTO_{ADAPT}	3-26	0.04 - 0.24
Min.	3	0.04
Max.	26	0.24

TM05 1673 4111

11.5 Performance curves, ALPHA2 and ALPHA3, XX-60 (N)




Fig. 39 ALPHA2 and ALPHA3, XX-60

Setting	P1 [W]	$I_{1/1}$ [A]
AUTO _{ADAPT}	3-34	0.04 - 0.32
Min.	3	0.04
Max.	34	0.32

TM05 1674 4111

11.6 Performance curves, ALPHA2 and ALPHA3, 25-40 A




Fig. 40 ALPHA2 and ALPHA3, 25-40 A

Setting	P1 [W]	$I_{1/1}$ [A]
AUTO _{ADAPT}	3-18	0.04 - 0.18
Min.	3	0.04
Max.	18	0.18

TN05 2016 4211

11.7 Performance curves, ALPHA2 and ALPHA3, 25-60 A




Fig. 41 ALPHA2 and ALPHA3, 25-60 A

Setting	P1 [W]	$I_{1/1}$ [A]
AUTO _{ADAPT}	3-34	0.04 - 0.32
Min.	3	0.04
Max.	34	0.32

TM05 2017 4211

11.8 Performance curves, ALPHA2 and ALPHA3, XX-80 (N)




Fig. 42 ALPHA2 and ALPHA3, 25-60 A

Setting	P1 [W]	$I_{1/1}$ [A]
AUTO _{ADAPT}	3-50	0.04 - 0.44
Min.	3	0.04
Max.	50	0.44

TM06 1285 2114

12. Accessories

12.1 Unions and valve kits

		Product numbers, unions													
ALPHA2/3	Connection	Union nut with internal threads			Union nut with external threads		Ball valve with internal threads			Ball valve with compression fitting		Union nut with soldering fitting			
															
15-xx*	G 1	3/4	1	1 1/4	1	1 1/4	3/4	1	1 1/4	∅22	∅28	∅18	∅22	∅28	∅42
15-xx N*	G 1														
25-xx	G 1 1/2	529921	529922	529821	529925	529924									
25-xx N	G 1 1/2	529971	529972				519805	519806	519807	519808	519809	529977	529978	529979	
32-xx	G 2		509921	509922											
32-xx N	G 2			509971											529995

Note: The product numbers are always for one complete set, incl. gaskets.

The product numbers for the very standard sizes are printed in bold.

* When ordering for UK 15-xx versions, use product numbers for 25-xx (G 1 1/2).

G-threads have a cylindrical form in accordance with the EN ISO 228-1 standard and are not sealing the thread. It requires a flat gasket. You can only screw male G-threads (cylindrical) into female G-threads. The G-threads are standard thread on the pump housing.

R-threads are tapered external threads in accordance with the EN 10226-1 standard.

Rc- or Rp-threads are internal threads with either tapered or cylindrical (parallel) threads. You can screw male R-threads (conical) into female Rc- or Rp-threads. See fig. 43.




Fig. 43 G-threads and R-threads

12.2 Insulating shells, ALPHA2, ALPHA3

The pump is supplied with two insulating shells. Type A pumps with air-separating chamber are not supplied with insulating shells. However, you can order insulating shells as an accessory. See table below.

The insulation thickness of the insulating shells corresponds to the nominal diameter of the pump.

The insulating shells, which are tailored to the individual pump type, enclose the entire pump housing. The insulating shells are easy to fit around the pump. See fig. 44.

Pump type	Product number	Available
ALPHA2/3 XX-XX 130	98091786	spare part
ALPHA2/3 XX-XX 180	98091787	spare part
ALPHA2/3 XX-XX A	505822	accessory

TM06 9235 2017



TM06 5822 0216

Fig. 44 Insulating shells

12.3 ALPHA plugs



TM06 5823 0216

Pos.	Description	Product number	Available
1	ALPHA straight plug, standard plug connector, complete	98284561	spare part
2	ALPHA angle plug, standard angle plug connection, complete	98610291	accessory
3	ALPHA plug, 90 ° bend to the left, including 4 m cable	96884669	accessory
*	ALPHA plug, 90 ° bend to the left, including 1 m cable and integrated NTC protection resistor	97844632	accessory

* This special cable with an active built-in NTC protection circuit, reduces possible inrush currents. To be used in case of for instance poor quality of relay components that are sensitive to inrush current.



ALPHA SOLAR cables and plugs can be delivered on request.

12.4 ALPHA Reader



TM06 8574 1517

The ALPHA Reader unit MI401 is the receiver and transmitter of pump performance data. The unit broadcasts the measured data from the pump to an Android or iOS-based mobile device via Bluetooth. The unit uses a small lithium battery.

The unit is together with the Grundfos GO Balance app used for balancing heating system primarily in one- and two-family houses. The app guides you through a number of steps where information on installation and measurements from the pump is being collected. In a two-pipe system or an underfloor heating system, the app calculates the balancing values for each of the valves. On the basis of these values, the app guides you through the adjustment of each presetting valve in the system.

The app is available for both Android and iOS devices, and you can download it free of charge from Google Play and App Store.

Description	Product number
ALPHA reader MI401	98916967

13. ALPHA SOLAR

13.1 Product introduction



TM06 5816 0216

Fig. 45 ALPHA SOLAR pump

The ALPHA SOLAR is designed to be integrated in all kinds of thermal solar systems with either variable or constant flow rate. High-efficiency ECM (Electronically Commutated Motor) pumps, such as ALPHA SOLAR, must not be speed-controlled by an external speed controller varying or pulsing the supply voltage. The speed can be controlled by a low-voltage PWM (Pulse Width Modulation) signal from a solar controller to optimise the solar harvesting and temperature of the system. As a result, the power consumption of the pump will be reduced considerably.


If no PWM signal is available, you can set ALPHA SOLAR to operate at constant speed / constant curve, only switched on and off by the controller.

13.2 Operating the product



13.3 Setting by means of the control panel

The user interface is designed with a single push button, one red and green LED and four yellow LEDs.



TMD06 05335 0414

Fig. 46 User interface with one push button and five LEDs

The user interface shows the following:

- operating status
- alarm status
- settings view, after pressing the button.

13.4 Operating and alarm status

During operation, the display shows the actual operating status or the alarm status.

If the circulator has detected one or more alarms, the LED switches from green to red. When an alarm is active, the LEDs indicate the alarm type as defined in the table in section [13.5 Fault finding the product](#). If multiple alarms are active at the same time, the LEDs only show the error with the highest priority. The priority is defined by the sequence of the table.

When there is no active alarm anymore, the user interface switches back to operating status.

The LEDs indicate the actual operating status or alarm status. See section [13.3 Setting by means of the control panel](#).

This circulator pump is either for internal control with constant-curve control or external PWM-signal control with profile C. See fig. [47](#).




Fig. 47 Operating mode

PWM can only operate if you have set the pump to PWM mode. Press the button five times until only the green LED is on. When you connect the PWM cable, the yellow LEDs are on and you can control the pump via the PWM signal. See fig. 47.

13.5 Fault finding the product

The alarm status is indicated by the LEDs.

Fault	Description
	<p>The rotor is blocked. Deblock the rotor.</p>
	<p>The supply voltage is low. Make sure that there is sufficient voltage supply to the pump.</p>
	<p>Electrical error. Replace the pump and send the pump to the nearest Grundfos service centre.</p>

DANGER

Electric shock

Death or serious personal injury

- Switch off the power supply before starting any work on the product. Make sure that the power supply cannot be accidentally switched on.



CAUTION

Pressurised system

Minor or moderate personal injury

- Before dismantling the pump, drain the system or close the isolating valve on either side of the pump. The pumped liquid may be scalding hot and under high pressure.




14. External PWM control mode and signals

PWM can only operate if you have set the pump to PWM mode. See section 13.4 *Operating and alarm status*.

PWM profile C input signal (solar)

At low PWM signal percentages (duty cycles), a hysteresis prevents the circulator from starting and stopping if the input signal fluctuates around the shifting point. Without PWM signal percentages, the circulator will stop for safety reasons. If a signal is missing, for example due to a cable breakage, the circulator will stop to avoid overheating of the solar thermal system.



TM05 1575 3211

Fig. 48 PWM input profile C

PWM input signal [%]	Pump status
≤ 5	Standby mode: off
> 5 / ≤ 8	Hysteresis area: on/off.
> 8 / ≤ 15	Minimum speed: IN
> 15/90	Variable speed: min. to max.
> 90 / ≤ 100	Maximum speed: max.

Digital low-voltage PWM signal


The square-wave PWM signal is designed for a 100 to 4,000 Hz frequency range. The PWM signal is used to select the speed (speed command) and as feedback signal. The PWM frequency on the feedback signal is fixed at 75 Hz in the circulator.

Duty cycle

$$d \% = 100 \times t/T$$

Example	Rating
T = 2 ms (500 Hz)	$U_{iH} = 4-24 \text{ V}$
t = 0.6 ms	$U_{iL} \leq 1 \text{ V}$
d % = $100 \times 0.6 / 2 = 30 \%$	$I_{iH} \leq 10 \text{ mA}$ (depending on U_{iH})

Example



TM04 9911 0211

Fig. 49 PWM signal

Abbreviation	Description
T	Period of time [sec.]
d	Duty cycle [t/T]
U_{iH}	High-level input voltage
U_{iL}	Low-level input voltage
I_{iH}	High-level input current

15. Digital signal converter

To replace UPS SOLAR with a new ALPHA SOLAR pump which fulfils the ErP requirements, we offer two solutions:

- Exchange the existing SOLAR controller to a controller suitable for high-efficiency pumps.
- Keep the old controller, and use the phase control. Use a signal converter, SIKON HE, which can convert the existing phase control to a PWM signal for the ALPHA SOLAR.

When you use SIKON HE, you can replace the conventional 230 V UPS SOLAR pump with a Grundfos ALPHA SOLAR pump without having to change the controller. The function of the performance control of the pump is maintained.



TM06 5809 0216


Fig. 50 Digital signal converter (SIKON HE)

For further information about the controller, see www.prozeda.de.

16. Technical data

System pressure	Maximum 1.0 MPa (10 bar)
Minimum inlet pressure	0.05 MPa (0.50 bar) at a liquid temperature of 95 °C
Maximum liquid temperature	2-110 °C at an ambient temperature of 70 °C
	2-130 °C at an ambient temperature of 60 °C
Enclosure class	IPX4D
Motor protection	No external protection needed
Approvals and markings	VDE, CE
Water-propylene glycol mixture	Maximum water-propylene glycol mixture is 50 %. Note: The water-propylene glycol mixture reduces the performance due to higher viscosity.

ALPHA SOLAR xx-75 130/180



Setting	Max. head _{nom}
Curve 1	4.5 m
Curve 2	5.5 m
Curve 3	6.5 m
Curve 4	7.5 m

Setting	Max. P ₁ nom
Curve 1	19 W
Curve 2	28 W
Curve 3	35 W
Curve 4	45 W

EEI ≤ 0.20 Part 3
 P_{L,avg} ≤ 20 W

TM06 3658 0815


Fig. 51 Performance curve

Note: PWM speed curves on request.

Electrical data, 1 x 230 V, 50 Hz		
Speed	P ₁ [W]	I _{1/1} [A]
Min.	2*	0.04
Max.	45	0.48

Settings			
PWM C	PP	CP	CC
1	-	-	4

* Only in minimum PWM speed operation




TM06 6493 1516



TM06 5636 5115

Pump type	Dimensions [mm]							Connections	Weight [kg]
	L1	L3	B1	B2	H1	H2	H3		
ALPHA SOLAR 15-75 130	130	90	72	45	36	92	128	G 1	1.8
ALPHA SOLAR 25-75 130	130	90	72	45	36	92	128	G 1 1/2	1.9
ALPHA SOLAR 25-75 180	180	90	72	45	36	92	128	G 1 1/2	2.0

ALPHA SOLAR xx-145/180



Setting	Max. head _{nom}
Curve 1	6.5 m
Curve 2	8.5 m
Curve 3	10.5 m
Curve 4	14.5 m

Setting	Max. P ₁ nom
Curve 1	39 W
Curve 2	45 W
Curve 3	52 W
Curve 4	60 W

EEl ≤ 0.20 Part 3
 P_{L,avg} ≤ 25 W


TM06 3652 0815

Note: PWM speed curves on request.

Electrical data, 1 x 230 V, 50 Hz		
Speed	P ₁ [W]	I _{1/1} [A]
Min.	2*	0.04
Max.	60	0.58

Settings			
PWM C	PP	CP	CC
1	-	-	4

* Only in minimum PWM speed operation



TM06 6493 1516



TM06 5636 5115

Pump type	Dimensions [mm]							Connections	Weight [kg]
	L1	L3	B1	B2	H1	H2	H3		
ALPHA SOLAR 25-145 180	180	90	72	45	25	103	128	G 1 1/2	2.0

17. Disposing of the product

This product has been designed with focus on the disposal and recycling of materials. The following average disposal values apply to all variants of ALPHA2, ALPHA3 and ALPHA SOLAR pumps:

- 92 % recycling
- 3 % incineration
- 5 % depositing.

Dispose of this product or parts of it in an environmentally sound way according to local regulations.

For further information, see the end-of-life information at www.grundfos.com.



The crossed-out wheellie bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local waste disposal

authorities. The separate collection and recycling of such products will help protect the environment and human health.

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Centro
Industrial Garin
1619 Garin Pcia. de B.A.
Phone: +54-3327 414 444
Telefax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Phone: +61-8-8461-4611
Telefax: +61-8-8340 0155

Austria

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Telefax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomssesteenweg 81-83
B-2630 Aartselaar
Tél.: +32-3-870 7300
Télécopie: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в
Минске
220125, Минск
ул. Шафарьянская, 11, оф. 56, БЦ
«Порт»
Тел.: +7 (375 17) 286 39 72/73
Факс: +7 (375 17) 286 39 71
E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A,
BH-71000 Sarajevo
Phone: +387 33 592 480
Telefax: +387 33 590 465
www.ba.grundfos.com
e-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo Branco,
630
CEP 09850 - 300
São Bernardo do Campo - SP
Phone: +55-11 4393 5533
Telefax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztochna Tangenta street no. 100
BG - 1592 Sofia
Tel. +359 2 49 22 200
Fax. +359 2 49 22 201
email: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada Inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Phone: +1-905 829 9533
Telefax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106
PRC
Phone: +86 21 612 252 22
Telefax: +86 21 612 253 33

COLOMBIA

GRUNDFOS Colombia S.A.S.
Km 1.5 vía Siberia-Cota Conj. Potrero
Chico,
Parque Empresarial Arcos de Cota Bod.
1A.
Cota, Cundinamarca
Phone: +57(1)-2913444
Telefax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Phone: +385 1 6595 400
Telefax: +385 1 6595 499
www.hr.grundfos.com

GRUNDFOS Sales Czechia and Slovakia s.r.o.

Čajkovského 21
779 00 Olomouc
Phone: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tlf.: +45-87 50 50 50
Telefax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikuja 1
FI-01360 Vantaa
Phone: +358-(0) 207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tél.: +33-4 74 82 15 15
Télécopie: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Telefax: +49-(0) 211 929 69-3799
e-mail: infoservice@grundfos.de
Service in Deutschland:
e-mail: kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Phone: +0030-210-66 83 400
Telefax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor
Siu Wai Industrial Centre
29-33 Wing Hong Street &
68 King Lam Street, Cheung Sha Wan
Kowloon
Phone: +852-27861706 / 27861741
Telefax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Tópark u. 8
H-2045 Törökbálint,
Phone: +36-23 511 110
Telefax: +36-23 511 111

India

GRUNDFOS Pumps India Private Limited
118 Old Mahabalipuram Road
Thoraiakkam
Chennai 600 096
Phone: +91-44 2496 6800

Indonesia

PT. GRUNDFOS POMPA
Graha Intirub Lt. 2 & 3
Jln. Cililitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Phone: +62 21-469-51900
Telefax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Phone: +353-1-4089 800
Telefax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Telefax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku,
Hamamatsu
431-2103 Japan
Phone: +81 53 428 4760
Telefax: +81 53 428 5005

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Phone: +82-2-5317 600
Telefax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava ielā 60, LV-1035, Rīga,
Tālr.: + 371 714 9640, 7 149 641
Fakss: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam U1/25
Glenmarie Industrial Park
40150 Shah Alam
Selangor
Phone: +60-3-5569 2922
Telefax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México S.A. de
C.V.
Boulevard TLC No. 15
Parque Industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Phone: +52-81-8144 4000
Telefax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Telefax: +31-88-478 6332
E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Phone: +64-9-415 3240
Telefax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tlf.: +47-22 90 47 00
Telefax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznania
PL-62-081 Przeźmierowo
Tel: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 00
Telefax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
Bd. Biruintei, nr 103
Pantelimon county Ilfov
Phone: +40 21 200 4100
Telefax: +40 21 200 4101
E-mail: romania@grundfos.ro

Russia

ООО Грундфос Россия
ул. Школьная, 39-41
Москва, RU-109544, Russia
Тел. (+7) 495 564-88-00 (495) 737-30-00
Факс (+7) 495 564 8811
E-mail grundfos.moscow@grundfos.com

Serbia

Grundfos Srbija d.o.o.
Omladinskih brigada 90b
11070 Novi Beograd
Phone: +381 11 2258 740
Telefax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Phone: +65-6681 9688
Telefax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D
821 09 BRATISLAVA
Phona: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
Leskoškova 9e, 1122 Ljubljana
Phone: +386 (0) 1 568 06 10
Telefax: +386 (0) 1 568 06 19
E-mail: tehnika-si@grundfos.com

South Africa

Grundfos (PTY) Ltd.
16 Lascelles Drive, Meadowbrook Estate
1609 Germiston, Johannesburg
Tel.: (+27) 10 248 6000
Fax: (+27) 10 248 6002
E-mail: lgradidge@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Camino de la Fuentesilla, s/n
E-28110 Algiete (Madrid)
Tel.: +34-91-848 8800
Telefax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunnagårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Telefax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Telefax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Phone: +886-4-2305 0868
Telefax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloe Phrakiat Rama 9 Road,
Dokmai, Pravej, Bangkok 10250
Phone: +66-2-725 8999
Telefax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi,
2. yol 200. Sokak No. 204
41490 Gebze/ Kocaeli
Phone: +90 - 262-679 7979
Telefax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

Бізнес Центр Європа
Столицне шосе, 103
м. Київ, 03131, Україна
Телефон: (+38 044) 237 04 00
Факс.: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone
Dubai
Phone: +971 4 8815 166
Telefax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Phone: +44-1525-850000
Telefax: +44-1525-850011

U.S.A.

GRUNDFOS Pumps Corporation
9300 Loiret Blvd.
Lenexa, Kansas 66219
Phone: +1-913-227-3400
Telefax: +1-913-227-3500

Uzbekistan

Grundfos Tashkent, Uzbekistan The
Representative Office of Grundfos
Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Телефон: (+998) 71 150 3290 / 71 150
3291
Факс: (+998) 71 150 3292

Addresses Revised 15.01.2019

98092353 0719

ECM: 1264550

Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and "be think innovate" are registered trademarks owned by The Grundfos Group. All rights reserved. © 2019 Grundfos Holding A/S, all rights reserved.