

TPE2, TPE2 D, TPE3, TPE3 D

Service instructions



English (GB) Service instructions

Original service instructions.

CONTENTS

	Page
1. Symbols used in this document	2
2. Identification	3
2.1 Nameplate	3
2.2 Type key	3
3. General information	4
4. Torques	4
5. Secondary materials	4
6. Service tools	5
7. Dismantling the pump	5
8. Assembling the pump	6
9. Replacing the sensor with cable	7
10. Replacing the valve flap	7
11. Exploded view	8

Warning



Prior to service work, read these service instructions carefully. Installation and service work must comply with local regulations and accepted codes of good practice.

Observe the safety instructions in the installation and operating instructions for the product.

1. Symbols used in this document



Warning

If these safety instructions are not observed, it may result in personal injury.



Warning

If these instructions are not observed, it may lead to electric shock with consequent risk of serious personal injury or death.




Warning

The surface of the product may be so hot that it may cause burns or personal injury.



Caution If these safety instructions are not observed, it may result in malfunction or damage to the equipment.




Note Notes or instructions that make the job easier and ensure safe operation.

2. Identification

This section shows the nameplate, type key and the codes that can appear in the variant code.

Note As codes can be combined, a code position may contain more than one code (one letter).

2.1 Nameplate



TM06 5005 3715

Fig. 1 Nameplate

Pos. Beskrivelse

1	Pump type
2	Pump model
3	Rated head
4	Rated speed
5	Efficiency
6	Minimum efficiency index
7	Country of production
8	Maximum system pressure Maximum liquid temperature
9	Rated flow rate

2.2 Type key

Code Example

Pump range, electronically speed-controlled pump	TPE3
TPE2 Without built-in sensor	D
TPE3 Built-in differential-pressure and temperature sensor	65
Twin-head pump	-120
Nominal diameter of the inlet and outlet port (DN)	-S
Maximum head [dm]	-A
S Built-in differential-pressure and temperature sensor.	-F
N Without built-in sensor	-A
Code for pump version	-BUBE
A Basic version	
I PN 6 flange	
X Special version	
Code for pipe connection:	
F Code for pipe connection	
Material code:	
A Special version	
I Stainless-steel pump housing and pump head 1.4308	
Code for shaft seal (incl. other plastic and rubber pump parts, except the neck ring)	

3. General information

Position numbers of parts (digits) refer to section [11. Exploded view](#). Position numbers of tools (letters) refer to section [6. Service tools](#).

Electrical parts must only be serviced by Grundfos or an authorised service centre.

Warning

Use personal protective equipment if there is a risk of getting into contact with the pumped liquid.

Observe local regulations.

Always use an antistatic service kit when handling electronic components. This will prevent static electricity from damaging components.

Caution

When unprotected, the component must be placed on the antistatic cloth.



Fig. 2 Antistatic service kit

4. Torques


Pos.	Type	Size	Dimensions [mm]	Torque [Nm]
7a	Pozidriv screw	2	M4 x 6	5
9	Screw	3 mm	M4 x 6	2.5
28	Hexagon head	NV 14	3/8" x 1"	45
67	Nut	NV 13	M8	30
92	Screw for clamp	5 mm	M7 x 60	8
251d	Torx screw	T x 25	M5 x 50	5-6
534a	Torx screw	T x 25	M5 x 10	5

5. Secondary materials

Pos.	Designation	Quantity [kg]	Product number
9	Loctite 243	0.05	V7137215
92	Rocol Sapphire Aqua-Sil	0.05	00RM2924
105	Water	-	-
301a	Rocol Sapphire Aqua-Sil	0.5	00RM2924
531a			

TM05 1590 3211

6. Service tools



Pos.	Designation	For pos.	Further information
A	Screwdriver	7a	PH2
B	Screwdriver	Terminal 23-26	Straight slot, 2.5 mm
C	Screwdriver	534a	Torx 25
		9	2 mm hexagon socket
D+E	Ratchet spanner with socket	28	14 mm
		67	13 mm
		92	5 mm hexagon socket
		18, 215	6 mm hexagon socket
F+G	Torque wrench	-	0-50 Nm
H	Ring/open-end spanner	100	24 mm
I	Mounting bush	105	98467480
J	Punch	105	98467479
		DN 32:	98699493
		DN 40:	98699494
K	Punch	45	DN 50: 98699480
		DN 65:	98699491
		DN 80:	98699492
		DN 100:	
L	Strap wrench	49	

7. Dismantling the pump

Warning

Switch off the power supply and make sure that it cannot be accidentally switched on.



Check that other pumps or sources do not force flow through the pump even if the pump is stopped. This will cause the motor to act like a generator, resulting in voltage on the pump.



Warning

Close the isolating valves, if fitted, and make sure that they cannot be accidentally opened.



Warning

Before starting work any on the product, let the product and pumped liquid cool off.

1. **TPE3, TPE3 D:** Detach the sensor as described in section 9. *Replacing the sensor with cable.*
2. Apply lubricant e.g. Rocol Sapphire Aqua-Sil on the screw for the clamp (92) and loosen the screw.
3. Lift the pump head out of the pump housing (6).
4. Remove the clamp (92).
5. Remove the O-ring (301a).
6. Remove the neck ring (45) and dispose of it. See fig. 3.





Fig. 3 Removal and disposal of the neck ring

7. Hold the impeller (49) with a strap wrench and loosen the impeller nut (67). Remove the impeller nut, washer (66a) and impeller (49) from the shaft.
8. Remove the spacer ring (100) and the rotating shaft seal part (105).
9. Loosen the two pozidriv screws (7a) and remove the coupling guard (7).
10. Loosen the four nuts (28) and remove the motor stool (77).
11. Remove the stationary shaft seal part (105) from the motor stool (77).
12. Loosen the two set screws (9) and remove the shaft (51).
13. Remove the key (11b) from the shaft (51).

8. Assembling the pump

Note Lubricate and tighten screws and nuts according to section [4. Torques](#) and [5. Secondary materials](#).


1. Make sure that the key (11) is fitted correctly on the motor shaft. See fig. 4.



TM06 5006 3715

Fig. 4 Key on motor shaft

2. Push the shaft (51) home on the motor shaft.
3. Apply a drop of Loctite 243 to the set screws (9) and tighten them into the pump shaft. See section [4. Torques](#).
4. Mount the motor stool (77) on the motor.
5. Fit the four nuts (28). See section [4. Torques](#).
6. Spray the stationary shaft seal part (105) with water.
7. Fit the stationary shaft seal part (105) on the shaft. Do not touch the seal face with your fingers.
8. Press the stationary shaft seal part home with a punch (J).
9. Fit the mounting bush (I) on the pump shaft.
10. Spray the rotating shaft seal part (105) with water.
11. Press the rotating shaft seal part home with a punch (J).
12. Remove the mounting bush (I).
13. Fit the spacer ring (100) on the pump shaft (51).
14. Fit the key (11b) and impeller (49) on the pump shaft (51).
15. Fit the washer (66a) and impeller nut (67).
16. Hold the impeller (49) with a strap wrench (L) and tighten the impeller nut (67). See section [4. Torques](#).
17. Fit a new neck ring (45) with the punch (K). See fig. 5.




TM06 1585 2714

Fig. 5 Fitting a neck ring

18. Clean the sealing face and the neck ring on the pump housing. The sealing face must be free of corrosion or deposits and have a uniformly smooth surface.
19. Lubricate the sealing face of the pump head.
20. Fit the O-ring (301a) in the pump head and lubricate it.
21. Fit the clamp (92) on the pump house without tightening it.

22. Make sure that the movable part of the neck ring is centred in the stationary part. See fig. 6.



TM06 1580 2614


Fig. 6 Centring of neck ring

23. Fit the pump head in the pump housing.

Note: Check that the pump head is home. There must be no gap between the contact surfaces of pump housing and pump head.

24. Apply lubricant e.g. Rocol Sapphire Aqua-Sil on the screw for the clamp (92) and loosen the screw.

Note: Make sure that the clamp is fastened correctly around the flange recesses on the pump head and pump housing. See fig. 7 and section [4. Torques](#).



TM06 1584 2714

Fig. 7 Fitting the clamp

25. Check that the pump shaft can rotate freely.

26. Fit the coupling guards (7) and tighten the pozidriv screws (7a). See section [4. Torques](#).

27. **TPE3, TPE3 D:** Connect the sensors as described in section [9. Replacing the sensor with cable](#).

Note If analog or digital inputs, the relay output or the CIM module has been removed from the pump, check the communication with external units after service.

9. Replacing the sensor with cable

The instruction below only applies to TPE3 and TPE3 D pumps.

Removing the sensor

1. Disconnect the power supply.
 2. Loosen the four screws (251d) and remove the cover of the terminal box (251a).
 3. Remove the sensor wires from terminals 23, 24, 25 and 26.
 4. Turn the union nut (530a) counter-clockwise until it is free. Make sure not to turn the sensor cable at the same time.
 5. Pull the sensor cable (530) out of the terminal box via the cable gland.
 6. Remove the screw (534a) and pull the cable clamp (534) to the right.
 7. Hold the sensor (531) by its sides and move it carefully from side to side to remove it from the pump housing.
- Note:** Check that the sensor pocket (531a) comes out of the hole in the pump housing.
8. Clean the sensor hole with a clean piece of cloth and check that there are no particles in the sensor hole. See fig. 8.




Fig. 8 Cleaning the sensor hole

Fitting the sensor

1. Fit the new sensor and push it carefully home. The nose of the sensor must face downwards. See fig. 9.




Fig. 9 Correct fitting of sensor

2. Fit the bracket from the right to the left.
3. Fit the earth conductor on the bracket and secure the bracket to the pump housing with the screw (534a). See section [4. Torques](#).
4. Lead the sensor cable into the terminal box via the cable gland.
5. Connect the sensor wires to terminals 23, 24, 25 and 26.

Terminal	26	23	25	24
Colour of wire	Brown	Silver	Yellow	White

6. Fit and tighten the impeller (530a) clockwise. Make sure not to turn the sensor cable at the same time.
7. Fit the cover of the terminal box (251a) and tighten the screws (251d). See section [4. Torques](#).

If analog or digital inputs, the relay output or the CIM module has been removed from the pump, check the communication with external units after service.

10. Replacing the valve flap

The instruction below only applies to TPE2 D and TPE3 D pumps.

Removal of valve flap

1. Remove the screws (215a).
2. Push the pin (215) out.
3. Remove the valve flap (217).

Fitting the valve flap

1. Insert the new valve flap (217).
2. Insert the pin (215).
3. Fit and tighten the screws (215a). See section [4. Torques](#) and [5. Secondary materials](#).

11. Exploded view




Fig. 10 TPE2, TPE2 D, TPE3, TPE3 D

TM05 8625 3715

Subject to alterations.

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Centro
Industrial Garin
1619 Garin Pcia. de B.A.
Phone: +54-3327 414 444
Telefax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Phone: +61-8-8461-4611
Telefax: +61-8-8340 0155

Austria

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Telefax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomsesteenweg 81-83
B-2630 Aartselaar
Tél.: +32-3-870 7300
Télécopie: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в
Минске
220125, Минск
ул. Шаффаринская, 11, оф. 56, БЦ
«Порт»
Тел.: +7 (375 17) 286 39 72/73
Факс: +7 (375 17) 286 39 71
E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A,
BH-71000 Sarajevo
Phone: +387 33 592 480
Telefax: +387 33 590 465
www.ba.grundfos.com
e-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo Branco,
630
CEP 09850 - 300
São Bernardo do Campo - SP
Phone: +55-11 4393 5533
Telefax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztochna Tangenta street no. 100
BG - 1592 Sofia
Tel.: +359 2 49 22 200
Fax. +359 2 49 22 201
email: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada Inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Phone: +1-905 829 9533
Telefax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106
PRC
Phone: +86 21 612 252 22
Telefax: +86 21 612 253 33

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Phone: +385 1 6595 400
Telefax: +385 1 6595 499
www.hr.grundfos.com

Czech Republic

GRUNDFOS s.r.o.
Čajkovského 21
779 00 Olomouc
Phone: +420-585-716 111
Telefax: +420-585-716 299

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tlf.: +45-87 50 50 50
Telefax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumpum AB
Trukkikuja 1
FI-01360 Vantaa
Phone: +358-(0) 207 889 500
Telefax: +358-(0) 207 889 550

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tél.: +33-4 74 82 15 15
Télécopie: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Telefax: +49-(0) 211 929 69-3799
e-mail: infoservice@grundfos.de
Service in Deutschland:
e-mail: kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Phone: +0030-210-66 83 400
Telefax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor
Siu Wai Industrial Centre
29-33 Wing Hong Street &
68 King Lam Street, Cheung Sha Wan
Kowloon
Phone: +852-27861706 / 27861741
Telefax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Park u. 8
H-2045 Törökpalánk,
Phone: +36-23 511 110
Telefax: +36-23 511 111

India

GRUNDFOS Pumps India Private Limited
118 Old Mahabalipuram Road
Thoraipakkam
Chennai 600 096
Phone: +91-44 2496 6800

Indonesia

PT. GRUNDFOS POMPA
Graha Intirub Lt. 2 & 3
Jln. Ciliilitan Besar No.454, Makasar,
Jakarta Timur
ID-Jakarta 13650
Phone: +62 21-469-51900
Telefax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Phone: +353-1-4089 800
Telefax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Telefax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
Gotanda Metalion Bldg., 5F,
5-21-15, Higashi-gotanda
Shiagawa-ku, Tokyo
141-0022 Japan
Phone: +81 35 448 1391
Telefax: +81 35 448 9619

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Phone: +82-2-5317 600
Telefax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava ielā 60, LV-1035, Riga,
Tāl.: +371 714 9640, 7 149 641
Fakss: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguan U1/25
Glenmarie Industrial Park
40150 Shah Alam
Selangor
Phone: +60-3-5569 2922
Telefax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México S.A. de
C.V.
Boulevard TLC No. 15
Parque Industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Phone: +52-81-8144 4000
Telefax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwemeer 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Telefax: +31-88-478 6332
E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Phone: +64-9-415 3240
Telefax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tlf.: +47-22 90 47 00
Telefax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznańia
PL-62-081 Przeźmierowo
Tel: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 90
Telefax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
Bd. Biruinței, nr 103
Pantelimon county Ilfov
Phone: +40 21 200 4100
Telefax: +40 21 200 4101
E-mail: romania@grundfos.ro

Russia

ООО Грундфос Россия
109544, г. Москва, ул. Школьная, 39-41,
стр. 1
Тел. (+7) 495 564-88-00 (495) 737-30-00
Факс (+7) 495 564 88 11
E-mail grundfos.moscow@grundfos.com

Serbia

Grundfos Srbija d.o.o.
Omladinskih brigada 90b
11070 Novi Beograd
Phone: +381 11 2258 740
Telefax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Phone: +65-6681 9688
Telefax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D
821 09 BRATISLAVA
Phona: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS d.o.o.
Šländrova 8b, SI-1231 Ljubljana-Črnuče
Phone: +386 31 718 808
Telefax: +386 (01) 5680 619
E-mail: slovenia@grundfos.si

South Africa

GRUNDFOS (PTY) LTD
Corner Mountjoy and George Allen Roads
Wilbart Ext. 2
Bedfordview 2008
Phone: (+27) 11 579 4800
Fax: (+27) 11 455 6066
E-mail: lsmart@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Camino de la Fuentecilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Telefax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunnagårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Telefax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Telefax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Phone: +886-4-2305 0868
Telefax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloem Phra Khan Rama 9 Road,
Dokmai, Pravej, Bangkok 10250
Phone: +66-2-725 8999

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi,
2, yol 200, Sokak No. 204
41490 Gebze/Kocaeli
Phone: +90 - 262-679 7979
Telefax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

Бізнес Центр Європа
Столичне шосе, 103
м. Київ, 03131, Україна
Телефон: (+38 044) 237 04 00
Факс: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone
Dubai
Phone: +971 4 8815 166
Telefax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Phone: +44-1525-850000
Telefax: +44-1525-850011

U.S.A.

GRUNDFOS Pumps Corporation
17100 West 118th Terrace
Olathe, Kansas 66061
Phone: +1-913-227-3400
Telefax: +1-913-227-3500

Uzbekistan

Grundfos Tashkent, Uzbekistan The Representative Office of Grundfos Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Телефон: (+998) 71 150 3290 / 71 150 3291
Факс: (+998) 71 150 3292

Addresses Revised 29.09.2015

be think innovate

98991089 1015

ECM: 1168304

www.grundfos.com

GRUNDFOS 

© Copyright Grundfos Holding A/S

The name Grundfos, the Grundfos logo, and be think innovate are registered trademarks owned by Grundfos Holding A/S or Grundfos A/S, Denmark. All rights reserved worldwide.