


TPE2 (D), TPE3 (D)

Installation and operating instructions



TPE2 (D), TPE3 (D)
Installation and operating instructions
Other languages
<http://net.grundfos.com/qr/i/98450210>

TPE2 (D), TPE3 (D)

English (GB)

Installation and operating instructions	4
---	---

English (GB) Installation and operating instructions

Original installation and operating instructions

Table of contents

1. General information	5	11.3 Liquid temperature	26
2. Symbols used in this document	5	11.4 Ambient temperature	27
3. Abbreviations and definitions	6	11.5 Operating pressure or test pressure	27
4. General information	7	11.6 Inlet pressure	27
4.1 Nameplate	7	11.7 Electrical data	27
4.2 Type key	8	11.8 Sound pressure level	27
5. General description	10	11.9 Environment	27
5.1 Radio communication	10	11.10 Installation altitude	27
5.2 Battery	10	11.11 Humidity	28
6. Receiving the product	10	11.12 Motor cooling	28
6.1 Delivery	10	12. User interfaces	28
6.2 Transporting the product	10	13. Standard control panel	29
6.3 Inspecting the product	10	13.1 Setpoint setting	30
6.4 Handling the product	10	14. Advanced control panel	32
7. Applications	11	15. Home display	33
7.1 Pumped liquids	11	15.1 Start-up guide	33
8. Mechanical installation	12	15.2 Menu overview for advanced control panel	34
8.1 Pipes	13	16. Grundfos GO	38
8.2 Terminal box positions	14	16.1 Communication	38
8.3 Fitting of pump head	15	16.2 Menu overview for Grundfos GO main menus	39
8.4 Base plate	16	17. Description of functions	42
8.5 Insulation	16	17.1 Heat energy monitor	42
8.6 Frost protection	16	17.2 Setpoint	42
8.7 Cable entries	16	17.3 Operating mode	42
8.8 Ensuring motor cooling	17	17.4 Set manual speed	43
8.9 Outdoor installation	17	17.5 User-defined speed	43
9. Electrical connection	18	17.6 Control mode	43
9.1 Protection against electric shock, indirect contact	18	17.7 Proportional-pressure setup	51
9.2 Cable requirements	18	17.8 FLOWLIMIT	51
9.3 Mains supply	19	17.9 Automatic Night Setback	52
9.4 Additional protection	20	17.10 Analog inputs	52
9.5 Connection terminals	21	17.11 Built-in Grundfos sensor	54
9.6 Signal cables	24	17.12 Pt100/1000 inputs	54
9.7 Bus connection cable	24	17.13 Digital inputs	55
10. Startup	25	17.14 Digital inputs/outputs	57
10.1 Flushing the pipe system	25	17.15 "Signal relays 1 and 2" (Relay outputs)	59
10.2 Priming the pump	25	17.16 Analog output	59
10.3 Starting the pump	25	17.17 Controller (Controller settings)	60
10.4 Shaft seal run-in	25	17.18 Operating range	62
11. Operating conditions	26	17.19 External setpoint function	63
11.1 Maximum number of starts and stops	26	17.20 Predefined setpoints	65
11.2 Alternating operation of twin-head pumps	26	17.21 Temperature influence	66
		17.22 Limit-exceeded function	67
		17.23 Pulse flowmeter setup	68
		17.24 Ramps	69
		17.25 Standstill heating	69

17.26	Motor bearing monitoring	70	29.3	Occasional motor alarm	94
17.27	Service	70	29.4	No motor alarm, but the pump does not run	94
17.28	Number (Pump number)	71	29.5	The pump performance is not constant	94
17.29	Radio communication (Enable/disable radio comm.)	71	29.6	The pump runs but delivers no water	95
17.30	Language	71	29.7	The pump runs backwards when switched off	95
17.31	Date and time (Set date and time)	71	29.8	Leakage in shaft seal	95
17.32	Unit configuration (Units)	71	29.9	Noise	95
17.33	"Buttons on product" (Enable/disable settings)	72	30. Megging	96	
17.34	Delete history	72	31. Technical data, single-phase motors	96	
17.35	Define Home display	72	31.1	Supply voltage	96
17.36	Display settings	72	31.2	Leakage current.	96
17.37	Store settings (Store actual settings).	72	32. Technical data, three-phase motors	96	
17.38	Recall settings (Recall stored settings).	73	32.1	Supply voltage	96
17.39	Undo	73	32.2	Leakage current, AC	96
17.40	Pump name	73	33. Inputs and outputs	97	
17.41	Connection code	73	34. Other technical data.	98	
17.42	Run start-up guide	74	34.1	Torques	99
17.43	Alarm log	74	34.2	Sound pressure level	99
17.44	Warning log	74	35. Factory settings	100	
17.45	Assist	74	36. Disposing of the product	101	
17.46	Assisted pump setup	75			
17.47	Setup, analog input	75			
17.48	Setting of date and time	76			
17.49	Multipump setup (Setup of multi-pump system)	76			
17.50	Description of control mode	79			
17.51	Assisted fault advice	79			
18.	Selecting control mode	80			
19.	Bus signal	82			
20.	Priority of settings.	83			
21.	Grundfos Eye	84			
22.	Signal relays	86			
23.	Installing a communication interface module	87			
24.	Identification of functional module	89			
25.	Identification of control panel	90			
26.	Changing the position of the control panel	91			
27.	Servicing the product	92			
27.1	Maintenance	92			
27.2	Service	92			
28.	Cleaning the product	93			
29.	Fault finding	94			
29.1	The motor does not run when started	94			
29.2	Motor alarm when the power supply is switched on	94			

1. General information



Read this document before you install the product. Installation and operation must comply with local regulations and accepted codes of good practice.

2. Symbols used in this document



DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The text accompanying the three hazard symbols DANGER, WARNING and CAUTION is structured in the following way:

**SIGNAL WORD****Description of the hazard**

- Consequence of ignoring the warning
- Action to avoid the hazard.



Tips and advice that make the work easier.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.

3. Abbreviations and definitions

AI	Analog input
AL	Alarm, out of range at lower limit
AO	Analog output
AU	Alarm, out of range at upper limit
CIM	Communication interface module
Current sinking	The ability to draw current into the terminal and guide it towards earth in the internal circuitry.
Current sourcing	The ability to push current out of the terminal and into an external load which must return it to earth.
DI	Digital input
DO	Digital output
ELCB	Earth-leakage circuit breaker
FM	Functional module
GDS	Grundfos Digital Sensor Factory-fitted sensor in some Grundfos pumps
GENibus	Proprietary Grundfos fieldbus standard
GFCI	Ground fault circuit interrupter USA and Canada
GND	Earth


Grundfos Eye	Status indicator light
LIVE	Low voltage with the risk of electric shock if the terminals are touched
OC	Open collector: Configurable open-collector output
PE	Protective earth
PELV	Protective extra-low voltage A voltage that cannot exceed ELV under normal conditions and under single-fault conditions, except earth faults in other circuits.
RCD	Residual-current device
SELV	Safety extra-low voltage A voltage that cannot exceed ELV under normal conditions and under single-fault conditions, including earth faults in other circuits.
TPE2	Single-head pump without factory-fitted differential-pressure and temperature sensor
TPE2 D	Twin-head pump without factory-fitted differential-pressure and temperature sensor
TPE3	Single-head pump with factory-fitted differential-pressure and temperature sensor
TPE3 D	Twin-head pump with factory-fitted differential-pressure and temperature sensor

4. General information

These installation and operating instructions apply to the Grundfos TPE2, TPE2 D and TPE3, TPE3 D pumps.

The pumps are fitted with frequency-controlled permanent-magnet motors for single-phase or three-phase mains connection.

4.1 Nameplate



TM083495

Example of nameplate

Pos.	Description
1	Type designation
2	Identification code
	92811427 Product number
	10000001 Serial number
	P1 Production site code
	2243 Production year and week (YYWW)
	A Service model
3	Nominal flow rate
4	Pressure rating and maximum temperature
5	Actual impeller diameter
6	Country of origin
7	Nominal pump head
	WRAS approval or Pump Energy Index (PEI)
8	PEI _{CL} : constant load PEI _{VL} : variable load
9	Rated pump speed
10	Hydraulic efficiency at best efficiency point
11	Minimum efficiency index
12	Frequency

4.2 Type key

Example: TPE3 D 65-120 S-A-F-A-BQQE-FAB

Code	Type	Explanation
TPE3		Pump range, electronically speed-controlled pump
	TPE2	Without built-in sensor
	TPE3	Built-in differential-pressure and temperature sensor
D		Twin-head pump
		Nominal diameter of inlet and outlet ports [mm]
65		Maximum head [decimeters (dm)]
-120	S	Built-in differential-pressure and temperature sensor
S	N	Without built-in sensor
		Code for pump version:
-A	A	Basic version
	I	PN 6 flange
	X	Special version
		Code for pipe connection:
	F	DIN flange
		Code for materials:
	A	Basic version
	I	Stainless steel 1.4308 pump housing and motor stool
-BQQE		Code for shaft seal including other plastic and rubber pump parts, except the neck ring
		Code for NEMA motors [kW (hp)]:
	C	0.25 (0.33)
	D	0.37 (0.5)
	E	0.55 (0.75)
	F	0.75 (1)
	G	1.1 (1.5)
	H	1.5 (2)
	I	2.2 (3)
		Code for phase & voltage and other information:
	A	1 x 200-240 V
	B	3 x 200-240 V
	C	3 x 440-480 V
	D	3 x 380-500 V
	W	Not for sale in North America
	Y	Out of DOE scope (department of energy)
		Code for speed variant [rpm]:
B		

Code	Type	Explanation
	A	1450-2200
	B	2900-4000
	C	4000-5900

4.2.1 Codes for shaft seal

Example: BQQE

Code	Type	Explanation
		Grundfos type designation
B	A	O-ring seal with fixed seal driver
	B	Rubber bellows seal
	D	O-ring seal, balanced
	G	Bellows seal with reduced seal faces
	R	O-ring seal with reduced seal faces
		Material of rotating face
Q	A	Carbon, antimony-impregnated
	B	Carbon, resin-impregnated
	Q	Silicon carbide
		Material of stationary seat
Q	B	Carbon, resin-impregnated
	Q	Silicon carbide
	U	Tungsten carbide
		Material of secondary seal
E	E	EPDM
	P	NBR rubber
	V	FKM
	F	FXM

5. General description

The pumps are fitted with frequency-controlled permanent-magnet motors for single-phase or three-phase mains connection.

5.1 Radio communication

This product incorporates a radio module for remote control which is a class 1 device and can be used anywhere in the EU member states without restrictions.

For use in USA and Canada, see section Installation in the USA and Canada.

Some variants of the product and products sold in China and Korea have no radio module.

This product can communicate with Grundfos GO and other products of the same type via the built-in radio module.

In some cases, an external antenna may be required. Only Grundfos-approved external antennas may be connected to this product, and only by a Grundfos-approved installer.

5.2 Battery

DANGER

Intoxication or risk of chemical burn

Death or serious personal injury



- The battery can cause severe or fatal injuries in 2 hours or less if it is swallowed or placed inside any part of the body. In such an event, seek medical attention immediately.

- The replacement or servicing of batteries must be carried out by a qualified person.
- The battery contained within this product, whether new or used, is hazardous and is to be kept away from children.



Pumps with the advanced functional module, FM 300, incorporate a Li-ion battery. The Li-ion battery complies with the Battery Directive (2006/66/EC). The battery does not contain mercury, lead and cadmium.

6. Receiving the product

6.1 Delivery

The pump is delivered from the factory in a carton with a wooden bottom, specially designed for transport by fork-lift truck or a similar vehicle.

6.2 Transporting the product

WARNING

Falling objects

Death or serious personal injury



- Secure the product during transportation to prevent it from tilting or falling down.

CAUTION

Crushing of feet

Minor or moderate personal injury



- Wear safety shoes when moving the product.

6.3 Inspecting the product

Before you install the product, do the following:

1. Check that the product is as ordered.
2. Check that no visible parts have been damaged.

If parts are damaged or missing, contact your local Grundfos sales company.

6.4 Handling the product

Observe local regulations setting limits for manual lifting or handling. The motor weight is stated on the nameplate.

CAUTION

Back injury

Minor or moderate personal injury



- Use lifting equipment.

CAUTION

Crushing of feet

Minor or moderate personal injury




- Wear safety shoes and attach lifting equipment to the motor eyebolts when handling the product.




Do not lift the product by the terminal box.

Lift the pump by means of nylon straps. See figures TPE2, TPE3 and TPE2 D, TPE3 D.



TPE2, TPE3



TPE2 D, TPE3 D

TM057914

TM057915

7. Applications

The pumps are designed to circulate hot or cold water in residential, institutional and industrial applications:

- heating systems
- district heating plants
- central heating systems for blocks of flats
- air-conditioning systems
- cooling systems.

In addition, the pumps are used for liquid transfer and water supply in for instance:

- washing systems
- domestic hot-water systems
- industrial systems in general.

To ensure optimum operation, the dimensioning range of the system must fall within the performance range of the pump.

7.1 Pumped liquids

WARNING

Contact with hazardous liquids

Death or serious personal injury



- If the pump is used for a liquid which is injurious to health, it will be classified as contaminated. In such cases, take proper precautions to avoid injury to health when operating or working on the pump.
- Wear personal protection equipment.

The pump is suitable for thin, clean, non-aggressive and non-flammable liquids, not containing solid particles or fibres that may attack the pump mechanically or chemically.

Examples:

- Central heating system water. The water must meet the requirements of accepted standards on water quality in heating systems.
- Cooling liquids.
- Domestic hot water.
- Industrial liquids.
- Softened water.

The pumping of liquids with a density and/or kinematic viscosity higher than that of water will have the following effects:

- a considerable pressure drop
- a drop in hydraulic performance
- a rise in power consumption.

In such cases, fit the pump with a bigger motor. If in doubt, contact Grundfos.

The EPDM O-rings fitted as standard are primarily suitable for water.

If the water contains mineral or synthetic oils or chemicals or if other liquids than water are pumped, chose the O-rings accordingly.

8. Mechanical installation



WARNING

Hot or cold surface

Death or serious personal injury




- Make sure that no one can accidentally come into contact with hot or cold surfaces.



In order to maintain the UL mark, additional requirements apply to the equipment. See section Installation in the USA and Canada.

Install the pump in a dry well-ventilated, but frost-free position.

When installing pumps with oval bolt holes in the pump flange, PN 6/10, use washers as shown in the figure below.



TM010683

Use of washers for oval bolt holes

Pos.	Description
1	Washer
2	Installation
3	Pump


Arrows on the pump housing show the direction of flow of liquid through the pump.

You can install the pump in horizontal or vertical pipes.



The motor must never fall below the horizontal plane.

For inspection and removal of motor or pump head, a clearance of 300 mm is required above the motor. See the figure below.




TM057916

Required clearance above the motor

Twin-head pumps installed in horizontal pipes must be fitted with an automatic air vent in the upper part of the pump housing. See the figure below.


The automatic air vent is not supplied with the pump.



TM057983

Automatic air vent

If the liquid temperature falls below the ambient temperature, condensation may form in the motor during standstill. In this case, make sure that one of the drain holes in the motor flange is open and points downwards. See the figure below.



TM057917

Drain hole in motor flange

If twin-head pumps are used for pumping liquids with a temperature below 0 °C (32 °F), condensed water may freeze and cause the coupling to get stuck. You can solve the problem by installing heating elements. Whenever possible, install the pump with the motor shaft in horizontal position. See figure Automatic air vent.



Observe the conditions in section Operating conditions.

8.1 Pipes

Fit isolating valves on either side of the pump to avoid draining the system if the pump needs to be cleaned or repaired.

The pump is suitable for pipeline mounting, provided that the pipes are adequately supported on either side of the pump.

Single-head pumps are designed for pipeline mounting only.


Twin-head pumps are prepared for installation on a mounting bracket or base plate.

When installing the pipes, make sure that the pump housing is not stressed by the pipes.

The inlet and outlet pipes must be of an adequate size, taking the pump inlet pressure into account.

To avoid sediment build-up, do not fit the pump at the lowest point of the system.

Install the pipes so that air locks are avoided, especially on the inlet side of the pump.



TM002263

Correct pipes on the inlet side of the pump



The pump must not run against a closed outlet valve as this will cause an increase in temperature or formation of steam in the pump, which may cause damage to the pump.

If there is any risk of the pump running against a closed outlet valve, ensure a minimum liquid flow through the pump by connecting a bypass or a drain to the outlet pipe. The drain can for instance be connected to a tank. A minimum flow rate of 10 % of the flow rate at maximum efficiency is needed at all times.

Flow rate and head at maximum efficiency are stated on the pump nameplate.

8.2 Terminal box positions

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before you make any connections in the terminal box. Make sure that the power supply cannot be accidentally switched on.

WARNING

Hazardous liquids

Death or serious personal injury



- If the pump is used for a liquid which is injurious to health, it will be classified as contaminated. In such cases, take proper precautions to avoid injury to health when operating or working on the pump.
- Wear personal protection equipment.

WARNING

Falling objects

Death or serious personal injury



- If the pump head has been lifted partly or completely from the pump housing, pay special attention when fitting the pump head again.

CAUTION

Crushing of feet

Minor or moderate personal injury



- Wear safety shoes.
- Pay special attention to any escaping vapour when loosening the clamp. See figure Clamp (A).

WARNING

Pressurised system


Death or serious personal injury



- Pay special attention to any escaping vapour when loosening the clamp. See figure Clamp (A).
- Wear personal protection equipment.

You can turn the terminal box to any position. Change the terminal box position as follows:

1. Loosen the clamp securing the pump head to the pump housing.




TM060721

Clamp (A)

2. Turn the pump head to the required position.
3. Check the following before you tighten the clamp:
 - The contact face of the pump housing and that of the pump head must be in full contact.
 - The clamp must be positioned correctly in the flange recess of both the pump head and the pump housing.

Torque: 8 Nm (± 1 Nm).



TM060724

Related information

[5.2 Battery](#)

[8.3 Fitting of pump head](#)

8.3 Fitting of pump head

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before you make any connections in the terminal box. Make sure that the power supply cannot be accidentally switched on.

WARNING

Falling objects

Death or serious personal injury



- If the pump head has been lifted partly or completely from the pump housing, pay special attention when fitting the pump head again.

CAUTION

Crushing of feet

Minor or moderate personal injury



- Wear safety shoes.
- Pay special attention that the pump head does not fall down when loosening the clamp. See figure Clamp (A).

WARNING

Pressurised system


Death or serious personal injury



- Pay special attention to any escaping vapour when loosening the clamp. See figure Clamp (A).
- Wear personal protection equipment.

If for some reason the pump head has been lifted from the pump housing, follow the following procedure in order to mount the pump head correctly:


1. Visually check that the neck ring is centred in the pump housing.



TM060722

Centring of neck ring

2. Gently lower the pump head with rotor shaft and impeller into the pump housing.




TM060723

Lowering of pump head

3. Check the following before you tighten the clamp:
 - The contact face of the pump housing and that of the pump head must be in full contact.
 - The clamp must be positioned correctly in the flange recess of both the pump head and the pump housing.

Torque: 8 Nm (\pm 1 Nm).



TM060724

Positioning of clamp ring

Related information

5.2 Battery

8.4 Base plate


Twin-head pumps have tapped holes in the bottom of the pump housing. You can use the holes for mounting a base plate.

8.5 Insulation



Do not insulate the motor stool as this will trap any vapour escaping from the shaft seal, thus causing corrosion. Covering the motor stool with insulation will also make inspection and service difficult.

Follow the guidelines in figure below when insulating the pump.



TM057918

Insulation of TPE2, TPE3 pumps

Pos.	Description
A	Without insulation
B	Correct insulation
C	Incorrect insulation

8.6 Frost protection

Drain pumps which are not being used during periods of frost to avoid damage.

8.7 Cable entries


See the size of the cable entries in the section on other technical data.

Related information

34. Other technical data

8.8 Ensuring motor cooling

Leave at least 50 mm between the end of the fan cover and a wall or other fixed objects.



TM055236

Minimum distance, D, from the motor to a wall or other fixed objects


8.9 Outdoor installation

If you install the motor outdoors, provide the motor with a cover and open the drain holes to avoid condensation on the electronic components. See figure Examples of covers, not supplied by Grundfos.



When fitting a cover to the motor, observe the guidelines in section Ensuring motor cooling.

The cover must be sufficiently large to ensure that the motor is not exposed to direct sunlight, rain or snow. Grundfos does not supply covers. We therefore recommend that you have a cover built for the specific application. In areas with high humidity, we recommend that you connect the motor permanently to the mains supply and activate the built-in standstill heating function. See section Standstill heating.



TM053496

Examples of covers, not supplied by Grundfos



In order to maintain the UL mark, additional requirements apply to the equipment. See section Installation in the USA and Canada.

Related information

[17.25 Standstill heating](#)

9. Electrical connection

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before you make any connections in the terminal box. Make sure that the power supply cannot be switched on accidentally.

DANGER

Electric shock

Death or serious personal injury



- Check that the supply voltage and frequency correspond to the values stated on the nameplate.

If the power cable is damaged, it must be replaced by the manufacturer, the manufacturer's service partner or a similarly qualified person.

The user or the installer is responsible for correct earthing and protection according to local regulations. All operations must be carried out by a qualified electrician.

9.1 Protection against electric shock, indirect contact

WARNING

Electric shock

Death or serious personal injury



- Connect the motor to protective earth and provide protection against indirect contact in accordance with local regulations.

Protective earth conductors must always have a yellow and green, PE, or yellow, green and blue, PEN, colour marking.

9.1.1 Protection against mains voltage transients

The motor is protected against mains voltage transients in accordance with EN 61800-3.

9.1.2 Motor protection

The motor requires no external motor protection. The motor incorporates thermal protection against slow overloading and blocking.

9.2 Cable requirements

9.2.1 Cable cross-section

DANGER

Electric shock

Death or serious personal injury



- Always comply with local regulations as to cable cross-sections.

1 x 200-230 V

Power [kW]	Conductor type	Cross section	
		[mm ²]	[AWG]
0.25 - 1.5	Solid	1.5 - 2.5	16-12
	Stranded	1.5 - 2.5	16-12

3 x 380-500 V

Power [kW]	Conductor type	Cross section	
		[mm ²]	[AWG]
0.25 - 2.2	Solid	1.5 - 10	16-8
	Stranded	1.5 - 10	16-8
3.0 - 11	Solid	2.5 - 10	14-8
	Stranded	2.5 - 10	14-8

3 x 200-240 V

Power [kW]	Conductor type	Cross section	
		[mm ²]	[AWG]
1.1 - 1.5	Solid	1.5 - 10	16-8
	Stranded	1.5 - 10	16-8
2.2 - 5.5	Solid	2.5 - 10	14-8
	Stranded	2.5 - 10	14-8

9.2.2 Conductors

Type

Stranded or solid copper conductors.

Temperature rating

Temperature rating for conductor insulation: 60 °C (140 °F).

Temperature rating for outer cable sheath: 75 °C (167 °F).

9.3 Mains supply



DANGER

Electric shock

Death or serious personal injury

- Use the recommended fuse size. See section Supply voltage.

Related information

[31.1 Supply voltage](#)

[32.1 Supply voltage](#)

9.3.1 Single-phase supply voltage

- 1 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.


Check that the supply voltage and frequency correspond to the values stated on the nameplate.



If you want to supply the motor through an IT network, make sure that you have a suitable motor variant. If you are in doubt, contact Grundfos.


The wires in the motor terminal box must be as short as possible. Excepted from this is the separated earth conductor which must be so long that it is the last one to be disconnected in case the cable is inadvertently pulled out of the cable entry.

For maximum backup fuse, see section Supply voltage.



TM054034

Example of a mains-connected motor with mains switch, backup fuse and additional protection



Mains connection, single-phase motors

Related information

[31.1 Supply voltage](#)

TM053494

Pos.	Description
1	RCD, type B

9.3.2 Three-phase supply voltage

Three-phase motors are available for the voltages below:

- 3 x 380-500 V - 10 %/+ 10 %, 50/60 Hz, PE
- 3 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

The wires in the motor terminal box must be as short as possible. Excepted from this is the separated earth conductor which must be so long that it is the last one to be disconnected in case the cable is inadvertently pulled out of the cable entry.

In order to avoid loose connections, ensure that the terminal block for L1, L2 and L3 is pressed home in its socket when the supply cable has been connected.

For maximum backup fuse, see section Supply voltage.




If you want to supply the motor through an IT network, make sure that you have a suitable motor variant. If you are in doubt, contact Grundfos.

Only the following motors can be supplied through an IT network:

- Motors with speed of 1450-2000/2200 rpm and up to 1.5 kW
- Motors with speed of 2900-4000 rpm or 4000-5900 rpm and up to 2.2 kW.




Corner earthing is not allowed for supply voltages above 3 x 240 V and 3 x 480 V, 50/60 Hz.



Example of a mains-connected motor with mains switch, backup fuses and additional protection

Pos.	Description
1	RCD, type B



TM053495

Mains connection, three-phase motors

Related information

[32.1 Supply voltage](#)

9.4 Additional protection

DANGER

Electric shock

Death or serious personal injury

- Only use residual-current circuit breakers (ELCB, GFCI, RCD) of type B.



The residual-current circuit breaker must be marked with the following symbol:



The total leakage current of all the electrical equipment in the installation must be taken into account. You find the leakage current of the motor in the sections on leakage current and leakage current (AC).

This product can cause a direct current in the protective earth conductor.

Overvoltage and undervoltage protection

Overvoltage and undervoltage may occur in case of unstable power supply or a faulty installation. The motor is stopped if the voltage falls outside the permissible voltage range. The motor restarts automatically when the voltage is again within the permissible voltage range. Therefore, no additional protection relay is required.

TM053942



The motor is protected against transients from the power supply according to EN 61800-3. In areas with high lightning intensity, we recommend external lightning protection.

Overload protection

If the upper load limit is exceeded, the motor automatically compensates for this by reducing the speed and stops if the overload condition persists.

The motor remains stopped for a set period. After this period, the motor automatically attempts to restart.

The overload protection prevents damage to the motor. Consequently, no additional motor protection is required.

Overtemperature protection

The electronic unit has a built-in temperature sensor as an additional protection. When the temperature rises above a certain level, the motor automatically compensates for this by reducing the speed and stops if the temperature keeps rising. The motor remains stopped for a set period. After this period, the motor automatically attempts to restart.

Protection against phase unbalance

Three-phase motors must be connected to a power supply with a quality corresponding to IEC 60146-1-1, class C, to ensure correct motor operation at phase unbalance. This also ensures long life of the components.

Related information

[31.2 Leakage current](#)

[32.2 Leakage current, AC](#)

9.5 Connection terminals

The descriptions and terminal overviews in this section apply to both single-phase and three-phase motors.

For maximum tightening torques, see section Torques.

Related information

[34.1 Torques](#)

9.5.1 Connection terminals, advanced functional module, FM 300

The advanced module has these connections:

- Three analog inputs.
- One analog output.
- Two dedicated digital inputs.
- Two configurable digital inputs or open-collector outputs.

- Input and output for Grundfos Digital Sensor. The input and output are not applicable for TPE2, TPE2 D pumps. The built-in sensor for TPE3, TPE3 D pumps is connected to this input.
- Two Pt100/1000 inputs. For some pumps, the built-in temperature sensor is connected to Pt100/1000 input 1 (terminals 17 and 18).
- Two LiqTec sensor inputs.
- Two signal relay outputs.
- GENibus connection.

See figure Connection terminals, FM 300.



Digital input 1 is factory-set to be start-stop input where open circuit results in stop. A jumper has been factory-fitted between terminals 2 and 6. Remove the jumper if digital input 1 is to be used as external start-stop or any other external function.

DANGER



Electric shock

Death or serious personal injury

- Make sure that the wires to be connected to the connection groups below are separated from each other by reinforced insulation in their entire lengths.



- Inputs and outputs
All inputs and outputs are internally separated from the mains-conducting parts by reinforced insulation and galvanically separated from other circuits.
All control terminals are supplied by protective extra-low voltage, PELV, thus ensuring protection against electric shock.
- Signal relay outputs
 - Signal relay 1:
 - LIVE:
 - You can connect supply voltages up to 250 VAC.
 - PELV:
 - The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.
 - Signal relay 2:
 - PELV:
 - The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.
- Mains supply, terminals N, PE, L or L1, L2, L3, PE



* If you use an external supply source, make sure that there is a connection to earth.
 Connection terminals, FM 300


TW1053509

Terminal	Type	Function
NC	Normally closed contact	Signal relay 1 LIVE or PELV
C1	Common	
NO	Normally open contact	
NC	Normally closed contact	Signal relay 2 PELV only
C2	Common	
NO	Normally open contact	
18	GND	Earth
11	DI4/OC2	Digital input and output, configurable. Open collector: Max. 24 V resistive or inductive.
19	Pt100/1000 input 2	Pt100/1000 sensor input
17	Pt100/1000 input 1	Pt100/1000 sensor input
12	AO	Analog output: 0-20 mA / 4-20 mA 0-10 V
9	GND	Earth
14	AI3	Analog input: 0-20 mA / 4-20 mA 0-10 V
1	DI2	Digital input, configurable
21	LiqTec sensor input 1	LiqTec sensor input white conductor
20	GND	Earth brown and black conductors
22	LiqTec sensor input 2	LiqTec sensor input blue conductor
10	DI3/OC1	Digital input or output, configurable. Open collector: maximum 24 V resistive or inductive.

Terminal	Type	Function
4	AI1	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0.5 V / 0-10 V
2	DI1	Digital input, configurable
5	+5 V	Supply to potentiometer and sensor
6	GND	Earth
A	GENIbus, A	GENIbus, A (+)
Y	GENIbus, Y	GENIbus, GND
B	GENIbus, B	GENIbus, B (-)
3	GND	Earth
15	+24 V	Supply
8	+24 V	Supply
26	+5 V	Supply to potentiometer and sensor
23	GND	Earth
25	GDS TX	Grundfos Digital Sensor output
24	GDS RX	Grundfos Digital Sensor input
7	AI2	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0.5 V / 0-10 V

9.6 Signal cables

- Use screened cables with a cross-sectional area of minimum 0.5 mm² and maximum 1.5 mm² for external on/off switch, digital inputs, setpoint and sensor signals.
- Connect the screens of the cables to frame at both ends with good connection. The screens must be as close as possible to the terminals.



TM02 1325

Stripped cable with screen and wire connections


- Always tighten screws for frame connections whether a cable is fitted or not.
- The wires in the motor terminal box must be as short as possible.

9.7 Bus connection cable

9.7.1 New installations

For the bus connection, use a screened 3-core cable with a cross-sectional area of minimum 0.5 mm² and maximum 1.5 mm².

- If the motor is connected to a unit with a cable clamp which is identical to the one on the motor, connect the screen to this cable clamp.
- If the unit has no cable clamp as shown in figure below.




TM053973

Connection with screened 3-core cable

Pos.	Description
1	Motor

9.7.2 Replacing a motor

- If you have used a screened 2-core cable in the existing installation, connect the cable as shown below.



TM078987

Connection with screened 2-core cable

Pos.	Description
M	Motor

- If you have used a screened 3-core cable in the existing installation, follow the instructions in section New installation.

Related information

[9.7.1 New installations](#)

10. Startup

10.1 Flushing the pipe system



Before starting up the pump for the first time, clean the pipe system thoroughly by flushing it and filling it with clean water.



Do not use the pump for flushing the pipe system.
The warranty does not cover any damage caused by flushing the pipe system by means of the pump.

10.2 Priming the pump



Fill the pump with liquid and vent the pump before starting the pump. To ensure correct venting, the vent screw must point upwards.

Closed systems or open systems where the liquid level is above the pump inlet

1. Close the outlet isolating valve and loosen the vent screw in the motor stool. See figure Position of vent screw.

WARNING

Escaping hot or cold liquids

Death or serious personal injury

- Pay attention to the direction of the vent hole, and make sure that the escaping hot or cold liquid does not cause injury to persons or damage to the equipment.
- Wear personal protection equipment.




2. Slowly open the isolating valve in the inlet pipe until a steady stream of liquid runs out of the vent hole.
3. Tighten the vent screw and completely open the isolating valve(s).

Open systems where the liquid level is below the pump inlet

Make sure that the inlet pipe and the pump is filled with liquid and vented before you start the pump.

1. Close the outlet isolating valve and open the isolating valve in the inlet pipe.
2. Loosen the vent screw. See figure Position of vent screw.
3. Remove the plug from one of the pump flanges, depending on the pump location.
4. Pour liquid through the priming port until the inlet pipe and the pump are filled with liquid.
5. Replace the plug and tighten securely.
6. Tighten the vent screw.

You can fill the inlet pipe with liquid and vent it before you connect it to the pump. You can also install a priming device before the pump.



Position of vent screw

TM057922

10.3 Starting the pump

1. Before starting the pump, completely open the isolating valve on the inlet side of the pump and leave the outlet isolating valve almost closed.
2. Start the pump. See section User interfaces.
3. Vent the pump by loosening the vent screw in the motor stool until a steady stream of liquid runs out of the vent hole. See figure Position of vent screw.

WARNING

Escaping hot or cold liquids

Death or serious personal injury

- Pay attention to the direction of the vent hole, and make sure that the escaping hot or cold liquid does not cause injury to persons or damage to the equipment.
- Wear personal protection equipment.



4. When the pipe system has been filled with liquid, slowly open the outlet isolating valve until it is completely open.

Related information

[10.2 Priming the pump](#)

[12. User interfaces](#)

10.4 Shaft seal run-in

The seal faces are lubricated by the pumped liquid, meaning that there may be a certain amount of leakage from the shaft seal.

When the pump is started up for the first time, or when a new shaft seal is installed, a certain run-in period is required before the leakage is reduced to an

acceptable level. The time required for this depends on the operating conditions, i.e. every time the operating conditions change, a new run-in period will be started.

Under normal conditions, the leaking liquid will evaporate.

As a result, no leakage will be detected.

However, liquids such as kerosene will not evaporate.

The leakage may therefore be seen as a shaft seal failure.

11. Operating conditions

11.1 Maximum number of starts and stops

The number of starts and stops via the power supply must not exceed four times per hour.

When switched on via the power supply, the pump will start after approximately 5 seconds.

If a higher number of starts and stops is desired, use the input for external start/stop when starting or stopping the pump.

When started via an external on/off switch, the pump will start immediately.

11.2 Alternating operation of twin-head pumps

On twin-head pumps, the duty and backup pumps must be alternated on a regular basis, i.e. once a week, to ensure an even distribution of the operating hours on both pumps. The pumps alternate automatically. See section "Multipump setup" (Setup of multi-pump system).

If twin-head pumps are used for pumping domestic hot water, the duty and backup pumps must be alternated on a regular basis, i.e. once a day, to avoid blocking of the backup pump due to deposits such as calcareous deposits. The pumps alternate automatically. See section "Multipump setup" (Setup of multi-pump system).



If twin-head pumps are alternated by an external controller, it is recommended to alternate the pumps at least once every 24 hours to avoid seizing shaft seals.

Related information

[17.49 Multipump setup \(Setup of multi-pump system\)](#)

11.3 Liquid temperature

-25 °C (~ -13 °F) up to +120 °C (~ +248 °F).

The maximum liquid temperature depends on the shaft seal type and the pump type.

Depending on the cast-iron version and the pump application, the maximum liquid temperature may be limited by local regulations and laws.

The maximum liquid temperature is stated on the pump nameplate.



If the pump is used for liquids at high temperatures, the life of the shaft seal and the built-in Grundfos sensor may be reduced.

11.4 Ambient temperature

11.4.1 Ambient temperature during storage and transportation

Minimum: -30 °C.

Maximum: 60 °C.

11.4.2 Ambient temperature during operation

	3 x 200-240 V	3 x 380-500 V
Minimum	-20 °C	-20 °C
Maximum	40 °C	50 °C

The motor can operate with the rated power output, P2, at 50 °C, but continuous operation at higher temperatures reduces the expected product life. If the motor is to operate at ambient temperatures between 50 and 60 °C, select an oversized motor. Contact Grundfos for further information.

11.5 Operating pressure or test pressure

The pressure test has been made with water containing anti-corrosive additives at a temperature of 20 °C (~ 68 °F).

Pressure stage	Operating pressure		Test pressure	
	[bar]	[MPa]	[bar]	[MPa]
PN 6	6	0.6	10	1.0
PN 6 / PN 10	10	1.0	15	1.5
PN 16	16	1.6	24	2.4

11.6 Inlet pressure

To ensure optimum and quiet pump operation, the inlet pressure, system pressure, must be adjusted correctly. See the table in the Appendix.

For the calculation of specific inlet pressures, contact the local Grundfos company or see the data booklet for TP, TPD, TPE, TPED, TPE2, TPE2 D, TPE3 and TPE3,D on Grundfos Product Center (<https://product-selection.grundfos.com/>).

11.7 Electrical data

See sections Technical data, single-phase motors and Technical data, three-phase motors.

For specific motor data, see the motor nameplate.

11.8 Sound pressure level

See section Sound pressure level.

Related information

[34.2 Sound pressure level](#)

11.9 Environment

Non-aggressive and non-explosive atmosphere.

11.10 Installation altitude


Installation altitude is the height above sea level of the installation site.

Motors installed up to 1000 m above sea level can be loaded 100 %.

The motors can be installed up to 3500 m above sea level.



Motors installed more than 1000 m above sea level must not be fully loaded due to the low density and consequent low cooling effect of the air.




Motor output power in relation to altitude

Pos. Description

X Altitude [m]

In order to maintain the galvanic isolation and ensure correct clearance according to EN 60664-1:2007, you must adapt the supply voltage to the altitude:




Supply voltage for three-phase motor in relation to altitude

Pos. Description

A Supply voltage [V]

B Altitude [m]



Supply voltage for single-phase motor in relation to altitude

Pos.	Description
A	Supply voltage [V]
B	Altitude [m]

11.11 Humidity

Maximum humidity: 95 %.

If the humidity is constantly high and above 85 %, one of the drain holes in the drive-end flange must be open. See section Mechanical installation.

Related information

[8. Mechanical installation](#)

11.12 Motor cooling

To ensure cooling of motor and electronics, observe the following:

- Position the motor in such a way that adequate cooling is ensured. See the section on ensuring motor cooling.
- The temperature of the cooling air must not exceed 50 °C.
- Keep cooling fins and fan blades clean.

Related information

[8.8 Ensuring motor cooling](#)

12. User interfaces

WARNING

Hot surface

Death or serious personal injury

- Only touch the buttons on the display as the product may be very hot.



WARNING

Electric shock

Death or serious personal injury

- If the control panel is cracked or perforated, replace it immediately. Contact the nearest Grundfos sales company.



You can make pump settings by means of the following user interfaces:

Control panels

- Standard control panel. See section Standard control panel.
- Advanced control panel. See section Advanced control panel.

Remote controls

- Grundfos GO. See section Grundfos GO.

If the power supply to the pump is switched off, the settings are stored.

Related information


[13. Standard control panel](#)

[14. Advanced control panel](#)

[16. Grundfos GO](#)


13. Standard control panel

Pump variant	Fitted as standard	Option
TPE3, TPE3 D	-	-
TPE2, TPE2 D	•	-



TM0548-48

Standard control panel



Pos.	Symbol	Description
1		Grundfos Eye Shows the operating status of the pump. See section Grundfos Eye for further information.
2	-	Light fields for indication of setpoint.
3		Up and down. Changes the setpoint.
4		Allows radio communication with Grundfos GO and other products of the same type. When you try to establish radio communication between the pump and Grundfos GO or another pump, the green indicator light in Grundfos Eye on the pump flashes continuously. Press  on the pump control panel to allow radio communication with Grundfos GO and other products of the same type.
5		Makes the pump ready for operation as well as starts and stops the pump. Start If you press the button when the pump is stopped, the pump only starts if no other functions with higher priority have been enabled. See section Priority of settings. Stop If you press the button when the pump is running, the pump always stops. The "Stop" text next to the button is on.

Related information

[20. Priority of settings](#)

[21. Grundfos Eye](#)


13.1 Setpoint setting

Set the desired setpoint of the pump by pressing  or . The light fields on the control panel will indicate the setpoint set.

13.1.1 Pump in differential-pressure control mode

The following example applies to a pump in an application where a pressure sensor gives a feedback to the pump. If you retrofit the sensor to the pump, set it up manually as the pump does not automatically register a connected sensor.

The figure below shows that the light fields 5 and 6 are activated, indicating a desired setpoint of 3 m with a sensor measuring range from 0 to 6 m. The setting range is equal to the sensor measuring range.




Setpoint set to 3 m, differential-pressure control

TM057958

13.1.2 Pump in constant-curve control mode




In constant-curve control mode, the pump performance will lie between the maximum and minimum curve of the pump.



TM054895

Pump in constant-curve control mode


Setting to maximum curve:

- Press  continuously to change over to the maximum curve of the pump. The top light field flashes. When the top light field is on, press  for 3 seconds until the light field starts flashing.
- To change back, press  continuously until the desired setpoint is indicated.

Example

Pump set to maximum curve.

The figure below shows that the top light field is flashing, indicating maximum curve.



TM054896

Maximum-curve duty


Setting to minimum curve:

- Press continuously to change over to the minimum curve of the pump. The bottom light field flashes. When the bottom light field is on, press for 3 seconds until the light field starts flashing.
- To change back, press continuously until the desired setpoint is indicated.

Example

Pump set to minimum curve.

The figure below shows that the bottom light field is flashing, indicating minimum curve.



TM054897

Minimum curve duty

13.1.3 Start and stop of pump



If you have stopped the pump by pressing and the "Stop" text on the control panel is on, you can only give it free to operation by pressing again.

If you have stopped the pump by pressing , you can restart it by pressing or by using Grundfos GO.

Start the pump by pressing or by continuously pressing until the desired setpoint is indicated.

Stop the pump by pressing . When the pump is stopped, the "Stop" text next to the button is on. You can also stop the pump by continuously pressing until none of the light fields are on.

You can also stop the pump with Grundfos GO or via a digital input set to External stop. See section Priority of settings.

Related information

[20. Priority of settings](#)


13.1.4 Resetting of fault indications

Reset a fault indication in one of the following ways:

- Via the digital input if it has been set to Alarm resetting.
- Briefly press or on the pump. This does not change the setting of the pump. You cannot reset a fault indication by pressing or if the buttons have been locked.
- Switch off the power supply until the indicator lights are off.
- Switch the external start-stop input off and on.
- With Grundfos GO.

14. Advanced control panel

Pump variant	Fitted as standard	Option
TPE3, TPE3 D	•	-
TPE2, TPE2 D	-	•



TM054849

Advanced control panel

Pos.	Symbol	Description
1		Grundfos Eye Shows the operating status of the pump. For further information, see section Grundfos Eye.
2	-	Graphical colour display.
3		Goes one step back.
4		Navigates between main menus, displays and digits. When you change the menu, the display always shows the top display of the new menu. Navigates between submenus. Changes value settings. Note: If you have disabled the possibility to make settings with the Enable/disable settings function, then you can enable it again temporarily by pressing these buttons simultaneously for at least 5 seconds. See section "Buttons on product" (Enable/disable settings).

Pos.	Symbol	Description
4	OK	Saves changed values, resets alarms and expands the value field. Enables radio communication with Grundfos GO and other products of the same type. When you try to establish radio communication between the pump and Grundfos GO or another pump, the green indicator light in Grundfos Eye flashes. A note also appears in the pump display stating that a wireless device wants to connect to the pump. Press OK on the pump control panel to allow radio communication with Grundfos GO and other products of the same type.
5		Makes the pump ready for operation, and starts and stops the pump. Start: If you press the button when the pump is stopped, the pump only starts if no other functions with higher priority have been enabled. See section Priority of settings. Stop: If you press the button when the pump is running, the pump is always stopped. When you stop the pump via this button, the icon appears in the bottom of the display.
6		Goes to the Home menu.


Related information

[17.33 "Buttons on product" \(Enable/disable settings\)](#)

[20. Priority of settings](#)

[21. Grundfos Eye](#)

15. Home display



Example of **Home** display

Pos.	Symbol	Description
1		Home This menu shows up to four user-defined parameters. You can select parameters shown as shortcut icon , and when pressing OK you go directly to the Settings display for the selected parameter.
2	-	Status This menu shows the status of the pump and system as well as warnings and alarms.
3	-	Settings This menu gives access to all setting parameters. You can make detailed settings of the pump in this menu. See section Description of functions.
4	-	Assist This menu enables assisted pump setup, provides a short description of the control modes and offers fault advice. See section Assist.
5		Indicates that the pump has been stopped via the button.

Pos.	Symbol	Description
6		Indicates that the pump is functioning as master pump in a multipump system.
7		Indicates that the pump is functioning as a slave pump in a multipump system.
8		Indicates that the pump is operating in a multipump system. See section "Multipump setup" (Setup of multi-pump system).
9		Indicates that the possibility to make settings has been disabled for protective reasons. See section "Buttons on product" (Enable/disable settings).

Related information

- [17.33 "Buttons on product" \(Enable/disable settings\)](#)
- [17.45 Assist](#)
- [17.49 Multipump setup \(Setup of multi-pump system\)](#)

15.1 Start-up guide

The pump incorporates a startup guide which is started at the first startup. See section Run start-up guide. After the startup guide, the main menus appear in the display.

Related information

- [17.42 Run start-up guide](#)

15.2 Menu overview for advanced control panel

15.2.1 Main menus

Home	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	
	•	•	•	

Status	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
Operating status	•	•	•	
Operating mode, from	•	•	•	
Control mode	•	•	•	
Pump performance	•	•	•	
Actual controlled value	•	•	•	
Max. curve and duty point	•	•	•	
Resulting setpoint	•	•	•	
Liquid temp.	•	-	•	
Speed	•	•	•	
Acc. flow and specific energy	•	•	•	
Power and energy consumption	•	•	•	
Measured values	•	•	•	
Set date and time	•	•	•	
Analog input 2	•	•	•	
Analog input 3	•	•	•	
Pt100/1000 input 1	•	•	•	
Pt100/1000 input 2	•	•	•	
Analog output	•	•	•	
Warning and alarm	•	•	•	
Actual warning or alarm	•	•	•	
Warning log	•	•	•	
Alarm log	•	•	•	
"Heat energy monitor"	•	-	•	<i>Heat energy monitor</i>
Heat power	•	-	•	
Heat energy	•	-	•	
Flow rate	•	-	•	
Volume	•	-	•	
Hours counter	•	-	•	
Temperature 1	•	-	•	
Temperature 2	•	-	•	

Status	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
Differential temp.	•	-	•	
Operating log	•	•	•	
Operating hours	•	•	•	
Trend data	•	•	•	
Fitted modules	•	•	•	
Date and time	•	•	•	
Product identification	•	•	•	
Motor bearing monitoring	•	•	•	
Multi-pump system	-	-	•	
System operating status	-	-	•	
System performance	-	-	•	
System input power and energy	-	-	•	
Pump 1, multi-pump system	-	-	•	
Pump 2, multi-pump system	-	-	•	
Pump 3, multi-pump system	-	-	•	
Pump 4, multi-pump system	-	-	•	

Settings	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
Setpoint	•	•	•	Setpoint
Operating mode	•	•	•	<i>Operating mode</i>
Set manual speed	•	•	•	<i>Set manual speed</i>
"Set user-defined speed"	•	•	•	<i>User-defined speed</i>
Control mode	•	•	•	<i>Control mode</i>
FLOWLIMIT	•	-	•	<i>FLOWLIMIT</i>
Automatic Night Setback	•	-	•	<i>Automatic Night Setback</i>
Analog inputs	•	•	•	
Analog input 1, setup	•	•	•	<i>Analog inputs</i>
Analog input 2, setup	•	•	•	
Analog input 3, setup	•	•	•	
Built-in Grundfos sensor	•	-	•	<i>Built-in Grundfos sensor</i>
Pt100/1000 inputs	•	•	•	
Pt100/1000 input 1, setup	•	•	•	<i>Pt100/1000 inputs</i>
Pt100/1000 input 2, setup	•	•	•	

Settings	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
Digital inputs	•	•	•	
Digital input 1, setup	•	•	•	<i>Digital inputs</i>
Digital input 2, setup	•	•	•	
Digital inputs/outputs	•	•	•	
Digital input/output 3, setup	•	•	•	<i>Digital inputs/outputs</i>
Digital input/output 4, setup	•	•	•	
Relay outputs	•	•	•	
Relay output 1	•	•	•	<i>"Signal relays 1 and 2" (Relay outputs)</i>
Relay output 2	•	•	•	
Analog output	•	•	•	
Output signal	•	•	•	<i>Analog output</i>
Function of analog output	•	•	•	
"Controller settings"	•	•	•	<i>Controller (Controller settings)</i>
Operating range	•	•	•	Operating range
Setpoint influence	•	•	•	
External setpoint function	•	•	•	<i>External setpoint function</i>
"Predefined setpoints"	•	•	•	Predefined setpoints
Temperature influence	•	-	•	<i>Temperature influence</i>
Monitoring functions	•	•	•	
Motor bearing monitoring	•	•	•	<i>Motor bearing monitoring</i>
Motor bearing maintenance	•	•	•	
Limit-exceeded function	•	•	•	<i>Limit-exceeded function</i>
"Special functions"	•	•	•	
"Pulse flowmeter setup"	•	•	•	<i>Pulse flowmeter setup</i>
"Ramps"	•	•	•	<i>Ramps</i>
"Standstill heating"	•	•	•	Standstill heating
Communication	•	•	•	
Pump number	•	•	•	Number (Pump number)
Enable/disable radio comm.	•	•	•	Radio communication (Enable/disable radio comm.)
General settings	•	•	•	
Language	•	•	•	Language
Set date and time	•	•	•	<i>Date and time (Set date and time)</i>
Units	•	•	•	<i>Unit configuration (Units)</i>

Settings	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
Enable/disable settings	•	•	•	<i>"Buttons on product" (Enable/disable settings)</i>
Delete history	•	•	•	Delete history
Define Home display	•	•	•	Define Home display
Display settings	•	•	•	Display settings
Store actual settings	•	•	•	"Store settings" (Store actual settings)
Recall stored settings	•	•	•	"Recall settings" (Recall stored settings)
Run start-up guide	•	•	•	Run start-up guide


Assist	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
Assisted pump setup	•	•	•	Assisted pump setup
Setup, analog input	•	•	•	Setup, analog input
Setting of date and time	•	•	•	Setting of date and time
Setup of multi-pump system	•	•	•	"Multipump setup" (Setup of multi-pump system)
Description of control mode	•	•	•	Description of control mode
Assisted fault advice	•	•	•	Assisted fault advice

16. Grundfos GO

The pump is designed for wireless radio or infrared communication with Grundfos GO.

Grundfos GO enables setting of functions and gives access to status overviews, technical product information and actual operating parameters.

Grundfos GO offers the following mobile interfaces, MI.



Grundfos GO communicating with the pump via radio or infrared connection, IR

TM060256

Pos.	Description
	Grundfos MI 301:
1	Separate module enabling radio or infrared communication. You can use the module in conjunction with an Android or iOS-based smart device with Bluetooth connection.

16.1 Communication

When Grundfos GO initiates communication with the pump, the indicator light in the middle of Grundfos Eye flashes green. See section Grundfos Eye.

Furthermore, on pumps fitted with an advanced control panel a text appears in the display saying that a wireless device is trying to establish connection.

Press **OK** on the pump in order to establish connection with Grundfos GO or press **↩** to reject connection.

Establish communication using one of these communication types:

- radio communication
- infrared communication.

Related information

[21. Grundfos Eye](#)

16.1.1 Radio communication

Radio communication can take place at distances up to 30 m. The first time Grundfos GO communicates with the pump, you must enable communication by pressing **📶** or **OK** on the pump control panel. Later when communication takes place, the pump is recognized by Grundfos GO and you can select the pump from the "List" menu.

16.1.2 Infrared communication

When communicating via infrared light, Grundfos GO must be pointed at the pump control panel.

16.2 Menu overview for Grundfos GO main menus

Dashboard	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	
	•	•	•	

Status	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
"System mode"	-	-	• ¹⁾	
"Resulting setpoint"	•	•		
"Resulting system setpoint"	-	-	• ¹⁾	
"Actual controlled value"	•	•	• ¹⁾	
"Motor speed (rpm, %)"	•	•	-	
"Power consumption"	•	•	-	
"Power cons., sys."	-	-	• ¹⁾	
"Energy consumption"	•	•		
"Energy cons., sys."	-	-	• ¹⁾	
"Acc. flow, specific energy"	•	•	• ¹⁾	
"Operating hours"	•	•		
"Operating hours, system"	-	-	• ¹⁾	
"Liquid temperature"	•	-	-	
"Analog input 1"	•	•	-	
"Analog input 2"	•	•	-	
"Analog input 3"	•	•	-	
"Pt100/1000 input 1"	•	•	-	
"Pt100/1000 input 2"	•	•	-	
"Analog output"	•	•	-	
"Digital input 1"	•	•	-	
"Digital input 2"	•	•	-	
"Digital in/output 3"	•	•	-	
"Digital in/output 4"	•	•	-	
"Fitted modules"	•	•	-	
"Trend data"	•	-	-	
"Heat energy monitor"	•	-	-	17.1 Heat energy monitor
"Pump 1"	-	-	• ¹⁾	

Status	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
"Pump 2"	-	-	● 1)	
"Pump 3"	-	-	● 1)	
"Pump 4"	-	-	● 1)	

1) Only available if Grundfos GO is connected to a multipump system.

Settings	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
"Setpoint"	●	●	●	Setpoint
"Operating mode"	●	●	●	17.3 Operating mode
"Set user-defined speed"	●	●	●	17.5 User-defined speed
"Control mode"	●	●	●	17.6 Control mode
"Proportional-pressure setup"	●	-	-	Proportional-pressure setup
"Date and time"	●	●	●	17.31 Date and time (Set date and time)
"Flow limit"	●	-	●	17.8 FLOWLIMIT
"Automatic Night Setback"	●	-	●	17.9 Automatic Night Setback
"Temperature influence"	●	-	●	17.21 Temperature influence
"Buttons on product"	●	●	●	17.33 "Buttons on product" (Enable/disable settings)
"Controller"	●	●	●	17.17 Controller (Controller settings)
"Operating range"	●	●	●	Operating range
"Ramps"	●	●	-	17.24 Ramps
"Pump number"	●	●	-	Number (Pump number)
"Radio communication"	●	●	-	Radio communication (Enable/disable radio comm.)
"Analog input 1"	●	●	-	
"Analog input 2"	●	●	-	17.10 Analog inputs
"Analog input 3"	●	●	-	
"Built-in Grundfos sensor"	●	-	●	17.11 Built-in Grundfos sensor
"Pt100/1000 input 1"	●	●	-	
"Pt100/1000 input 2"	●	●	-	17.12 Pt100/1000 inputs
"Digital input 1"	●	●	-	
"Digital input 2"	●	●	-	17.13 Digital inputs
"Digital in/output 3"	●	●	-	
"Digital in/output 4"	●	●	-	17.14 Digital inputs/outputs
"Predefined setpoint"	●	●	●	Predefined setpoints

Settings	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
"Analog output"	•	•	-	17.16 Analog output
"External setpoint funct."	•	•	-	17.19 External setpoint function
"Signal relay 1"	•	•	-	17.15 "Signal relays 1 and 2" (Relay outputs)
"Signal relay 2"	•	•	-	
"Limit 1 exceeded"	•	•	•	17.22 Limit-exceeded function
"Limit 2 exceeded"	•	•	•	
"Alternating operation, time"	-	-	• ¹⁾	"Multipump setup" (Setup of multi-pump system)
"Time for pump changeover"	-	-	• ¹⁾	
"Standstill heating"	•	•	-	Standstill heating
"Motor bearing monitoring"	•	•	-	17.26 Motor bearing monitoring
"Service"	•	•	-	"Service"
"Store settings"	•	•	-	"Store settings" (Store actual settings)
"Recall settings"	•	•	-	"Recall settings" (Recall stored settings)
"Undo"	•	•	•	"Undo"
"Pump name"	•	•	•	"Pump name"
"Connection code"	•	•	•	"Connection code"
"Unit configuration"	•	•	•	17.32 Unit configuration (Units)

Alarms and warnings	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
"Alarm log"	•	•	•	Alarm log
"Warning log"	•	•	•	Warning log
"Reset alarm" button	•	•	•	

Assist	TPE3 TPE3 D	TPE2 TPE2 D	Multipump system	Section
"Assisted pump setup"	•	•	-	Assisted pump setup
"Assisted fault advice"	•	•	•	Assisted fault advice
"Multipump setup"	•	•	•	"Multipump setup" (Setup of multi-pump system)

17. Description of functions

17.1 Heat energy monitor

Pump variant	Heat energy monitor
TPE3, TPE3 D	•
TPE2, TPE2 D	-


The heat energy monitor is a monitoring function that calculates the heat energy consumption within a system. The built-in flow estimation needed for the calculation has an inaccuracy of $\pm 10\%$ of the maximum flow in the area down to 10% flow and down to 12.5% of the maximum head. The calculations are based on water at a temperature of $20\text{ }^{\circ}\text{C}$. Also, the temperature measurements needed for the calculation have some inaccuracy depending on the sensor type. Therefore, you cannot use the heat energy value for billing purposes. However, the value is perfect for optimisation purposes in order to prevent excessive energy costs caused by system imbalances.

The heat energy monitor requires an additional temperature sensor installed in the flow pipe or return pipe depending on where the pump is installed.



Use the analog inputs and/or Pt100/1000 inputs for measuring the temperatures used for calculation by the heat energy monitor.

The used inputs must not be set to **Not active** and one of the measuring parameters must be set to **Temperature 2**.



TM061182

Example: pump installed in the flow pipe and additional temperature sensor installed in the return pipe

Pos.	Description
t _F	Flow-pipe temperature
t _R	Return-pipe temperature

17.2 Setpoint

Pump variant	Setpoint
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can set the setpoint for all control modes, except AUTOADAPT and FLOWADAPT, in this submenu when you have selected the desired control mode. See section Control mode.

Factory setting

See section Factory settings.

Related information

[17.6 Control mode](#)

[35. Factory settings](#)


17.3 Operating mode

Pump variant	Operating mode
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Possible operating modes:

- **Normal**
The pump runs according to the selected control mode.
- **Stop**
The pump stops.
- **Min.**
Use the minimum-curve mode in periods in which a minimum flow is required. This operating mode is for instance suitable for manual night setback if you do not want to use automatic night setback.
- **Max.**
Use the maximum-curve mode in periods in which a maximum flow is required. This operating mode is for instance suitable for systems with hot-water priority.
- **Manual**
The pump is operating at a manually set speed. In **Manual** the setpoint via bus is overruled. See section Set manual speed.
- "User-defined speed"
The motor is operating at a speed set by the user. See section "Set user-defined speed".

All operating modes are illustrated in the figure below.



TM064024

Operating modes

Pos.	Description
1	Normal
2	Normal
3	Manual

Factory setting

See section Factory settings.

Related information

[17.4 Set manual speed](#)

[17.5 User-defined speed](#)

[35. Factory settings](#)

17.4 Set manual speed

Pump variant	Set manual speed
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel. With Grundfos GO, you set the speed via the **Setpoint** menu.

You can set the pump speed in % of the maximum speed. When you have set the operating mode to **Manual**, the pump starts running at the set speed. The speed can then be changed manually via Grundfos GO or via the advanced control panel.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.5 User-defined speed

Use this function to set the motor speed in percentage of the maximum speed. When you have set the operating mode to **User-defined speed**, the pump starts running at the set speed.

17.6 Control mode

Pump variant	"Control mode"
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Possible control modes:

- "AUTOADAPT"
- "FLOWADAPT"
- **Prop. pressure** (proportional pressure)
- **Const. pressure** (constant pressure)
- **Const. temp.** (constant temperature)
- **Con. diff. press.** (constant differential pressure)
- **Con. diff. temp.** (constant differential temperature)
- **Const. flow rate** (constant flow rate)
- **Const. level** (constant level)
- **Const. other val.** (constant other value)
- **Const. curve** (constant curve).



Set the operating mode to **Normal** before you enable a control mode.

You can change the setpoint for all control modes, except AUTOADAPT and FLOWADAPT, in the **Setpoint** submenu under **Settings** when you have selected the desired control mode.

Factory setting

See section Factory settings.

Related information


[35. Factory settings](#)

17.6.1 AUTOADAPT

Pump variant	AUTOADAPT
TPE3, TPE3 D	•
TPE2, TPE2 D	-

The **AUTOADAPT** control mode continuously adapts the pump performance according to the actual system characteristic.

Manual setting of the setpoint is not possible.



TM057910

AUTOADAPT

When the **AUTOADAPT** control mode has been enabled, the pump will start with the factory setting, H_{fac} is equal to H_{set1} , and then adjust its performance to A_1 . See the figure AUTOADAPT.

When the pump registers a lower head on the maximum curve, A_2 , the **AUTOADAPT** function automatically selects a correspondingly lower control curve, H_{set2} . If the valves in the system close, the pump will adjust its performance to A_3 .

- A_1 : Original duty point.
- A_2 : Lower registered head on the maximum curve.
- A_3 : New duty point after AUTOADAPT control.
- H_{set1} : Original setpoint setting.
- H_{set2} : New setpoint after AUTOADAPT control.
- H_{fac} : Factory setting.
- H_{auto_min} : A fixed value of 1.5 m.

The **AUTOADAPT** control mode is a form of proportional-pressure control where the control curves have a fixed origin, H_{auto_min} .

17.6.2 FLOWADAPT


Pump variant	FLOWADAPT
TPE3, TPE3 D	•
TPE2, TPE2 D	-

When you select FLOWADAPT, the pump runs AUTOADAPT and ensures that the flow never exceeds the entered FLOWLIMIT value.

The setting range for FLOWLIMIT is 25 to 90 % of the maximum flow rate of the pump.

The factory setting of the FLOWLIMIT is the flow rate where the AUTOADAPT factory setting meets the maximum curve. See figure FLOWADAPT.

Do not set the FLOWLIMIT lower than the sized duty point.



FLOWADAPT

Pos.	Description
1	Setting range

17.6.3 Proportional pressure


Pump variant	Proportional pressure
TPE3, TPE3 D	•
TPE2, TPE2 D	-

The head of the pump is reduced at decreasing water demand and increased at rising water demand. See the figure Proportional pressure.

This control mode is especially suitable in systems with relatively large pressure losses in the distribution pipes. The head of the pump increases proportionally to the flow in the system to compensate for the large pressure losses in the distribution pipes.

The setpoint can be set with an accuracy of 0.1 metre. The head against a closed valve is half the setpoint. The setting range is between 25 % and 90 % of maximum head.


For more information about settings, see section on proportional-pressure setup.



Proportional pressure

Example

- Factory-fitted differential-pressure sensor.



Proportional pressure

Controller settings

For recommended controller settings, see section on the controller (controller settings).

Related information


[17.7 Proportional-pressure setup](#)

[17.17 Controller \(Controller settings\)](#)

17.6.4 Constant pressure

Pump variant	Constant pressure
TPE3, TPE3 D	•
TPE2, TPE2 D	•

We recommend this control mode if the pump is to deliver a constant pressure, independently of the flow in the system. The pump maintains a constant pressure independently of the flow rate.




TM057901

Constant pressure

This control mode requires an external pressure sensor as shown in the examples below. You can set the pressure sensor in the **Assist** menu. See section Assisted pump setup. The setting range is between 12.5 % of maximum head and maximum head.

Examples

- One external pressure sensor.



Constant pressure

Controller settings

For recommended controller settings, see the section the controller (controller settings).

Related information


[17.17 Controller \(Controller settings\)](#)

[17.46 Assisted pump setup](#)

17.6.5 Constant temperature

Pump variant	Constant temperature
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This control mode ensures a constant temperature. Constant temperature is a comfort control mode that you can use in domestic hot-water systems to control the flow to maintain a constant temperature in the system.




TM057900

Constant temperature


This control mode requires either an internal or external temperature sensor as shown in the examples below.

Examples

- Factory-fitted temperature sensor. Only TPE3, TPE3 D.



- One external temperature sensor.



Constant temperature

Controller settings

For recommended controller settings, see the section the controller (controller settings).


Related information

[17.17 Controller \(Controller settings\)](#)

17.6.6 Constant differential pressure

Pump variant	Constant differential pressure
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The pump maintains a constant differential pressure, independently of the flow in the system. This control mode is primarily suitable for systems with relatively small pressure losses.




TM057901

Constant differential pressure


The setting range is between 12.5 % of maximum head and maximum head. This control mode requires either an internal or external differential-pressure sensor or two external pressure sensors as shown in the examples below.

Examples


- Factory-fitted differential-pressure sensor. Only TPE3, TPE3 D.



- One external differential-pressure sensor. The pump uses the input from the sensor to control the differential pressure. You can set sensor manually or by using the **Assist** menu. See section Assisted pump setup.



- Two external pressure sensors. Constant differential-pressure control is achievable with two individual pressure sensors. The pump uses the inputs from the two sensors and calculates the differential pressure. The sensors must have the same unit and must be set as feedback sensors. You can set the sensors manually, sensor by sensor, or by using the **Assist** menu. See section Assisted pump setup.



Constant differential pressure

Controller settings

For recommended controller settings, see the section on the controller (controller settings).


Related information

- [17.17 Controller \(Controller settings\)](#)
- [17.46 Assisted pump setup](#)

17.6.7 Constant differential temperature

Pump variant	Constant differential temperature
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The pump maintains a constant differential temperature in the system and the pump performance is controlled according to this.



TM/057954

Constant differential temperature


This control mode requires either two temperature sensors or one external differential-temperature sensor. See the examples below.

The temperature sensors can either be analog sensors connected to two of the analog inputs or two Pt100/Pt1000 sensors connected to the Pt100/1000 inputs, if these are available on the specific pump.

Set the sensor in the **Assist** menu under **Assisted pump setup**. See section Assisted pump setup.


Examples

- Factory-fitted temperature sensor and an external temperature sensor. Only TPE3, TPE3 D.




- Two external temperature sensors. Constant differential-temperature control is achievable with two temperature sensors. The pump uses the inputs from the two sensors and calculates the differential temperature.

The sensors must have the same unit and must be set as feedback sensors. You can set the sensors manually, sensor by sensor, or by using the **Assist** menu. See section Assisted pump setup.



- One external differential-temperature sensor. The pump uses the input from the sensor to control the differential temperature. You can set the sensor manually or by using the **Assist** menu. See section Assisted pump setup.



Constant differential temperature

Controller settings

For recommended controller settings, see the section on the controller (controller settings).

Related information


[17.17 Controller \(Controller settings\)](#)

[17.46 Assisted pump setup](#)

17.6.8 Constant flow rate

Pump variant	Constant flow rate
TPE3,TPE3 D	•
TPE2,TPE2 D	•

The pump maintains a constant flow in the system, independently of the head.




TM057955

Constant flow rate

This control mode requires an external flow sensor. See the example below.

Example

- One external flow sensor.



Constant flow rate

Controller settings

For recommended controller settings, see the section on the controller (controller settings).


Related information

[17.17 Controller \(Controller settings\)](#)

17.6.9 Constant level

Pump variant	Constant level
TPE3,TPE3 D	•
TPE2,TPE2 D	•

The pump maintains a constant level, independently of the flow rate.



TM057941

Constant level

This control mode requires an external level sensor.

The pump can control the level in a tank in two ways:


- As an emptying function where the pump draws the liquid from the tank.
- As a filling function where the pump pumps the liquid into the tank.

See the figure Constant level.


The type of level control function depends on the setting of the built-in controller. See the section on the controller (controller settings).

Examples

- One external level sensor.
 - emptying function.



- One external level sensor.
 - filling function.



Controller settings

For recommended controller settings, see the section on the controller (controller settings).

Related information

[17.17 Controller \(Controller settings\)](#)

17.6.10 Constant other value

Pump variant	Constant other value
TPE3,TPE3 D	•
TPE2,TPE2 D	•

Any other value is kept constant.


Use this control mode if you want to control a value which is not available in the **Control mode** menu. Connect a sensor measuring the controlled value to one of the analog inputs of the pump. The controlled value will be shown in percentage of sensor range.

17.6.11 Constant curve

Pump variant	Constant curve
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can set the pump to operate according to a constant curve, like an uncontrolled pump. See the figure Constant curve.


You can set the desired speed in % of maximum speed in the range from 13 to 100 %.



TM057957

Constant curve

Depending on the system characteristic and the duty point, the 100 % setting may be slightly smaller than the actual maximum curve of the pump even though the display shows 100 %. This is due to the power and pressure limitations built into the pump. The deviation varies according to pump type and pressure loss in the pipes.



TM057913

Power and pressure limitations influencing the maximum curve

Pos.	Description
1	Limited maximum curve

Controller settings

For recommended controller settings, see the section on the controller (controller settings).

Related information

[17.17 Controller \(Controller settings\)](#)

17.7 Proportional-pressure setup

Pump variant	Proportional-pressure setup
TPE3, TPE3 D	•
TPE2, TPE2 D	-

Control-curve function

You can set the curve either to quadratic or linear.

Zero-flow head


You can set this value in % of the setpoint. With a setting of 100 %, the control mode is equal to constant differential pressure.

17.8 FLOWLIMIT

Pump variant	FLOWLIMIT
TPE3, TPE3 D	•
TPE2, TPE2 D	-

FLOWLIMIT

- Enable the FLOWLIMIT function.
- Set the FLOWLIMIT.



TM057908

FLOWLIMIT

Pos.	Description
1	Setting range

You can combine the FLOWLIMIT function with the following control modes:

- **Prop. pressure**
- **Con. diff. press.**
- **Con. diff. temp.**
- **Const. temp.**
- **Const. curve.**

A flow-limiting function ensures that the flow never exceeds the entered FLOWLIMIT value.

The setting range for FLOWLIMIT is 25 to 90 % of the Q_{\max} of the pump.

The factory setting of the FLOWLIMIT is the flow where the AUTOADAPT factory setting meets the maximum curve. See figure FLOWADAPT.

Factory setting

See section Factory settings.

Related information

[17.6.2 FLOWADAPT](#)

[35. Factory settings](#)

17.9 Automatic Night Setback

Pump variant	Automatic Night Setback
TPE3, TPE3 D	•
TPE2, TPE2 D	-

Once you have enabled automatic night setback, the pump automatically changes between normal duty and night setback, duty at low performance.

Changeover between normal duty and night setback depends on the flow-pipe temperature.

The pump automatically changes over to night setback when the built-in sensor registers a flow-pipe temperature drop of more than 10 to 15 °C within approximately two hours. The temperature drop must be at least 0.1 °C/min.

Changeover to normal duty takes place without a time lag when the temperature has increased by approximately 10 °C.

You cannot enable automatic night setback when the pump is in constant-curve mode.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.10 Analog inputs

Pump variant	Analog inputs
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Function	Terminal ²⁾
Analog input 1, setup	4
Analog input 2, setup	7
Analog input 3, setup	14

²⁾ See section Connection terminals, advanced functional module, FM 300.

Set the analog input for a feedback sensor via the **Assisted pump setup** menu. See section Assisted pump setup.

If you want to set an analog input for other purposes, you can do this manually.

You can set the analog inputs via the **Setup, analog input** menu. See section Setup, analog input.

If you perform the manual setting via Grundfos GO, you need to enter the menu for the analog input under the **Settings** menu.



Function

You can set the analog inputs to these functions:

- **Not active.**
- **Feedback sensor**
Sensor used for the selected control mode.
- **Ext. setpoint infl.**
See section External setpoint function.
- **Other function.**

Measured parameter

Select one of the parameters, such as the parameter to be measured in the system by the sensor connected to the actual analog input.



Overview of sensor locations

Sensor function, measured parameter	Pos.
Inlet pressure	1
Diff. press., inlet	2
"Outlet pressure"	3
Diff. press.,outlet	4
Diff. press.,pump	5
Operating mode	6
Press. 2, external	7
Diff. press., ext.	8
Storage tank level	9
Feed tank level	10
Pump flow	11
Flow, external	12
Liquid temp.	
TPE3, TPE3 D: The temperature is measured by the built-in sensor.	13
Temperature 1	14
Temperature 2	15
Diff. temp., ext.	16
Ambient temp.	Not shown
Other parameter	Not shown

Unit

Available measuring units:

Parameter	Possible measuring units
Pressure	bar, m, kPa, psi, ft
Level	m, ft, in
Flow rate	m ³ /h, l/s, yd ³ /h, gpm
Liquid temp.	°C, °F
Other parameter	%

Electrical signal

Select signal type:

- 0.5-3.5 V
- 0-5 V
- 0-10 V
- 0-20 mA
- 4-20 mA.

Sensor range, minimum value

Set the minimum value of the connected sensor.

Sensor range, maximum value

Set the maximum value of the connected sensor.

Factory setting

See section Factory settings.

Related information

[9.5.1 Connection terminals, advanced functional module, FM 300](#)

[17.19 External setpoint function](#)

[17.46 Assisted pump setup](#)

[17.47 Setup, analog input](#)

[35. Factory settings](#)

17.10.1 Setting two sensors for differential measurement

In order to measure the difference of a parameter between two points, set the corresponding sensors as follow:

Parameter	Analog input for sensor 1	Analog input for sensor 2
Pressure, option 1	Differential pressure, inlet	Differential pressure, outlet
Pressure, option 2	Pressure 1, external	Pressure 2, external
Flow	Pump flow	Flow, external
Temperature	Temperature 1	Temperature 2



If you want to use the control mode "constant differential pressure", you must choose the function **Feedback sensor** for the analog input of both sensors.

17.11 Built-in Grundfos sensor

Pump variant	Built-in Grundfos sensor
TPE3, TPE3 D	•
TPE2, TPE2 D	-

You can select the function of the built-in sensor in the **Built-in Grundfos sensor** menu.

Set the **Built-in Grundfos sensor** via the **Assisted pump setup** menu. See section Assisted pump setup.

If you perform the setting manually in the advanced control panel, you must enter the **Analog inputs** menu under the **Settings** menu in order to access the **Built-in Grundfos sensor** menu.

If you perform the setting manually via Grundfos GO, you need to enter the menu for the **Built-in Grundfos sensor** under the **Settings** menu.

Function

You can set the built-in sensor to these functions:

- **Grundfos diff.-pressure sensor**
 - **Not active**
 - **Feedback sensor**
 - **Setpoint influence**
 - **Other function.**

Factory setting

See section Factory settings.

Related information

- [17.46 Assisted pump setup](#)
- [35. Factory settings](#)

17.12 Pt100/1000 inputs

Pump variant	Pt100/1000 inputs
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Function	Terminal ³⁾
Pt100/1000 input 1, setup	17 and 18
Pt100/1000 input 2, setup	18 and 19

³⁾ See section Connection terminals, advanced functional module, FM 300.

For some pumps, the built-in temperature sensor is connected to Pt100/1000 input 1 (terminals 17 and 18).

Set the Pt100/1000 input for a feedback sensor via the **Assisted pump setup** menu. See section Assisted pump setup.

If you want to set a Pt100/1000 input for other purposes, you can do this manually.

You can set the analog inputs via the **Setup, analog input** menu. See section Setup, analog input.

If you perform the manual setting via Grundfos GO, you need to enter the menu for the Pt100/1000 input under the **Settings** menu.


Function

You can set the Pt100/1000 inputs to these functions:

- **Not active**
- **Feedback sensor**
- **Ext. setpoint infl.**
 - See section External setpoint function
- **Other function.**

Measured parameter

Select one of the parameters, such as the parameter to be measured in the system by the Pt100/1000 sensor connected to the actual Pt100/1000 input.



Overview of Pt100/1000 sensor locations

Parameter	Pos.
Liquid temp.	1
Temperature 1	2
Temperature 2	3
Ambient temp.	Not shown

Measuring range

-50 to +204 °C.

Factory setting

See section Factory settings.

Related information

[9.5.1 Connection terminals, advanced functional module, FM 300](#)

[17.19 External setpoint function](#)

[17.46 Assisted pump setup](#)

[17.47 Setup, analog input](#)

[35. Factory settings](#)

17.13 Digital inputs

Pump variant	Digital inputs
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Function	Terminal ⁴⁾
Digital input 1, setup	2 and 6
Digital input 2, setup	1 and 9

⁴⁾ See section Connection terminals, advanced functional module, FM 300.

To set a digital input, make the settings below.

Function

Select one of these functions:

- **Not active**
When set to **Not active**, the input has no function.
- **External stop**
When the input is deactivated, open circuit, the pump stops.
- **Min.** (minimum speed)
When the input is activated, the pump runs at the set minimum speed.
- **Max.** (maximum speed)
When the input is activated, the pump runs at the set maximum speed.
- "User-defined speed"
When the input is activated, the motor runs at a speed set by the user.
- **External fault**
When the input is activated, a timer starts. If the input is activated for more than 5 seconds, the pump stops and a fault is indicated. This function depends on input from external equipment.
- **Alarm resetting**
When the input is activated, a possible fault indication is reset.
- **Dry running**
When this function has been selected, lack of inlet pressure or water shortage can be detected. When lack of inlet pressure or water shortage, dry running, is detected, the pump stops. The pump cannot restart as long as the input is activated. This requires the use of an accessory, such as these:
 - a pressure switch installed on the inlet side of the pump
 - a float switch installed on the inlet side of the pump.
- **Accumulated flow**
When this function has been selected, the accumulated flow can be registered. This requires the use of a flowmeter which can give a feedback signal as a pulse per defined flow of water. See section "Pulse flowmeter setup".
- **Predefined setpoint digit 1**, applies only to digital input 2
When digital inputs are set to a predefined setpoint, the pump operates according to a setpoint based on the combination of the activated digital inputs. See section "Predefined setpoints".
- Activate output
When the input is activated, the related digital output is activated. See section Digital inputs/ outputs. This is done without any changes to pump operation.
- Local motor stop

When the input is activated, the given pump in a multipump system stops without affecting the performance of the other pumps in the system.

The priority of the selected functions in relation to each other appears from section Priority of settings. A stop command always has the highest priority.

Activation delay

Pump variant	Activation delay
TPE3, TPE3 D	-
TPE2, TPE2 D	•

Select the activation delay, T1.

It is the time between the digital signal and the activation of the selected function.

Range: 0 to 6000 seconds.

Duration timer mode


Select the mode. See figure Duration timer function of digital inputs.

- **Not active**
- active with interrupt, mode A
- active without interrupt, mode B
- active with after-run, mode C.

Select the duration time, T2.

It is the time which, together with the mode, determines how long the selected function is active.

Range: 0 to 15,000 seconds.



TM064949

Duration timer function of digital inputs

Pos.	Description
1	Mode C
2	Mode B
3	Mode A
4	Digital input
5	T input > T1 + T2

Pos.	Description
6	T input < T1 + T2
7	T input
8	T input

Factory setting

See section Factory settings.

Related information

[9.5.1 Connection terminals, advanced functional module, FM 300](#)

[17.14 Digital inputs/outputs](#)

[17.20 Predefined setpoints](#)

[17.23 Pulse flowmeter setup](#)

[20. Priority of settings](#)

[35. Factory settings](#)


17.14 Digital inputs/outputs

Pump variant	Digital inputs/outputs
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Function	Terminal ⁵⁾
Digital input/output 3, setup	10 and 16
Digital input/output 4, setup	11 and 18

5) See section Connection terminals, advanced functional module, FM 300.

You can select if the interface must be used as input or output. The output is an open collector and you can connect it to for example an external relay or controller such as a PLC.



Example of configurable digital inputs or outputs

Pos.	Description
1	External controller

To set a digital input or output, make the settings below.

Mode

You can set the digital input or output 3 and 4 to act as digital input or digital output:

- **Digital input**
- **Digital output.**

Function

You can set the digital input or output 3 and 4 to the functions mentioned below.

You can set the signal outputs to the following:

- **Operation**
- **Pump running**
- **Ready**
- **Alarm**
- **Warning.**

Possible functions, digital input or output 3

Function if input See details in section Digital inputs	Function if output See details in section "Signal relays 1 and 2" (Relay outputs)
<ul style="list-style-type: none"> • Not active • External stop • Min. • Max. • "User-defined speed" • External fault • Alarm resetting • Dry running • Accumulated flow • "Predefined setpoint 2" • "Activate output" • "Local motor stop" 	<ul style="list-style-type: none"> • Not active • Ready • Alarm • Operation • Pump running • Warning • Limit 1 exceeded • Limit 2 exceeded • "Digital input 1, state" • "Digital input 2, state" • "Digital input 3, state" • "Digital input 4, state"

Possible functions, digital input or output 4

Function if input See details in section Digital inputs	Function if output See details in section "Signal relays 1 and 2" (Relay outputs)
<ul style="list-style-type: none"> • Not active • External stop • Min. • Max. • "User-defined speed" • External fault • Alarm resetting • Dry running • Accumulated flow • "Predefined setpoint 3" • "Activate output" • "Local motor stop" 	<ul style="list-style-type: none"> • Not active • Not active • Ready • Alarm • Operation • Pump running • Warning • Limit 1 exceeded • Limit 2 exceeded • "Digital input 1, state" • "Digital input 2, state" • "Digital input 3, state" • "Digital input 4, state"

Activation delay

Pump variant	Activation delay
TPE3, TPE3 D	-
TPE2, TPE2 D	•

Select the activation delay, T1.

It is the time between the digital signal and the activation of the selected function.

Range: 0 to 6000 seconds.

Duration timer mode


Select the mode. See figure Duration timer function of digital inputs.

- **Not active**
- active with interrupt, mode A
- active without interrupt, mode B
- active with after-run, mode C.

Select the duration time, T2.

It is the time which, together with the mode, determines how long the selected function is active.

Range: 0 to 15,000 seconds.



TM064949

Duration timer function of digital inputs

Pos.	Description
1	Mode C
2	Mode B
3	Mode A
4	Digital input
5	T input > T1 + T2
6	T input < T1 + T2
7	T input
8	T input

Factory setting

See section Factory settings.

Related information

[9.5.1 Connection terminals, advanced functional module, FM 300](#)

[17.13 Digital inputs](#)

[17.15 "Signal relays 1 and 2" \(Relay outputs\)](#)

[35. Factory settings](#)

17.15 "Signal relays 1 and 2" (Relay outputs)

Pump variant	"Signal relays 1 and 2"
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Function	Terminal ⁶⁾
Relay output 1	NC, C1, NO
Relay output 2	NC, C2, NO

⁶⁾ See section Connection terminals, advanced functional module, FM 300.

The pump incorporates two signal relays for potential-free signalling. For further information, see section Signal relays.

Function

You can configure the signal relays to be activated by one of the following incidents:

- **Not active.**
- **Ready**
The pump can be running or is ready to run and no alarms are present.
- **Alarm**
There is an active alarm and the pump is stopped.
- **"Operating" (Operation)** "Operating" equals "Running" but the pump is still in operation when it has been stopped due to a warning.
- **"Running" (Pump running)**
- **Warning**
There is an active warning.
- **"Digital input 1, state"**
Follows digital input 1. If digital input 1 is activated, output is also activated.
- **"Digital input 2, state"**
Follows digital input 2. If digital input 2 is activated, output is also activated.
- **"Digital input 3, state"**
Follows digital input 3. If digital input 3 is activated, output is also activated.
- **"Digital input 4, state"**
Follows digital input 4. If digital input 4 is activated, output is also activated.
- **Limit 1 exceeded**
When the **Limit 1 exceeded** function is activated, the signal relay is activated. See section Limit-exceeded function.
- **Limit 2 exceeded**

When the **Limit 2 exceeded** function is activated, the signal relay is activated. See section Limit-exceeded function.

- **Relubricate**
- External fan control (**Control of external fan**)

When you select "External fan control", the relay is activated if the internal temperature of the motor electronics reach a preset limit value.

Factory setting

See section Factory settings.

Related information

[9.5.1 Connection terminals, advanced functional module, FM 300](#)

[17.22 Limit-exceeded function](#)

[22. Signal relays](#)

[35. Factory settings](#)

17.16 Analog output

Pump variant	Analog output
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Function	Terminal ⁷⁾
Analog output	12

⁷⁾ See section Connection terminals, advanced functional module, FM 300.

The analog output enables the transfer of certain operating data to external control systems.

To set the analog output, make the settings below.

Output signal

- **0-10 V**
- **0-20 mA**
- **4-20 mA.**

Function of analog output

- **Actual speed**

Signal range [V, mA]	Actual speed [%]		
	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of nominal speed.

- **Actual value**

Signal range [V, mA]	Actual value	
	Sensor _{min}	Sensor _{max}
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the range between sensor_{min} and sensor_{max}.

- **Resulting setpoint**

Signal range [V, mA]	Resulting setpoint [%]	
	0	100
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the external setpoint range.

- **Motor load**

Signal range [V, mA]	Motor load [%]	
	0	100
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the maximum permissible load at the actual speed.

- **Motor current**

Signal range [V, mA]	Motor current [%]		
	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the rated current (I_N).

- **Limit 1 exceeded** and **Limit 2 exceeded**

Signal range [V, mA]	Limit-exceeded function	
	Output not active	Output active
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The **Limit-exceeded function** is typically used for monitoring of secondary parameters in the system. If the limit is exceeded, an output, warning or alarm is activated.

- **Flow rate**

Signal range [V, mA]	Flow rate [%]		
	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the nominal flow.

Factory setting

See section Factory settings.

Related information

[9.5.1 Connection terminals, advanced functional module, FM 300](#)

[35. Factory settings](#)

17.17 Controller (Controller settings)

Pump variant	Controller (Controller settings)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The pumps have a factory setting of gain, K_p and integral time, T_i .

However, if the factory setting is not the optimum setting, you can change the gain and the integral time:

- Set the gain within the range from 0.1 to 20.
- Set the integral time within the range from 0.1 to 3600 seconds.

If you select 3600 seconds, the controller functions as a P controller.

Furthermore, you can set the controller to inverse control.

This means that if the setpoint is increased, the speed is reduced. In the case of inverse control, set the gain within the range from -0.1 to -20.

Guidelines for setting of PI controller

The tables below show the recommended controller settings:

Differential-pressure control	K_p	T_i
	0.5	0.5
	0.5	L1 < 5 m: 0.5 L1 > 5 m: 3 L1 > 10 m: 5

L1: distance in metres between pump and sensor.

Temperature control	K_p		T_i
	Heating system ⁸⁾	Cooling system ⁹⁾	
	0.5	-0.5	10 + 5L2
	0.5	-0.5	30 + 5L2

⁸⁾ In heating systems, an increase in pump performance results in a rise in temperature at the sensor.

⁹⁾ In cooling systems, an increase in pump performance results in a drop in temperature at the sensor.

L2: distance in metres between heat exchanger and sensor.


Differential-temperature control	K_p	T_i
	-0.5	10 + 5L2

L2: distance in metres between heat exchanger and sensor.

Flow control	K_p	T_i
	0.5	0.5

Constant-pressure control	K_p	T_i
	0.5	0.5
	0.1	0.5

Level control	K_p	T_i
	-2.5	100

Level control	K_p	T_i
	2.5	100

Rules of thumb

If the controller is too slow-reacting, increase the gain.

If the controller is hunting or unstable, dampen the system by reducing the gain or increasing the integral time.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)


17.18 Operating range

Pump variant	Operating range
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Set the operating range as follows:

- Set the minimum speed within the range from fixed minimum speed to user-set maximum speed.
- Set the maximum speed within the range from user-set minimum speed to fixed maximum speed.

The range between the user-set minimum and maximum speeds is the operating range.



Example of minimum and maximum settings

Speeds below 25 % may result in noise from the shaft seal.

Pos.	Description
1	Fixed maximum speed
2	User-set maximum speed
3	Operating range
4	User-set minimum speed
5	Fixed minimum speed

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.19 External setpoint function

Pump variant	External setpoint function
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can influence the setpoint by an external signal, either via one of the analog inputs or, if an advanced functional module is fitted, via one of the Pt100/1000 inputs.



Before you can enable the **External setpoint function**, you must set one of the analog inputs or Pt100/1000 inputs to **Setpoint influence**.


See sections Analog inputs and Pt100/1000 inputs.

If more than one input has been set to **Setpoint influence**, the function selects the analog input with the lowest number, for example **Setting of pump**, and ignores the other inputs, for example **Analog input 3** or "Pt100/1000 input 1".

Example with constant pressure with linear influence

Actual setpoint: actual input signal x (setpoint - sensor min.) + sensor min.

At a lower sensor value of 0 bar, a setpoint of 2 bar and an external setpoint of 60 %, the actual setpoint is $0.60 \times (2 - 0) + 0 = 1.2$ bar.



TM064165

Example of setpoint influence with sensor feedback

Pos.	Description
A	Actual input signal, 60 %
B	External setpoint signal
C	Setpoint


Pos.	Description
D	Sensor max.
E	Sensor min.
F	Actual Setpoint

Example with constant curve with linear influence

Actual setpoint: actual input signal x (setpoint - user-set minimum speed) + user-set minimum speed.

At a user-set minimum speed of 25 %, a setpoint of 85 % and an external setpoint of 60 %, the actual setpoint is $0.60 \times (85 - 25) + 25 = 61$ %. See figure Example of setpoint influence with constant curve.

In some cases, the maximum curve is limited to a lower speed. See figure Power and pressure limitations influencing the maximum curve.



TM064525

Example of setpoint influence with constant curve

Pos.	Description
A	External setpoint signal
B	Speed [%]
C	Fixed maximum speed
D	Actual input signal, 60 %
E	User-set min. speed
F	Setpoint
G	Actual setpoint

Factory setting

See section Factory settings.

Related information

- 17.6.11 Constant curve
- 17.10 Analog inputs
- 17.12 Pt100/1000 inputs
- 35. Factory settings

17.19.1 Setpoint influence


Pump variant	Setpoint influence
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The table below gives an overview of the types of setpoint influence and the availability depending on pump type.

Setpoint influence	Pump type	
	TPE3 TPE3 D	TPE2 TPE2 D
Not active	•	•
Linear function	•	•
Linear with Stop	•	•
Influence table	•	•

You can select these functions:

- **Not active**
When set to **Not active**, the setpoint is not influenced from any external function.
- **Linear function**
The setpoint is influenced linearly from 0 to 100 %.




TM064166

Linear function

Pos.	Description
A	Setpoint influence [%]
B	External input

- **Linear with Stop**
 - In the input signal range from 20 to 100 %, the setpoint is influenced linearly.
 - If the input signal is below 10 %, the pump changes to operating mode **Stop**.
 - If the input signal is above 15 %, the operating mode is changed back to **Normal**.




TM064167

Linear with Stop

Pos.	Description
A	Setpoint influence [%]
B	External input
C	Normal
D	Stop

- **Influence table**
The setpoint is influenced by a curve made out of two to eight points. There will be a straight line between the points and a horizontal line before the first point and after the last point.



TM064170

Influence table, example with five points

Pos.	Description
A	Setpoint influence [%]
B	External input

17.20 Predefined setpoints

Pump variant	Predefined setpoints
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can set and activate seven predefined setpoints by combining the input signals to digital inputs 2, 3 and 4 as shown in the table below.

Set the digital inputs 2, 3 and 4 to "Predefined setpoints" if all seven predefined setpoints are to be used. You can also set one or two of the digital inputs to "Predefined setpoints" but this will limit the number of predefined setpoints available.


Digital inputs			Setpoint
2	3	4	
0	0	0	Normal setpoint or stop
1	0	0	Predefined setpoint 1
0	1	0	Predefined setpoint 2
1	1	0	Predefined setpoint 3
0	0	1	Predefined setpoint 4
1	0	1	Predefined setpoint 5
0	1	1	Predefined setpoint 6
1	1	1	Predefined setpoint 7

0: Open contact

1: Closed contact

Example

The figure below shows how you can use the digital inputs to set seven predefined setpoints. Digital input 2 is open and digital inputs 3 and 4 are closed. If you compare with the table above, you can see that "Predefined setpoint 6" is activated.



TM064269

Principle sketch showing how predefined setpoints function

Pos.	Description
SP	Set point
DI	Digital input
SP _a	Actual set point
SP _n	Normal set point

If all digital inputs are open, the pump either stops or runs at the normal setpoint. Set the desired action with Grundfos GO or with the advanced control panel.

Factory setting

See section Factory settings.

Related information


[35. Factory settings](#)

17.21 Temperature influence

Pump variant	Temperature influence
TPE3, TPE3 D	•
TPE2, TPE2 D	-

When this function is enabled in proportional- or constant-pressure control mode, the setpoint for head is reduced according to the liquid temperature.

You can set the temperature influence to function at liquid temperatures below 80 or 50 °C. These temperature limits are called T_{max} . The setpoint is reduced in relation to the head set which is equal to 100 % according to the characteristics below.



TM057911

Temperature influence

In the above example, T_{max} , which is equal to 80 °C, has been selected. The actual liquid temperature, T_{actual} , causes the setpoint for head to be reduced from 100 % to H_{actual} .

The temperature influence function requires the following:

- proportional-pressure or constant-pressure control mode
- pump installed in flow pipe
- system with flow-pipe temperature control.

Temperature influence is suitable for the following systems:

- Systems with variable flows, for example two-pipe heating systems, in which the enabling of the temperature influence function ensures a further reduction of the pump performance in periods with small heating demands and consequently a reduced flow-pipe temperature.
- Systems with almost constant flows, for example one-pipe heating systems and underfloor heating systems, in which variable heating demands cannot be registered as changes in the head as is the case with two-pipe heating systems. In such systems, you can only adjust the pump performance by enabling the temperature influence function.

Selecting the maximum temperature

In systems with a dimensioned flow-pipe temperature of:

- up to and including 55 °C, select T_{\max} . equal to 50 °C
- above 55 °C, select T_{\max} . equal to 80 °C.

You cannot use the temperature influence function in air-conditioning and cooling systems.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.22 Limit-exceeded function

Pump variant	Limit-exceeded function
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This function can monitor a measured parameter or one of the internal values such as speed, motor load or motor current. If a set limit is reached, a selected action can take place. You can set two limit-exceeded functions meaning that you can monitor two parameters or two limits of the same parameter simultaneously.

The function requires setting of the following:

Measured

Here you set the measured parameter to be monitored.

Limit

Here you set the limit which activates the function.

Hysteresis band

Here you set the hysteresis band.

Limit exceeded when

Here you can set if you want the function to be activated when the selected parameter exceeds or drops below the set limit.

- Above limit
The function is activated if the measured parameter exceeds the set limit.
- Below limit
The function is activated if the measured parameter drops below the set limit.

Action

If the value exceeds a limit, you can define an action. You can select the following actions:

- No action
The pump remains in its current state. Use this setting if you only want to have a relay output when the limit is reached. See section Signal relays 1 and 2 (Relay outputs).
- Warning/alarm
There is a warning.
- **Stop**
The pump stops.
- **Min.**
The pump reduces speed to minimum.
- **Max.**
The pump increases speed to maximum.
- User-defined speed
The pumps run at a speed set by the user.

Detection delay


You can set a detection delay which ensures that the monitored parameter stays above or below a set limit in a set time before the function is activated.

Resetting delay

The resetting delay is the time from which the measured parameter differs from the set limit including the set hysteresis band and until the function is reset.

Example

The function is to monitor the outlet pressure of a pump. If the pressure is below 5 bar for more than 5 seconds, a warning must be given. If the outlet pressure is above 7 bar for more than 8 seconds, you must reset the warning.



Limit exceeded (example)

Pos.	Setting parameter	Setting
1	Measured	Outlet pressure
2	Limit	5 bar
3	Hysteresis band	2 bar
4	Limit exceeded when	Below limit
5	Detection delay	5 seconds
6	Resetting delay	8 seconds
A	Limit-exceeded function active	-
-	Action	Warning

Factory setting

See section Factory settings.

Related information

[17.15 "Signal relays 1 and 2" \(Relay outputs\)](#)

[35. Factory settings](#)

17.23 Pulse flowmeter setup

Pump variant	Pulse flowmeter setup
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can connect an external pulse flowmeter to one of the digital inputs in order to register the actual and accumulated flows. Based on this, you can also calculate the specific energy.

To enable a pulse flowmeter, set one of the digital inputs to **Accumulated flow** and set the pumped volume per pulse. See section Digital inputs.

Factory setting

See section Factory settings.

Related information

[17.13 Digital inputs](#)

[35. Factory settings](#)

17.24 Ramps

Pump variant	Ramps
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The ramps determine how quickly the motor can accelerate and decelerate, during start-stop or setpoint changes.


You can set the following:

- acceleration time, 0.1 to 300 seconds
- deceleration time, 0.1 to 300 seconds.

The times apply to the acceleration from 0 rpm to fixed maximum speed and the deceleration from fixed maximum speed to 0 rpm.

At short deceleration times, the deceleration of the motor may depend on load and inertia as there is no possibility of actively braking the motor.

If the power supply is switched off, the deceleration of the motor only depends on load and inertia.



TM039439

Ramp-up and ramp-down

Pos.	Description
A	Speed
B	Time
1	Fixed maximum
2	User set maximum
3	User set minimum
4	Fixed initial ramp
5	Fixed final ramp
6	User set ramp-up
7	User set ramp-down

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.25 Standstill heating

Pump variant	Standstill heating
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can use this function to avoid condensation in humid environments. When you set the function to **Active** and the pump is in operating mode **Stop**, a low AC voltage will be applied to the motor windings. The voltage is not high enough to make the motor rotate but ensures that sufficient heat is generated to avoid condensation in the motor including the electronic parts in the drive.



Remember to remove the drain plugs and fit a cover over the motor.

For further information, see section Outdoor installation.

Factory setting

See section Factory settings.

Related information

[8.9 Outdoor installation](#)

[35. Factory settings](#)

17.26 Motor bearing monitoring

Pump variant	Motor bearing monitoring
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can set the motor bearing monitoring function to these values:

- **Active**
- **Not active.**

When the function is set to **Active**, a counter in the controller will start counting the mileage of the bearings.

When the function is changed to "Active" again, the accumulated mileage is again used to calculate the replacement time.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.27 Service

Pump variant	Service
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Time until next service (Motor bearing service)

This display shows when to replace the motor bearings. The controller monitors the operating pattern of the motor and calculates the period between bearing replacements.

Displayable values:

- in 2 years
- in 1 year
- in 6 months
- in 3 months
- in 1 month
- in 1 week
- Now.

Bearing replacements

Indicates the number of bearing replacements that have been done during the lifetime of the motor.

Bearings replaced (Motor bearing maintenance)

When the bearing monitoring function is active, the controller gives a warning when the motor bearings are to be replaced.

When you have replaced the motor bearings, confirm this action by pressing [Bearings replaced].

17.28 Number (Pump number)

Pump variant	Number (Pump number)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can allocate a unique number to the pump. This makes it possible to distinguish between pumps in connection with bus communication.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.29 Radio communication (Enable/disable radio comm.)

Pump variant	Radio communication (Enable/disable radio comm.)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can set the radio communication to either enabled or disabled. You can use this function in areas where radio communication is not allowed. IR communication remains active.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.30 Language

Pump variant	Language
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

In this menu you can select the desired language. A number of languages are available.

17.31 Date and time (Set date and time)

Pump variant	Date and time (Set date and time)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

You can set date and time as well as how they are to be shown in the display:

- **Select date format:**
YYYY-MM-DD
DD-MM-YYYY
MM-DD-YYYY.
- **Select time format:**
HH:MM 24-hour clock
HH:MM am/pm 12-hour clock.
- **Set date**
- **Set time.**

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.32 Unit configuration (Units)

Pump variant	Unit configuration
TPE3, TPE3 D	•
TPE2, TPE2 D	•

In this menu you can select between SI and US units. The setting can be made generally for all parameters or customised for each individual parameter.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.33 "Buttons on product" (Enable/disable settings)

Pump variant	"Buttons on product" (Enable/disable settings)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

In this display, you can disable the possibility of making settings.

Grundfos GO

If you set the buttons to "Not active", the buttons on the standard control panel are disabled. If you set the buttons to "Not active" on pumps with an advanced control panel, see below.

Advanced control panel

If you have disabled the settings, you can still use the buttons to navigate through the menus but you cannot make changes in the **Settings** menu.

When you have disabled the possibility to make settings, the **0** symbol appears in the display.

To unlock the pump and allow settings, press **0** and **0** simultaneously for at least 5 seconds.

Standard control panel

The **0** button always remains active but you can only unlock all other buttons on the pump with Grundfos GO.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.34 Delete history

Pump variant	Delete history
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

In this menu, you can delete the following historic data:

- Delete work log.
- Delete heat energy data.
- Delete energy consumption.

17.35 Define Home display

Pump variant	Define Home display
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

In this menu, you can set the **Home** display to show up to four user-set parameters.

17.36 Display settings

Pump variant	Display settings
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

In this menu you can adjust the display brightness and set whether or not the display is to turn off if no buttons have been activated for a period of time.

17.37 Store settings (Store actual settings)

Pump variant	Store actual settings
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Grundfos GO

In this menu, you can store the actual settings for later use in the same pump or in other pumps of the same type.

Advanced control panel

In this menu, you can store the actual settings for later use in the same pump.

17.38 Recall settings (Recall stored settings)

Pump variant	Recall settings (Recall stored settings)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

Grundfos GO

In this menu, you can recall stored settings from a number of previously stored settings that the pump then uses.

Advanced control panel

In this menu, you can recall the last stored settings that the pump then uses.

17.39 Undo

Pump variant	Undo
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in Grundfos GO.

In this display, you can undo all settings that have been made with Grundfos GO in the current communication session. You cannot undo a **Recall stored settings** action.

17.40 Pump name

Pump variant	Pump name
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in Grundfos GO.

In this display, you can give the pump a name. In this way, you can easily identify the pump when connecting with Grundfos GO.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.41 Connection code

Pump variant	Connection code
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in Grundfos GO.

You can set a connection code to avoid having to press the connection button each time and to restrict remote access to the product.

Setting the code in the product using Grundfos GO

1. Connect Grundfos GO to the product.
2. In the product dashboard, select "Settings".
3. Choose "Connection code".
4. Enter the wanted code and press [OK]. The code must be a character string, ASCII. You can always modify the code. The old code is not needed.

Setting the code in Grundfos GO

You can set a default connection code in Grundfos GO so that it automatically attempts to connect to the selected product via this code.

When you select a product with the same connection code in Grundfos GO, Grundfos GO automatically connects to the product and you do not have to press the connection button on the module.

Set the default code in Grundfos GO in this way:

1. In the main menu, under "General", select "Settings".
2. Choose "Remote".
3. Enter the connection code in the field "Preset connection code". The field now says "Connection code set".

You can always modify the default connection code by pressing [Delete] and entering a new one.

If Grundfos GO fails to connect and ask you to press the connection button on the product, it means that the product has no connection code or has a different connection code. In this case, you can only establish connection via the connection button.

After setting a connection code, you must switch off the product until the light in Grundfos Eye turns off before you can use the new connection code.

Factory setting

See section Factory settings.

Related information

[35. Factory settings](#)

17.42 Run start-up guide

Pump variant	Run start-up guide
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

The startup guide automatically starts when you start the pump for the first time.

You can always run the startup guide later via this menu.

The startup guide guides you through the general settings of the pump.

- **Language.** See section Language.
- **Select date format.***
See section "Date and time" (Set date and time).
- **Set date.***
See section "Date and time" (Set date and time).
- **Select time format.***
See section "Date and time" (Set date and time).
- **Set time.***
See section "Date and time" (Set date and time).
- **Setting of pump**
 - **Go to Home.**
 - **Run with Constant curve/Run with Constant pressure.**
See section Control mode.
 - **Go to "Assisted pump setup".**
See section Assisted pump setup.
 - **Return to factory settings.**

* Applies only for pumps with advanced functional module, FM 300. For further information, see section Identification of functional module.

Related information

[17.6 Control mode](#)

[17.30 Language](#)

[17.31 Date and time \(Set date and time\)](#)

[24. Identification of functional module](#)

17.43 Alarm log

Pump variant	Alarm log
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu contains a list of logged alarms from the product. The log shows the name of the alarm, when the alarm occurred and when it was reset.

17.44 Warning log

Pump variant	Warning log
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu contains a list of logged warnings from the product. The log shows the name of the warning, when the warning occurred and when it was reset.

17.45 Assist

Pump variant	Assist
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The menu consist of functions which take you through the steps needed to set the pump.

17.46 Assisted pump setup

Pump variant	Assisted pump setup
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The menu guides you through the following:

Setting of pump

- Selection of control mode. See section Control mode.
- Configuration of feedback sensors.
- Adjusting the setpoint. See section Setpoint.
- Controller settings. See section "Controller"("Controller settings").
- Summary of settings.

Example of how to use the Assisted pump setup for setting up the pump to constant pressure:

Grundfos GO

1. Open the **Assist** menu.
2. Select **Assisted pump setup**.
3. Select the control mode "Constant pressure".
4. Read the description of this control mode.
5. Select which analog input to use as sensor input.
6. Select sensor function according to where the sensor is installed in the system. See figure Overview of sensor locations in section Analog inputs.
7. Select electrical input signal according to the sensor specifications.
8. Select measuring unit according to the sensor specifications.
9. Set the minimum and maximum sensor values according to the sensor specifications.
10. Set the desired setpoint.
11. Set the controller settings K_p and T_i . See the recommendations in section "Controller"("Controller settings").
12. Type the pump name.
13. Check the summary of settings and confirm them.

Advanced control panel

1. Open the **Assist** menu.
2. Select **Assisted pump setup**.
3. Select the control mode **Const. pressure**.
4. Select which analog input to be used as sensor input.
5. Select the measured parameter to be controlled. See figure Overview of sensor locations in section Analog inputs.
6. Select measuring unit according to the sensor specifications.

7. Set the minimum and maximum sensor values according to the sensor specifications.
8. Select electrical input signal according to the sensor specifications.
9. Set the setpoint.
10. Set the controller settings K_p and T_i . See recommendations in section "Controller"("Controller settings").
11. Check the summary of settings and confirm them by pressing [OK].

Related information

[17.2 Setpoint](#)

[17.6 Control mode](#)

[17.10 Analog inputs](#)

[17.17 Controller \(Controller settings\)](#)

17.47 Setup, analog input

Pump variant	Setup, analog input
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

The menu guides you through the following:

Setup, analog input

- Analog inputs 1 to 3. See section Analog inputs.
- Pt100/1000 input 1 and 2. See section Pt100/1000 inputs.
- Adjusting the setpoint. See section Setpoint.
- Summary.

Related information

[17.2 Setpoint](#)

[17.10 Analog inputs](#)

[17.12 Pt100/1000 inputs](#)

17.48 Setting of date and time

Pump variant	Setting of date and time
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu guides you through the following:

- **Select date format.** See section "Date and time" (Set date and time).
- **Set date.** See section "Date and time" (Set date and time).
- **Select time format.** See section "Date and time" (Set date and time).
- **Set time.** See section "Date and time" (Set date and time).

Related information

[17.31 Date and time \(Set date and time\)](#)

17.49 Multipump setup (Setup of multi-pump system)

Pump variant	Multipump setup (Setup of multi-pump system)
TPE3, TPE3 D	•
TPE2, TPE2 D	•

The multipump function enables the control of two pumps connected in parallel without the use of external controllers. The pumps in a multipump system communicate with each other via the wireless GENlair connection or the wired GENI connection.

A multipump system is set via a selected pump, such as the master pump which is the first selected pump.

If two pumps in the system are configured with an outlet-pressure sensor, both pumps can function as master pumps and take over the master pump function if the other fails. This provides additional redundancy in the multipump system.

The multipump functions are described in the following sections.

17.49.1 Alternating operation

Alternating operation functions as a duty-standby operating mode and is possible with two pumps of same size and type connected in parallel. The main purpose of the function is to ensure an even amount of running hours and to ensure that the standby pump takes over if the running pump stops due to an alarm.

Each pump requires a non-return valve in series with the pump.

You can choose between two alternating operation modes:

- Alternating operation, time Pump changeover to the other is based on time.
- Alternating operation, energy Pump changeover to the other is based on energy consumption.

If the duty pump fails, the other pump takes over automatically.

17.49.2 Backup operation

Backup operation is possible with two pumps of same size and type connected in parallel. Each pump requires a non-return valve in series with the pump.

One pump is operating continuously. The backup pump is operated for a short time each day to prevent seizing up. If the duty pump stops due to a fault, the backup pump starts automatically.

17.49.3 Cascade operation

Cascade operation ensures that the pump performance is automatically adapted to the consumption by switching pumps on or off. The system thus runs as energy-efficiently as possible with a constant pressure and a limited number of pumps.

When a twin-head pump is running in constant-pressure control mode, the second pump head starts at 90 % and stops at 50 % performance.

All pumps in operation run at equal speed. Pump changeover is automatic and depends on energy, operating hours and fault.

Pump system:

- Twin-head pump.
- Two to four single-head pumps connected in parallel.
The pumps must be of the same type and size. Each pump requires a non-return valve in series with the pump.

Set the control mode to **Const. pressure** or **Const. curve**. In constant curve all pumps will run at the same time.

This function is available with up to 4 motors installed in parallel. The motors must be of the same size and the pumps must be of the same model.

- The performance is adjusted to the demand through cutting pumps in or out and through parallel control of the pumps in operation.
- The controller maintains a constant pressure through continuous adjustment of the speed of the pumps.
- Pump changeover is automatic and depends on load, operating hours and fault detection.
- All pumps in operation run at the same speed.
- The number of pumps in operation also depends on the energy consumption of the pumps. If only one pump is required, two pumps will run at a lower speed if this results in a lower energy consumption.
- If several motors in the system have a sensor, they can all function as master and take over the master function if the other motors fail.

17.49.4 "Sensor to be used"

Define the sensor to be used for controlling the pump system. If a sensor is placed in a way that it is able to measure the sensor output from all pumps in the system, for example, in the manifold, then select "Master pump sensor".

If a sensor is placed on, or across the individual pumps, for example, installed behind non-return valves and not able to measure the sensor output from all pumps, then select "Running pump sensor".

17.49.5 Setting a multipump system

You can set a multipump system in the following ways:

- Grundfos GO and wireless pump connection
- Grundfos GO and wired pump connection
- Advanced control panel and wireless pump connection
- Advanced control panel and wired pump connection..

See step-by-step descriptions below.

Grundfos GO and wireless pump connection

1. Power on both pumps.
2. Establish contact to one of the pumps with Grundfos GO.
3. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section Assisted pump setup.
4. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
5. Disconnect Grundfos GO from the pump.
6. Establish contact to the other pump.
7. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section Assisted pump setup.
8. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
9. Select the "Assist" menu and "Multipump setup".
10. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
11. Press [➤] to continue.
12. Set the time for pump changeover such as the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
13. Press [➤] to continue.
14. Select "Radio" as the communication method to be used between the two pumps.
15. Press [➤] to continue.
16. Press "Select pump 2".
17. Select the pump from the list. Use the [OK] or Ⓞ button to identify the pump.
18. Press [➤] to continue.

19. Confirm the multipump setup by pressing [Send].
20. Press [Finish] in the "Setup complete" dialog box.
21. Wait for the green indicator light in the middle of Grundfos Eye to light up.

The multipump system has now been set.

Grundfos GO and wired pump connection

1. Connect the two pumps with each other with a 3-core screened cable between the GENibus terminals A, Y, B.
2. Power on both pumps.
3. Establish contact to one of the pumps with Grundfos GO.
4. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section Assisted pump setup.
5. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
6. Assign pump number 1 to the pump. See section "Number" (Pump number).
7. Disconnect Grundfos GO from the pump.
8. Establish contact to the other pump.
9. Set the needed analog and digital inputs via Grundfos GO according to the connected equipment and the required functionality. See section Assisted pump setup.
10. Assign a pump name to the pump using Grundfos GO. See section "Pump name".
11. Assign pump number 2 to the pump. See section "Number" (Pump number).
12. Select the "Assist" menu and choose "Multipump setup".
13. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
14. Press [>] to continue.
15. Set the time for pump changeover such as the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
16. Press [>] to continue.
17. Select "BUS cable" as the communication method to be used between the two pumps.
18. Press [>] to continue.
19. Press "Select pump 2".
20. Select the additional pump from the list. Use the [OK] or Ⓞ button to identify the pump.
21. Press [>] to continue.
22. Press [Send].
23. Press [Finish] in the "Setup complete" dialog box.
24. Wait for the green indicator light in the middle of Grundfos Eye to light up.

The multipump system has now been set.

Advanced control panel and wireless pump connection

1. Power on both pumps.
2. On both pumps, set the needed analog and digital inputs according to the connected equipment and the required functionality. See section Assisted pump setup.
3. Select the **Assist** menu on one of the pumps and choose **Setup of multi-pump system**.
4. Press [>] to continue.
5. Select **Wireless** as the communication method to be used between the two pumps.
6. Press [>] to continue.
7. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
8. Press [>] three times to continue.
9. Press [OK] to search for other pumps. The green indicator light in the middle of Grundfos Eye flashes on the other pumps.
10. Press the connect button on the pump which is to be added to the multipump system.
11. Press [>] to continue.
12. Set the time for pump changeover such as the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
13. Press [>] to continue.
14. Press [OK]. The multipump function icons appear in the bottom of the control panels.

The multipump system has now been set.

Advanced control panel and wired pump connection

1. Connect the two pumps with each other with a 3-core screened cable between the GENibus terminals A, Y, B.
2. Set the needed analog and digital inputs according to the connected equipment and the required functionality. See section Assisted pump setup.
3. Assign pump number 1 to the first pump. See section "Number" (Pump number).
4. Assign pump number 2 to the other pump. See section "Number" (Pump number).
5. Select the **Assist** menu on one of the pumps and choose **Setup of multi-pump system**.
6. Press [>] to continue.
7. Select **Wired GENibus** as the communication method to be used between the two pumps.
8. Press [>] twice to continue.
9. Select the desired multipump function. See sections Alternating operation, Backup operation and Cascade operation.
10. Press [>] to continue.
11. Press [OK] to search for other pumps.
12. Select the additional pump from the list.
13. Press [>] to continue.
14. Set the time for pump changeover such as the time at which the alternation between the two pumps is to take place. This step applies only if you have selected "Alternating operation, time" and if the pumps are fitted with FM 300.
15. Press [>] to continue.
16. Press [OK]. The multipump function icons will appear in the bottom of the control panels.

The multipump system has now been set.

Disabling the multipump function via Grundfos GO

1. Select the "Assist" menu.
2. Select "Multipump setup".
3. Select "Disable".
4. Press [>] to continue.
5. Confirm the multipump setup by pressing [Send].
6. Press [Finish].

The multipump function has now been disabled.

Disabling a multipump via advanced control panel

1. Select the **Assist** menu.
2. Select **Setup of multi-pump system**.
3. Press [>] to continue.
4. Confirm **No multi-pump function** by pressing [OK].
5. Press [>] to continue.
6. Press [OK].

The multipump system has now been disabled.

Related information

[17.28 Number \(Pump number\)](#)

[17.40 Pump name](#)

[17.46 Assisted pump setup](#)

[17.49.1 Alternating operation](#)

[17.49.2 Backup operation](#)

[17.49.3 Cascade operation](#)

17.50 Description of control mode

Pump variant	Description of control mode
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu is only available in the advanced control panel.

This menu describes each of the possible control modes. See also section Control mode.

Related information

[17.6 Control mode](#)

17.51 Assisted fault advice

Pump variant	Assisted fault advice
TPE3, TPE3 D	•
TPE2, TPE2 D	•

This menu gives guidance and corrective actions in case of pump failures.

18. Selecting control mode

System application

Recommended for most heating systems, especially in systems with relatively large pressure losses in the distribution pipes. See the description under proportional pressure.


In replacement situations where the proportional-pressure duty point is unknown.

The duty point has to be within the AUTOADAPT operating range. During operation, the pump automatically adjusts to the actual system characteristic.

This setting ensures minimum energy consumption and low noise level from valves, which reduces operating costs and increases comfort.

Select this control mode

AUTOADAPT



The FLOWADAPT control mode is a combination of AUTOADAPT and FLOWLIMIT.

This control mode is suitable for systems where you want a maximum flow limit, FLOWLIMIT. The pump continuously monitors and adjusts the flow, thus ensuring that the selected FLOWLIMIT is not exceeded.

Main pumps in boiler applications where a steady flow through the boiler is required. No extra energy is used for pumping too much liquid into the system.

In systems with mixing loops, you can use the control mode to control the flow in each loop.


Benefits

- Enough water for all loops at peak load conditions if you have set each loop to the right maximum flow.
- The dimensioned flow for each zone, required heat energy, is determined by the flow from the pump.

You can set this value precisely in the FLOWADAPT control mode without the use of throttling valves.

- When the flow is lower than the balancing valve setting, the pump ramps down instead of losing energy by pumping against a balancing valve.
- Cooling surfaces in air-conditioning systems can operate at high pressure and low flow.


FLOWADAPT



In systems with relatively large pressure losses in the distribution pipes and in air-conditioning and cooling systems.

- Two-pipe heating systems with thermostatic valves and the following:
 - very long distribution pipes
 - strongly throttled balancing valves
 - differential-pressure regulators
 - large pressure losses in those parts of the system through which the total quantity of water flows, for example boiler, heat exchanger and distribution pipe up to the first branching.
- Primary circuit pumps in systems with large pressure losses in the primary circuit.
- Air-conditioning systems with the following:
 - heat exchangers, fan coils
 - cooling ceilings
 - cooling surfaces.

Proportional pressure




System application**Select this control mode**

In systems with relatively small pressure losses in the distribution pipes.

- Two-pipe heating systems with thermostatic valves and the following:
 - sized for natural circulation
 - small pressure losses in those parts of the system through which the total quantity of water flows, for example boiler, heat exchanger and distribution pipe up to the first branching or modified to a high differential temperature between flow pipe and return pipe, for example district heating.
- Underfloor heating systems with thermostatic valves.
- One-pipe heating systems with thermostatic valves or balancing valves.
- Primary circuit pumps in systems with small pressure losses in the primary circuit.

Constant differential pressure




In systems with a fixed system characteristic.

Examples

- one-pipe heating systems
- boiler shunts
- systems with three-way valves
- domestic hot-water circulation.

You can use FLOWLIMIT with advantage to control the maximum circulation flow.

Constant temperature and constant differential temperature




If an external controller is installed, the pump is able to change from one constant curve to another, depending on the external signal.

You can also set the pump to operate according to the maximum or minimum curve, like an uncontrolled pump:

- Use the maximum-curve mode in periods in which a maximum flow is required.
This operating mode is for instance suitable for hot-water priority.
- Use the minimum-curve mode in periods in which a minimum flow is required.

This operating mode is for instance suitable for manual night setback if you do not want automatic night setback.

Constant curve



System application


In systems requiring a constant flow, independently of pressure drop.

Examples

- chillers for air-conditioning
- heating surfaces
- cooling surfaces.

Select this control mode

Constant flow rate




In systems requiring a constant tank level, independently of the flow rate.

Examples

- process water tanks
- boiler condensate tanks.

Constant level



In systems with pumps connected in parallel.

The multipump function enables the control of two to four single-head pumps connected in parallel and twin-head pumps without the use of external controllers. The pumps in a multipump system communicate with each other via the wireless GENIair connection or the wired GENI connection.

Assist menu
Multipump setup

19. Bus signal

The pump supports serial communication via an RS-485 input. The communication is carried out according to Grundfos GENIbus protocol and enables connection to other pumps as well as a building management system or another external control system.




Via a bus signal, you can remote-set pump operating parameters, such as setpoint and operating mode. At the same time, the pump can, via the bus, provide status information about important parameters, such as actual value of control parameter, input power and fault indications.

Contact Grundfos for further information.



If you use a bus signal, the number of settings available via Grundfos GO are reduced.

20. Priority of settings

You can always set the pump to stop by pressing  on the pump control panel. When the pump is not in **Stop** mode, you can always stop the pump by continuously pressing . Furthermore, you can set the pump to maximum speed by continuously pressing . You can always set the pump to operation at maximum speed or to stop with Grundfos GO.

If two or more functions are enabled at the same time, the pump will operate according to the function with the highest priority.

Example

If you have set the pump to maximum speed via the digital input, the pump control panel or Grundfos GO can only set the pump to **Manual** or **Stop**.


The priority of the settings appears from the table below.

Priority	Start-stop button	Grundfos GO or control panel on the motor	Digital input	Bus communication
1	Stop			
2		Stop ¹⁰⁾		
3		Manual		
4		"Max. speed" ^{10)/ "User-defined speed"}		
5			Stop	
6			"User-defined speed"	
7				Stop
8				"Max. speed"
9				"Min. speed"
10				"Start"
11			"Max. speed"	
12		"Min. speed"		
13			"Min. speed"	
14			"Start"	
15		"Start"		

¹⁰⁾ "Stop" and "Max. speed" settings made with Grundfos GO or on the motor control panel can be overruled by another operating-mode command sent from a bus, for example "Start". If the bus communication is interrupted, the motor resumes its previous operating mode, for example "Stop", selected with Grundfos GO or on the motor control panel.

21. Grundfos Eye










The operating condition of the pump is indicated by Grundfos Eye on the control panel. See figure Grundfos Eye, A.



Grundfos Eye

TM055953

Grundfos Eye	Indication	Description
	No lights are on.	The power is off. The pump is not running.
	The two opposite green indicator lights are rotating in the direction of rotation of the pump when seen from the non-drive end.	The power is on. The pump is running.
	The two opposite green indicator lights are permanently on.	The power is on. The pump is not running.
	One yellow indicator light is rotating in the direction of rotation of the pump when seen from the non-drive end.	Warning. The pump is running.
	One yellow indicator light is permanently on.	Warning. The pump has stopped.
	The two opposite red indicator lights are flashing simultaneously.	Alarm. The pump has stopped.





























































Grundfos Eye	Indication	Description
	<p>The green indicator light in the middle flashes quickly four times.</p> 	<p>This is a feedback signal which the pump gives in order to ensure identification of itself.</p>
	<p>The green indicator light in the middle flashes continuously.</p> 	<p>Grundfos GO or another pump is trying to communicate with the pump. Press  on the pump control panel to allow communication.</p>
	<p>The green indicator light in the middle is permanently on.</p> 	<p>Remote control with Grundfos GO via radio.</p> <p>The pump is communicating with Grundfos GO via radio connection.</p>
	<p>The green indicator light in the middle flashes quickly while Grundfos GO is exchanging data with the pump. It takes a few seconds.</p> 	<p>Remote control with Grundfos GO via infrared light.</p> <p>The pump is receiving data from Grundfos GO via infrared communication.</p>

22. Signal relays

The pump has two outputs for potential-free signals via two internal relays.

You can set the signal outputs to **Operation, Pump running, Ready, Alarm** and **Warning**.

The functions of the two signal relays appear from the table below.

Description	Grundfos Eye	Contact position for signal relays when activated					Operating mode
		Operation	Pump running	Ready	Alarm	Warning	
The power is off.	 Off						-
The pump is running in Normal mode.	 Green, rotating						Normal, Min. or Max.
The pump runs in Manual mode.	 Green, rotating						Manual
The pump is in operating mode Stop .	 Green, steady						Stop
Warning, but the pump runs.	 Yellow, rotating						Normal, Min. or Max.
Warning, but the pump runs in Manual mode.	 Yellow, rotating						Manual
Warning, but the pump was stopped via Stop command.	 Yellow, steady						Stop
Alarm, but the pump runs.	 Red, rotating						Normal, Min. or Max.
Alarm, but the pump runs in Manual mode.	 Red, rotating						Manual
The pump has stopped due to an alarm.	 Red, flashing						Stop

23. Installing a communication interface module

DANGER Electric shock

Death or serious personal injury




- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.



Always use an antistatic service kit when handling electronic components. This prevents static electricity from damaging the components.


When unprotected, place the component on the antistatic cloth.



TM064462

Antistatic service kit


1. Loosen the four screws (A) and remove the terminal box cover (B).



TM064081

Removing the terminal box cover


2. Remove the CIM cover (A) by pressing the locking tab (B) and lifting the end of the cover (C). Then lift the cover off the hooks (D).



TM064084


Removing the CIM cover

3. Remove the securing screw (A).



Removing the securing screw


4. Fit the CIM module by aligning it with the three plastic holders (A) and the connecting plug (B). Press home the module using your fingers.



Fitting the CIM module


5. Fit and tighten the securing screw (A) to 1.3 Nm.
6. Make the electrical connections to the CIM module as described in the instructions delivered with the module.

7. Connect the cable screens of the bus cables to earth via one of the earth clamps (A).



Connecting the cable screens to earth


8. Route the wires for the CIM module. See the example below.



Example of wire routing

9. Fit the CIM cover.

10. If the CIM module is supplied with an FCC label, then place this on the terminal box.



TM057028

FCC label

11. Fit the terminal box cover (B) and cross-tighten the four mounting screws (A) to 6 Nm.



Make sure that the terminal box cover is aligned with the control panel. See section Changing the position of the control panel.

Related information

26. *Changing the position of the control panel*

24. Identification of functional module

You can identify the module in one of the following ways:

Grundfos GO


Select the **Fitted modules** menu under **Status**.

Pump display

If the pump is fitted with the advanced control panel, select **Fitted modules** menu under **Status**.

Motor nameplate

You can identify the fitted module on the motor nameplate.



TM051889

Identification of functional module

Variant	Description
FM 200	Standard functional module
FM 300	Advanced functional module

25. Identification of control panel

You can identify the module in one of the following ways:

Grundfos GO


Select the **Fitted modules** menu under **Status**.

Pump display

For pumps fitted with the advanced control panel, you can select the control panel in the **Fitted modules** menu under **Status**.

Motor nameplate

You can identify the control panel on the motor nameplate.



TM064013

Identification of control panel

Variant	Description
HMI 200	Standard control panel
HMI 300	Advanced control panel

26. Changing the position of the control panel

DANGER Electric shock


Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.


You can turn the control panel 180°. Follow the instructions below.

1. Loosen the four screws, TX25, of the terminal box cover.




Loosening the screws

2. Remove the terminal box cover.



Removing the terminal box cover

3. Press and hold in the two locking tabs, A, while gently lifting the plastic cover, B.




Lifting the plastic cover

4. Turn the plastic cover 180°.




Do not twist the cable more than 90°.




Turning the plastic cover

5. Position the plastic cover correctly on the four rubber pins, C. Make sure that the locking tabs, A, are placed correctly.



Positioning the plastic cover

6. Fit the terminal box cover, and make sure that it is also turned 180° so that the buttons on the control panel are aligned with the buttons on the plastic cover.
7. Tighten the four screws, TX25, with 5 Nm.



Fitting the terminal box cover

TM055354

TM055351

TM055355

TM055352

TM055356

TM055353

27. Servicing the product

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.

DANGER

Magnetic field

Death or serious personal injury



- Do not handle the motor or rotor if you have a pacemaker.

WARNING

Hazardous liquids

Death or serious personal injury



- If the pump is used for a liquid which is injurious to health, it will be classified as contaminated. In such cases, take proper precautions to avoid injury to health when operating or working on the pump.
- Wear personal protection equipment.

CAUTION

Hot or cold liquids

Minor or moderate personal injury



- Wear personal protection equipment.

CAUTION

Pressurised system

Minor or moderate personal injury



- Do not remove the ultrasonic flow sensor during service and maintenance.

CAUTION

Pressurised system

Minor or moderate personal injury



- Wear personal protective equipment.

27.1 Maintenance

27.1.1 Pump

The pump is maintenance-free.

If the pump is to be drained for a long period of inactivity, inject a few drops of silicone oil on the shaft between the motor stool and the coupling. This prevents the shaft seal faces from sticking.

27.1.2 Motor

If service is needed on the product, please contact Grundfos Service.

27.2 Service

If Grundfos is requested to service the pump, you must clean it before returning it. If you cannot clean the pump properly, then provide Grundfos with all relevant information about the pumped liquid.

If the above is not fulfilled, Grundfos can refuse to accept the pump for service.

Possible costs of returning the pump are to be paid by the customer.


27.2.1 Integral shaft and coupling

TPE2 and TPE3 pumps have integral shaft and coupling. We recommend that you do not remove the motor.

If you have removed the motor, you must remove the motor stool in order to refit the motor correctly. Otherwise the shaft seal may be damaged.

27.2.2 Blanking flanges

For twin-head pumps, a blanking flange with a pump housing gasket is available.



Fitting the blanking flange

If one pump requires service, fit the blanking flange to allow the other pump to continue operating.

28. Cleaning the product

WARNING

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Check that the terminal box cover is intact before spraying water on the product.

In order to avoid condensation in the motor, let the motor cool down before spraying it with cold water.

29. Fault finding

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.

DANGER

Magnetic field

Death or serious personal injury



- Do not handle the motor or rotor if you have a pacemaker.

WARNING

Hazardous liquids

Death or serious personal injury



- If the pump is used for a liquid which is injurious to health, it will be classified as contaminated. In such cases, take proper precautions to avoid injury to health when operating or working on the pump.
- Wear personal protection equipment.

CAUTION

Hot or cold liquids

Minor or moderate personal injury



- Wear personal protection equipment.

29.1 The motor does not run when started

Cause	Remedy
Supply failure.	Check the electrical connection. Remedy, if necessary.
The fuses are blown.	Replace the fuse.
The motor is defective.	Replace the motor.

29.2 Motor alarm when the power supply is switched on

Cause	Remedy
Supply failure.	Check the electrical connection. Remedy, if necessary.
The cable connection is loose or faulty.	Repair cable connection.
The motor winding is defective.	Repair the motor.
The pump is mechanically blocked.	Clean the pump.

29.3 Occasional motor alarm

Cause	Remedy
The supply voltage is periodically too low or too high.	Make sure the input supply voltage stable.

29.4 No motor alarm, but the pump does not run

Cause	Remedy
Check the power supply.	Make sure the power supply connected.
Check the fuses.	Replace the fuse, if defective.

29.5 The pump performance is not constant

Cause	Remedy
The pump inlet pressure is too low.	Increase the inlet pressure.
The inlet pipe or pump is partly is blocked by impurities.	Clean the inlet pipe or pump.

Cause	Remedy
The pump draws in air.	<ol style="list-style-type: none"> 1. Increase the liquid level on the inlet side. 2. Keep the liquid level as constant as possible. 3. Increase the inlet pressure.

29.6 The pump runs but delivers no water

Cause	Remedy
The inlet pipe or pump is blocked by impurities.	Clean the inlet pipe or pump.
The foot or non-return valve is blocked in closed position.	Repair the foot or non-return valve.
There is a leakage in the inlet pipe.	<p>Check the gaskets and bolts torque.</p> <p>Replace gaskets, if defective.</p>
There is air in the inlet pipe or pump.	Vent the inlet pipe or the pump.

29.7 The pump runs backwards when switched off

In twin-head pump installations, the backup pump often rotates slowly.

Cause	Remedy
There is a leakage in the inlet pipe.	<p>Check the gaskets and bolts torque.</p> <p>Replace gaskets, if defective.</p>
The foot or non-return valve is defective.	Replace the foot or non-return valve, if defective.
The foot or non-return valve is blocked in open or partly open position.	Repair the foot or non-return valve.

29.8 Leakage in shaft seal

Cause	Remedy
The shaft seal is defective.	Replace the shaft seal.

29.9 Noise

Cause	Remedy
The pump is cavitating.	Increase inlet pressure.
The pump does not rotate freely (frictional resistance) because of incorrect pump shaft position.	<p>Check the motor bearing, wear ring and impeller, shaft seal</p> <p>Replace them, if worn out or blocked.</p>
There is resonance in the installation.	<p>Fasten the support on foundation.</p> <p>Add damping joints.</p> <p>Make sure the pipes are properly supported.</p>
There are foreign bodies in the pump.	Clean the pump.

30. Megging



Megging of an installation incorporating MGE motors is not allowed, as the built-in electronics may be damaged.

31. Technical data, single-phase motors

31.1 Supply voltage

- 1 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

Recommended fuse size

Motor size [kW]	Min. [A]	Max. [A]
0.25 - 0.75	6	10
1.1 - 1.5	10	16

You can use standard as well as quick-blow or slow-blow fuses.

31.2 Leakage current

Earth leakage current less than 3.5 mA, AC.

Earth leakage current less than 10 mA, DC.

The leakage currents are measured in accordance with EN 61800-5-1:2007.

32. Technical data, three-phase motors

32.1 Supply voltage

- 3 x 380-500 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

Recommended fuse size

Motor size [kW]	Minimum [A]	Maximum [A]
0.25 - 1.1	6	6
1.5 - 2.2	6	10

- 3 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE

Motor size [kW]	Minimum [A]	Maximum [A]
1.1	10	20
1.5	10	20
2.2	13	35

You can use standard as well as quick-blow or slow-blow fuses.

32.2 Leakage current, AC

- 3 x 380-500 V - 10 %/+ 10 %, 50/60 Hz, PE
- 3 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Speed [min ⁻¹]	Power [kW]	Mains voltage [V]	Leakage current [mA]
1400-2000 1450-2200	0.25 - 1.5	≤ 400	< 3.5
		> 400	< 5
	2.2 - 4	≤ 400	< 3.5
		> 400	< 3.5
2900-4000	5.5 - 7.5	≤ 400	< 3.5
		> 400	< 5
	0.25 - 2.2	≤ 400	< 3.5
		> 400	< 5
4000-5900	3 - 5.5	≤ 400	< 3.5
		> 400	< 3.5
	7.5 - 11	≤ 400	< 3.5
		> 400	< 5
4000-5900	0.25 - 2.2	≤ 400	< 3.5
		> 400	< 5
	3 - 5.5	≤ 400	< 3.5
		> 400	< 3.5
7.5 - 11	≤ 400	< 3.5	
	> 400	< 5	

The leakage currents are measured without any load on the shaft and in accordance with EN 61800-5-1:2007.

33. Inputs and outputs

Earth reference, GND

All voltages refer to GND.

All currents return to GND.

Absolute maximum voltage and current limits

Exceeding the following electrical limits may result in severely reduced operating reliability and motor life:

Relay 1:

Maximum contact load: 250 VAC, 2 A or 30 VDC, 2 A.

Relay 2:

Maximum contact load: 30 VDC, 2 A.

GENI terminals: -5.5 to 9.0 VDC or less than 25 mADC.

Other input and output terminals: -0.5 to 26 VDC or less than 15 mADC.

Digital inputs, DI

Internal pull-up current greater than 10 mA at V_i equal to 0 VDC.

Internal pull-up to 5 VDC; currentless for V_i greater than 5 VDC.

Certain low logic level: V_i less than 1.5 VDC.

Certain high logic level: V_i greater than 3.0 VDC.

Hysteresis: No.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Open-collector digital outputs, OC

Current sinking capability: 75 mADC, no current sourcing.

Load types: Resistive or/and inductive.

Low-state output voltage at 75 mADC: Maximum 1.2 VDC.

Low-state output voltage at 10 mADC: Maximum 0.6 VDC.

Overcurrent protection: Yes.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Analog inputs, AI

Voltage signals:

- 0.5 - 3.5 VDC, AL AU.
- 0-5 VDC, AU.
- 0-10 VDC, AU.

Voltage signal: R_i greater than 100 k Ω at 25 °C.

Leak currents may occur at high operating temperatures. Keep the source impedance low.

Current signal ranges:

- 0-20 mADC, AU.
- 4-20 mADC, AL AU.

Current signal: R_i is equal to 292 Ω .

Current overload protection: Yes. Change to voltage signal.

Measurement tolerance: - 0/+ 3 % of full scale (maximum-point coverage).

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m, excl. potentiometer.

Potentiometer connected to +5 V, GND, any AI:

Use maximum 10 k Ω .

Maximum cable length: 100 m.

Analog output, AO

Current sourcing capability only.

Voltage signal:

- Range: 0-10 VDC.
- Minimum load between AO and GND: 1 k Ω .
- Short-circuit protection: Yes.

Current signal:

- Ranges: 0-20 and 4-20 mADC.
- Maximum load between AO and GND: 500 Ω .
- Open-circuit protection: Yes.

Tolerance: - 0/+ 4 % of full scale, maximum-point coverage.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Pt100/1000 inputs, PT

Temperature range:

- Minimum -50 °C. 80 Ω / 803 Ω .
- Maximum 204 °C. 177 Ω / 1773 Ω .

Measurement tolerance: \pm 1.5 °C.

Measurement resolution: less than 0.3 °C.

Automatic range detection, Pt100 or Pt1000: Yes.

Sensor fault alarm: Yes.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Use Pt100 for short wires.

Use Pt1000 for long wires.

LiqTec sensor inputs

Use Grundfos LiqTec sensor only.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Grundfos Digital Sensor input and output, GDS*

Use Grundfos Digital Sensor only.

* Not applicable for TPE2, TPE2 D pumps. The built-in sensor for TPE3, TPE3 D pumps is connected to this input.

Power supplies**+5 V:**

- Output voltage: 5 VDC - 5 %/+ 5 %.
- Maximum current: 50 mADC, sourcing only.
- Overload protection: Yes.

+24 V:

- Output voltage: 24 VDC - 5 %/+ 5 %.
- Maximum current: 60 mADC, sourcing only.
- Overload protection: Yes.

Digital outputs, relays

Potential-free changeover contacts.

Minimum contact load when in use: 5 VDC, 10 mA.

Screened cable: 0.5 - 2.5 mm², 28-12 AWG.

Maximum cable length: 500 m.

Bus input

Grundfos GENIbus protocol, RS-485.

Screened 3-core cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

34. Other technical data**EMC (electromagnetic compatibility)**

Standard used: EN 61800-3.

The table below shows the emission category of the motor.

C1 fulfils the requirements for residential areas.

Note: When connected to a public network, 11 kW motors do not comply with the partial weighted harmonic distortion (PWHd) requirements of EN 61000-3-12. If required by the distribution network operator, compliance can be obtained in the following way:

The impedance of the mains cables between the motor and the point of common coupling (PCC) must be equivalent to the impedance of a 50 m cable with a cross-section of 0.5 mm.

C3 fulfils the requirements for industrial areas.

Note: When the motors are installed in residential areas, supplementary measures may be required as the motors may cause radio interference.

Motor [kW]	Emission category	
	1450-2000 min ⁻¹	2900-4000 min ⁻¹ 4000-5900 min ⁻¹
0.25	C1	C1
0.37	C1	C1
0.55	C1	C1
0.75	C1	C1
1.1	C1	C1
1.5	C1	C1
2.2	C1	C1
3	C1	C1
4	C1	C1
5.5	C3/C1 ¹¹⁾	C1
7.5	C3/C1 ¹¹⁾	C3/C1 ¹¹⁾
11	-	C3/C1 ¹¹⁾

¹¹⁾ C1, if equipped with an external Grundfos EMC filter.

Immunity: The motor fulfils the requirements for industrial areas.

Contact Grundfos for further information.

Enclosure class

Standard: IP55 (IEC 34-5).

Optional: IP66 (IEC 34-5).

Insulation class

F (IEC 85).

Standby power consumption

5-10 W.

Cable entries

Motor size [kW]	Number and size of cable entries
0.25 - 2.2	4 x M20

34.1 Torques

Terminal	Thread size	Maximum torque [Nm]
L1, L2, L3, L, N	M4	2.35
NC, C1, C2, NO	M2.5	0.5
1 to 26 and A, Y, B	M2	0.5

Related information[34.2 Sound pressure level](#)**34.2 Sound pressure level**

Pump type	Sound pressure level ISO 3743 [dB(A)]
TPE2/TPE3 32-80	55
TPE2/TPE3 32-120	60
TPE2/TPE3 32-150	65
TPE2/TPE3 32-180	66
TPE2/TPE3 32-200	66
TPE2/TPE3 40-80	52
TPE2/TPE3 40-120	59
TPE2/TPE3 40-150	60
TPE2/TPE3 40-180	63
TPE2/TPE3 40-200	65
TPE2/TPE3 40-240	66
TPE2/TPE3 50-60	48
TPE2/TPE3 50-80	56
TPE2/TPE3 50-120	60
TPE2/TPE3 50-150	60
TPE2/TPE3 50-180	63
TPE2/TPE3 50-200	64
TPE2/TPE3 50-240	66
TPE2/TPE3 65-60	44
TPE2/TPE3 65-80	51
TPE2/TPE3 65-120	59
TPE2/TPE3 65-150	60
TPE2/TPE3 65-180	62
TPE2/TPE3 65-200	62
TPE2/TPE3 80-40	43
TPE2/TPE3 80-120	53
TPE2/TPE3 80-150	62
TPE2/TPE3 80-180	64
TPE2/TPE3 100-40	43
TPE2/TPE3 100-120	53
TPE2/TPE3 100-150	62
TPE2/TPE3 100-180	64

35. Factory settings

- Function is enabled.
- Function is disabled.
- Function is not available.

Settings	TPE3, TPE3 D	TPE2, TPE2 D
Setpoint	Auto	67 %
Operating mode	Normal	Normal
Control mode	AUTOADAPT	Const. curve
Date and time	●	●
FLOWLIMIT	○	-
Automatic Night Setback	○	-
Temperature influence	○	-
Buttons on product	●	●
Controller (Controller settings)		
T_i	1.0	0.5
K_p	8.0	0.5
Operating range		
Min.	25 %	25 %
Max.	100 %	100 %
Ramps	○	○
Ramp-up	1 second	1 second
Ramp-down	3 seconds	3 seconds
Number (Pump number)	1	1
Radio communication	●	●
Analog input 1	○	○
Analog input 2	○	○
Analog input 3	○	○
Built-in Grundfos sensor	●	-
Grundfos differential pressure sensor	Feedback sensor	-
Grundfos temperature sensor ¹²⁾	○	
	○/	
Pt100/1000 input 1	Other function, liquid temperature ¹²⁾	○
Pt100/1000 input 2	○	○
Digital input 1	○	○
Digital input 2	○	○
Digital in/output 3	○	○

Settings	TPE3, TPE3 D	TPE2, TPE2 D
Digital in/output 4	<input type="radio"/>	<input type="radio"/>
Pulse flowmeter	<input type="radio"/>	<input type="radio"/>
Predefined setpoints	<input type="radio"/>	<input type="radio"/>
Analog output	<input type="radio"/>	<input type="radio"/>
External setpoint function	<input type="radio"/>	<input type="radio"/>
Signal relay 1	<input type="radio"/>	<input type="radio"/>
Signal relay 2	<input type="radio"/>	<input type="radio"/>
Limit 1 exceeded	<input type="radio"/>	<input type="radio"/>
Limit 2 exceeded	<input type="radio"/>	<input type="radio"/>
Standstill heating	<input type="radio"/>	<input type="radio"/>
Motor bearing monitoring	<input type="radio"/>	<input type="radio"/>
Pump name	Grundfos	Grundfos
Connection code	-	-
Unit configuration	SI	SI

¹²⁾ Some pumps are fitted with a Grundfos temperature sensor and some pumps are fitted with an external Pt100/1000 temperature sensor.

36. Disposing of the product

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Dispose of the waste battery through the national collective schemes. If in doubt, contact your local Grundfos company.

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Industrias
1619 - Garin Pcia. de B.A.
Tel.: +54-3327 414 444
Fax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Tel.: +61-8-8461-4611
Fax: +61-8-8340-0155

Austria

GRUNDFOS Pumpen Vertrieb
Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Fax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomssesteenweg 81-83
B-2630 Aartselaar
Tel.: +32-3-870 7300
Fax: +32-3-870 7301

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A
BiH-71000 Sarajevo
Tel.: +387 33 592 480
Fax: +387 33 590 465
www.ba.grundfos.com
E-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo
Branco, 630
CEP 09850 - 300
São Bernardo do Campo - SP
Tel.: +55-11 4393 5533
Fax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztocna Tangenta street no. 100
BG - 1592 Sofia
Tel.: +359 2 49 22 200
Fax: +359 2 49 22 201
E-mail: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Tel.: +1-905 829 9533
Fax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106 PRC
Tel.: +86 21 612 252 22
Fax: +86 21 612 253 33

Columbia

GRUNDFOS Colombia S.A.S.
Km 1.5 vía Siberia-Cota Conj. Potrero
Chico,
Parque Empresarial Arcos de Cota Bd.
1A.
Cota, Cundinamarca
Tel.: +57(1)-2913444
Fax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Tel.: +385 1 6595 400
Fax: +385 1 6595 499
www.hr.grundfos.com

Czech Republic

GRUNDFOS Sales Czechia and Slovakia
s.r.o.
Čajkovského 21
779 00 Olomouc
Tel.: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tel.: +45-87 50 50 50
Fax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel.: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikujua 1
FI-01360 Vantaa
Tel.: +358-(0) 207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tel.: +33-4 74 82 15 15
Fax: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Fax: +49-(0) 211 929 69-3799
E-mail: infoservice@grundfos.de
Service in Deutschland:
kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Tel.: +0030-210-66 83 400
Fax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor, Siu Wai industrial
Centre
29-33 Wing Hong Street & 68 King Lam
Street, Cheung Sha Wan
Kowloon
Tel.: +852-27861706 / 27861741
Fax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Tópark u. 8
H-2045 Törökbalint
Tel.: +36-23 511 110
Fax: +36-23 511 111

India

GRUNDFOS Pumps india Private Limited
118 Old Mahabalipuram Road
Thoraipakkam
Chennai 600 097
Tel.: +91-44 2496 6800

Indonesia

PT GRUNDFOS Pompa
Graha intrub Lt. 2 & 3
Jln. Cililitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Tel.: +62 21-469-51900
Fax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Tel.: +353-1-4089 800
Fax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Fax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku
Hamamatsu
431-2103 Japan
Tel.: +81 53 428 4760
Fax: +81 53 428 5005

Kazakhstan

Grundfos Kazakhstan LLP
7' Kyz-Zhibek Str., Kok-Tobe micr.
KZ-050020 Almaty Kazakhstan
Tel.: +7 (727) 227-98-55/56

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Tel.: +82-2-5317 600
Fax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava ielā 60
LV-1035, Rīga,
Tel.: + 371 714 9640, 7 149 641
Fax: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel.: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam U1/25
Glenmarie Industrial Park
40150 Shah Alam, Selangor
Tel.: +60-3-5569 2922
Fax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México
S.A. de C.V.
Boulevard TLC No. 15
Parque industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Tel.: +52-81-8144 4000
Fax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Fax: +31-88-478 6332
E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Tel.: +64-9-415 3240
Fax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tel.: +47-22 90 47 00
Fax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznania
PL-62-081 Przeźmierowo
Tel.: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 00
Fax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
S-PARK BUSINESS CENTER, Clădirea
A2, etaj 2
Str. Tipografilor, Nr. 11-15, Sector 1, Cod
013714
București, Romania
Tel.: 004 021 2004 100
E-mail: romania@grundfos.ro

Serbia

Grundfos Srbija d.o.o.
Ormladinskih brigada 90b
11070 Novi Beograd
Tel.: +381 11 2258 740
Fax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Tel.: +65-6681 9688
Fax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D 821 09 BRATISLAVA
Tel.: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
Leskoškova 9e, 1122 Ljubljana
Tel.: +386 (0) 1 568 06 10
Fax: +386 (0)1 568 06 19
E-mail: tehnika-si@grundfos.com

South Africa

GRUNDFOS (PTY) LTD
16 Lascelles Drive, Meadowbrook Estate
1609 Germiston, Johannesburg
Tel.: (+27) 10 248 6000
Fax: (+27) 10 248 6002
E-mail: lgradidge@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Camino de la Fuentevilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Fax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunnagårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Fax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Fax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Tel.: +886-4-2305 0868
Fax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloe Phrakiat Rama 9 Road
Dokmai, Pravej, Bangkok 10250
Tel.: +66-2-725 8999
Fax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd.
Sti.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi
2. yol 200, Sokak No. 204
41490 Gebze/ Kocaeli
Tel.: +90 - 262-679 7979
Fax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

ТОВ "ГРУНДФОС УКРАЇНА"
Бізнес Центр Європа
Столичне шосе, 103
м. Київ, 03131, Україна
Tel.: (+38 044) 237 04 00
Fax: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone, Dubai
Tel.: +971 4 8815 166
Fax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Tel.: +44-1525-850000
Fax: +44-1525-850011

U.S.A.

Global Headquarters for WU
856 Koomey Road
Brookshire, Texas 77423 USA
Phone: +1-630-236-5500

Uzbekistan

Grundfos Tashkent, Uzbekistan
The Representative Office of Grundfos
Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Tel.: (+998) 71 150 3290 / 71 150 3291
Fax: (+998) 71 150 3292

98450210 12.2023

ECM: 1383319

www.grundfos.com

GRUNDFOS 

Trademarks displayed in this material, including but not limited to Grundfos and the Grundfos logo, are registered trademarks owned by The Grundfos Group. © 2023 Grundfos Holding A/S, all rights reserved.