

DPI

## Grundfos differential pressure sensor

Installation and operating instructions



be  
think  
innovate

**GRUNDFOS** 

# English (GB) Installation and operating instructions

## Original installation and operating instructions

## CONTENTS

	Page
1. Symbols used in this document	2
2. Delivery and handling	3
2.1 Delivery	3
2.2 Handling	3
3. Applications	3
4. Identification	4
4.1 Nameplate	4
5. Function	5
6. Installation	6
6.1 Extension of cable	7
6.2 Connection of amplifier	9
7. Technical data	10
7.1 Electrical data	10
7.2 Temperatures	10
7.3 Miscellaneous	10
8. Service	10
9. Disposal	10
10. Conversion tables	11



### Warning

Prior to installation, read these installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.

## 1. Symbols used in this document



### Warning

If these safety instructions are not observed, it may result in personal injury!

**Caution** If these safety instructions are not observed, it may result in malfunction or damage to the equipment!

**Note** Notes or instructions that make the job easier and ensure safe operation.

## 2. Delivery and handling

### 2.1 Delivery

Grundfos differential pressure sensor, type DPI, is supplied for direct mounting with 7/16"-20 UNF connection. Miscellaneous accessories are available on request.

### 2.2 Handling

Comply with local regulations and good practice for the handling of electronic equipment.

## 3. Applications

Grundfos differential pressure sensor, type DPI, is used for measuring differential pressure.

**Caution**


If the sensor is used in a manner not specified by the manufacturer, the protection provided may be damaged.



Do not use Grundfos DPI sensors in explosive environments zone-classified according to ATEX.

## 4. Identification

### 4.1 Nameplate



TM03 3063 2206

Fig. 1 Nameplate for DPI

---

#### Pos. Description


---

- 1 Pressure range
  - 2 Output signal
  - 3 Supply voltage
  - 4 Temperature range of medium
  - 5 Enclosure class
  - 6 Max. differential pressure, P1 ->P2
  - 7 Max. differential pressure, P2 ->P1
  - 8 Max. system pressure
  - 9 Connection P1, high pressure (discharge side)
  - 10 Connection P2, low pressure (suction side)
  - 11 12 - 30 V supply voltage
  - 12 GND (earth lead)
  - 13 Signal lead
  - 14 Max. current consumption
  - 15 Country of origin
  - 16 Version no.
- 

Conversion of SI units into US units, see page [11](#).

## 5. Function

The sensor measures the differential pressure between the high pressure (P1) and the low pressure (P2). It may for example be the differential pressure between the flanges on the suction and discharge side of a pump.



TM03 2058 3505

**Fig. 2** DPI with position of P1 and P2

Connect the sensor to the pressure gauge tappings of the pump flanges or to other measuring points in the system by means of 7/16"-20 UNF copper capillary tubes.


The pressure measurement is carried out by a silicon chip covered with a special coating developed by Grundfos.

The sensor signal is sent to an external controller or to a motor controller.

The sensor is supplied with power from an external voltage supply or direct from the terminal box of the motor.

## 6. Installation

The sensor can be mounted direct on the side of the pump or on a wall by means of the mounting bracket supplied.



TM03 22225 3905

**Fig. 3** Connections of the DPI

The DPI cable has four leads:

1	12 - 30 V supply voltage	Brown
2	GND (earth lead)	Yellow
3	Signal lead	Green
4	Test lead (can be cut off during mounting). This lead must not be connected to voltage supply.	White


The DPI must be supplied with power via a PELV supply (EN 60335-1) where GND is connected to protective earthing. Furthermore, connect the mounting bracket and/or one or both of the capillary tubes to earth.

## 6.1 Extension of cable

The DPI kit 2 enables the extension of the sensor cable to up to > 30 m.

If extension of the cable is required, always follow the guidelines below to ensure optimum connection between sensor and controller. The six steps below refer to fig. 4 on page 8:

1. Remove the outer insulation 50 mm from each cable end. Pull the outer screen away from the cable ends.  
Shorten and strip the individual conductors as shown.
2. Cut 1 Ø10 shrink-on sleeve and 4 Ø3 shrink-on sleeves in lengths of 20 mm.
3. Place the shrink-on sleeves as shown in fig. 4. Solder together conductor ends of the same colour.
4. Place the small shrink-on sleeves over the centre of each solder. Heat up the shrink-on sleeves from the centre and outwards using a heat gun in order to achieve the best result.
5. Hold the conductors close together and pull the outer screens over the joint, one screen at a time.
6. Place the big shrink-on sleeve over the centre of the joint and shrink it using the heat gun from the centre and outwards.



**Fig. 4** How to join the cables


TM04 0571 0808

## 6.2 Connection of amplifier

If the cable is more than 30 m long, use an amplifier to ensure correct signal values.

Connect the amplifier according to the diagram below:

### Fischer EN10-3



**Fig. 5** Wiring diagram for amplifier

## 7. Technical data

### 7.1 Electrical data

Voltage supply to the sensor: 12 - 30 VDC

PELV (protective extra low voltage)

(EN 60335-1)

Load:  
24 V: max. 500 ohm  
16 V: max. 200 ohm  
12 V: max. 100 ohm

Output signal, 3-wire: 4 - 20 mA

Enclosure class: IP 55 (according to EN 60529)

### 7.2 Temperatures

Temperature at sensor: -10 °C to +70 °C  
temporarily (max. 10 min.) up to 80 °C

Ambient temperature: -10 °C to +70 °C

Storage temperature: -40 °C to +80 °C

### 7.3 Miscellaneous

Cable length: 0.9 m

Cable length for DPI kit 2: 5 m

Max. air humidity: 95 %

Pressure range DPI: 0.... 0.6, 1.0, 1.6, 2.5, 4.0, 6.0, 10 bar

Pressure range DPI kit 2: 0.... 1.2, 2.5, 4.0, 6.0, 10 bar

Conversion of SI units into US units, see page [11](#).

## 8. Service

If the sensor is defective, replace the sensor.

## 9. Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

## 10. Conversion tables

### Pressure

SI unit [bar]	US unit [psi]
0.6	8.7
1	14.5
1.6	23.2
2.5	36.3
4	58
6	87
10	145
16	232

### Temperature

SI unit [ °C ]	US unit [ °F ]
-10	14
0	32
10	50
20	68
30	86
40	104
50	122
60	140
70	158
80	176

## Declaration of conformity

### GB: EU declaration of conformity

We, Grundfos, declare under our sole responsibility that the product DPI, to which the declaration below relates, is in conformity with the Council Directives listed below on the approximation of the laws of the EU member states.

### CZ: Prohlášení o shodě EU

My firma Grundfos prohlašujeme na svou pinou odpovědnost, že výrobek DPI, na který se toto prohlášení vztahuje, je v souladu s níže uvedenými ustanoveními směrnice Rady pro sblížení právních předpisů členských států Evropského spojenectví.

### DE: EU-Konformitätserklärung

Wir, Grundfos, erklären in alleiniger Verantwortung, dass das Produkt DPI, auf das sich diese Erklärung bezieht, mit den folgenden Richtlinien des Rates zur Angleichung der Rechtsvorschriften der EU-Mitgliedsstaaten übereinstimmt.

### DK: EU-overensstemmelseserklæring

Vi, Grundfos, erklaerer under ansvar at produktet DPI som erklæringen nedenfor omhandler, er i overensstemmelse med Rådets direktiver der er nævnt nedenfor, om indbyrdes tilnærmetil EU-medlemsstaterne lovgivning.

### ES: Declaración de conformidad de la UE

Grundfos declara, bajo su exclusiva responsabilidad, que el producto DPI al que hace referencia la siguiente declaración cumple lo establecido por las siguientes Directivas del Consejo sobre la aproximación de las legislaciones de los Estados miembros de la UE.

### FR: Déclaration de conformité UE

Nous, Grundfos, déclarons sous notre seule responsabilité, que le produit DPI, auquel se réfère cette déclaration, est conforme aux Directives du Conseil concernant le rapprochement des législations des États membres UE relatives aux normes énoncées ci-dessous.

### GR: Δήλωση συμμόρφωσης ΕΕ

Εμείς, η Grundfos, δηλώνουμε με αποκλειστικά δική μας ευθύνη ότι το προϊόν DPI, στο οποίο αναφέρεται η παρακάτω δήλωση, συμμορφώνεται με τις παρακάτω Οδηγίες του Συμβουλίου περί προσέγγισης των νομοθεσιών των κρατών μελών της ΕΕ.

### HU: EU megfelelőségi nyilatkozat

Mi, a Grundfos vállalat, teljes felelősséggel kijelentjük, hogy a(z) DPI termék, amelyre az alábbi nyilatkozat vonatkozik, megfelel az Európai Unió tagállamainak jogi irányelvezető összehangoltanács alábbi előírásainak.

### IT: Dichiarazione di conformità UE

Grundfos dichiara sotto la sua esclusiva responsabilità che il prodotto DPI, al quale si riferisce questa dichiarazione, è conforme alle seguenti direttive del Consiglio riguardanti il riavvicinamento delle legislazioni degli Stati membri UE.

### PL: Deklaracja zgodności UE

My, Grundfos, oświadczamy z pełną odpowiedzialnością, że nasz produkt DPI, którego deklaracja niniejsza dotyczy, jest zgodny z następującymi dyrektywami Rady w sprawie zbliżenia przepisów prawnych państw członkowskich.

### RU: Декларация о соответствии нормам ЕС

Мы, компания Grundfos, со всей ответственностью заявляем, что изделие DPI, к которому относится нижеприведённая декларация, соответствует нижеприведённым Директивам Совета Европейского союза о тождественности законов стран-членов ЕС.

- Low Voltage Directive (2014/35/EU).  
Standard used: EN 61010-1:2010
  - EMC Directive (2014/30/EU).  
Standard used: EN 61326-1:2006 and EN 61326-2-3:2013
- 

This EU declaration of conformity is only valid when published as part of the Grundfos safety instructions (publication number 96607940).

Bjerringbro, 14th April 2016



Svend Aage Kaae  
Director  
Grundfos Holding A/S  
Poul Due Jensens Vej 7  
8850 Bjerringbro, Denmark

Person authorised to compile the technical file and  
empowered to sign the EU declaration of conformity.

## Argentina

Bombas GRUNDFOS de Argentina S.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 411 111

## Australia

GRUNDFOS Pumps Pty. Ltd.  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

## Austria

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

## Belgium

N.V. GRUNDFOS Bellux S.A.  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

## Belarus

Представительство ГРУНДФОС в Минске  
Тел.: +7 (375 17) 286 39 72, 286 39 73  
Факс: +7 (375-17) 286 39 71

## Bosna and Herzegovina

GRUNDFOS Sarajevo  
Phone: +387 33 592 480  
Telefax: +387 33 590 465  
[www.ba.grundfos.com](http://www.ba.grundfos.com)  
email: grundfos@bih.net.ba

## Brazil

BOMBAS GRUNDFOS DO BRASIL  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

## Bulgaria

Grundfos Bulgaria EOOD  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201

## Canada

GRUNDFOS Canada Inc.  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

## China

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
Phone: +86-021-612 252 22  
Telefax: +86-021-612 253 33

## Croatia

GRUNDFOS CROATIA d.o.o.  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499

## Czech Republic

GRUNDFOS s.r.o.  
Phone: +420-585-716 111  
Telefax: +420-585-716 299

## Denmark

GRUNDFOS DK A/S  
Tlf.: +45-87 50 50 50  
E-mail:  
[info\\_GDK@grundfos.com](mailto:info_GDK@grundfos.com)  
[www.grundfos.com/DK](http://www.grundfos.com/DK)

## Estonia

GRUNDFOS Pumps Eesti OÜ  
Tel: + 372 606 1690  
Fax: + 372 606 1691

## Finland

OY GRUNDFOS Pumput AB  
Phone: +358-(0)207 889 500  
Telefax: +358-(0)207 889 550

## France

Pompes GRUNDFOS Distribution S.A.  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

## Germany

GRUNDFOS GMBH  
Tel.: +49-(0) 211 929 69-0  
e-mail:  
[infoservice@grundfos.de](mailto:infoservice@grundfos.de)  
Service in Deutschland:  
e-mail:  
[kundendienst@grundfos.de](mailto:kundendienst@grundfos.de)

## Greece

GRUNDFOS Hellas A.E.B.E.  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

## Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.  
Phone: +852-27861706/  
27861741  
Telefax: +852-27858664

## Hungary

GRUNDFOS Hungária Kft.  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

## India

GRUNDFOS Pumps India Private Limited  
Phone: +91-44 4596 6800

## Indonesia

PT GRUNDFOS Pompa  
Phone: +62 21-469 51900  
Telefax: +62-21-460 6910/  
460 6901

## Ireland

GRUNDFOS (Ireland) Ltd.  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

## Italy

GRUNDFOS Pompe Italia S.r.l.  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290/  
95838461

## Japan

GRUNDFOS Pumps K.K.  
Phone: +81-35-448 1391  
Telefax: +81-35-448 9619

## Korea

GRUNDFOS Pumps Korea Ltd.  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

## Latvia

SIA GRUNDFOS Pumps Latvia  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

## Lithuania

GRUNDFOS Pumps UAB  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

## **Malaysia**

GRUNDFOS Pumps Sdn.  
Bhd.  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

## **Mexico**

Bombas GRUNDFOS de  
México S.A. de C.V.  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

## **Netherlands**

GRUNDFOS Netherlands  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332 s

## **New Zealand**

GRUNDFOS Pumps NZ Ltd.  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

## **Norway**

GRUNDFOS Pumper A/S  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

## **Poland**

GRUNDFOS Pompy Sp. z  
o.o.  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

## **Portugal**

Bombas GRUNDFOS  
Portugal, S.A.  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

## **Romania**

GRUNDFOS Pompe  
România SRL  
Phone: +40 21 200 4100  
E-mail:  
romania@grundfos.ro

## **Russia**

ООО Грундфос Россия  
Тел. (+7) 495 737 30 00,  
564 88 00  
E-mail  
grundfos.moscow@grundfo  
s.com

## **Serbia**

Grundfos Srbija d.o.o.  
Phone: +381 11 2258 740  
Telefax: +381 11 2281 769

## **Singapore**

GRUNDFOS (Singapore)  
Pte. Ltd.  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

## **Slovakia**

GRUNDFOS s.r.o.  
Phona: +421 2 5020 1426

## **Slovenia**

GRUNDFOS LJUBLJANA,  
d.o.o.  
Phone: +386 (0) 1 568 06  
10  
Telefax: +386 (0) 1 568 06  
19

## **South Africa**

GRUNDFOS (PTY) LTD  
Phone: (+27) 11 579 4800  
Fax: (+27) 11 455 6066  
E-mail:  
lsmart@grundfos.com

## **Spain**

Bombas GRUNDFOS  
España S.A.  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

## **Sweden**

GRUNDFOS AB  
Tel.: +46(0)771-32 23 00  
Telefax: +46(0)31-331 94 60

## **Switzerland**

GRUNDFOS Pumpen AG  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

## **Taiwan**

GRUNDFOS Pumps  
(Taiwan) Ltd.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

## **Thailand**

GRUNDFOS (Thailand) Ltd.  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

## **Turkey**

GRUNDFOS POMPA San.  
ve Tic. Ltd. Sti.  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

## **Ukraine**

Бізнес Центр Європа  
Телефон: (+38 044) 237 04  
00  
Факс.: (+38 044) 237 04 01

## **United Arab Emirates**

GRUNDFOS Gulf  
Distribution  
Phone: +971-4- 8815 166  
Telefax: +971-4-8815 136

## **United Kingdom**

GRUNDFOS Pumps Ltd.  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

## **U.S.A.**

GRUNDFOS Pumps  
Corporation  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

## **Uzbekistan**

Grundfos Tashkent,  
Uzbekistan The  
Representative Office of  
Grundfos Kazakhstan in  
Uzbekistan  
Телефон: (+998) 71 150  
3290 / 71 150 3291  
Факс: (+998) 71 150 3292

Addresses revised  
25.01.2016

be think innovate

---

**96607940 0416**

ECM: 1182950x

[www.grundfos.com](http://www.grundfos.com)

**GRUNDFOS** 

The name Grundfos, the Grundfos logo, and **be think innovate** are registered trademarks owned by Grundfos Holding A/S or Grundfos A/S, Denmark. All rights reserved worldwide.

© Copyright Grundfos Holding A/S