

# SMART Digital S - DDC

up to 15 l/h

Installation and operating instructions



Further languages

<http://net.grundfos.com/qr/i/95726994>

be  
think  
innovate

GRUNDFOS 

# English (GB) Installation and operating instructions

## Original installation and operating instructions

## CONTENTS

	Page		
<b>1. Safety instructions</b>	<b>3</b>	6.5	SlowMode 23
1.1 Symbols used in this document	3	6.6	Key lock 23
1.2 Qualification and training of personnel	3	6.6.1	Temporary deactivation 23
1.3 Safety instructions for the operator/user	3	6.6.2	Deactivation 23
1.4 Safety of the system in the event of a failure in the dosing pump	3	6.7	Display Setup 23
1.5 Dosing chemicals	4	6.7.1	Units 23
1.6 Diaphragm breakage	4	6.7.2	Additional display 24
<b>2. General information</b>	<b>5</b>	6.8	Inputs/Outputs 24
2.1 Applications	5	6.8.1	Relay outputs 24
2.2 Improper operating methods	5	6.8.2	External stop 24
2.3 Symbols on the pump	6	6.8.3	Empty and Low level signals 25
2.4 Nameplate	6	6.9	Basic settings 25
2.5 Type key	7	<b>7. Service</b>	<b>25</b>
2.6 Product overview	8	7.1	Regular maintenance 25
<b>3. Technical data / Dimensions</b>	<b>9</b>	7.2	Cleaning 25
3.1 Technical data	9	7.3	Service system 26
3.2 Technical data for CIP (Clean-In-Place) applications	11	7.4	Perform service 26
3.3 Dimensions	11	7.4.1	Dosing head overview 26
<b>4. Assembly and installation</b>	<b>12</b>	7.4.2	Dismantling the diaphragm and valves 27
4.1 Pump assembly	12	7.4.3	Reassembling the diaphragm and valves 27
4.1.1 Requirements	12	7.5	Resetting the service system 27
4.1.2 Align and install mounting plate	12	7.6	Diaphragm breakage 28
4.1.3 Engage pump in mounting plate	12	7.6.1	Dismantling in case of diaphragm breakage 28
4.1.4 Adjust control cube position	12	7.6.2	Dosing liquid in the pump housing 28
4.2 Hydraulic connection	13	7.7	Repairs 29
4.3 Electrical connection	14	<b>8. Faults</b>	<b>29</b>
<b>5. Startup</b>	<b>16</b>	8.1	List of faults 30
5.1 Setting the menu language	16	8.1.1	Faults with error message 30
5.2 Deaerating the pump	17	8.1.2	General faults 30
5.3 Calibrating the pump	17	<b>9. Disposal</b>	<b>31</b>
<b>6. Operation</b>	<b>19</b>		
6.1 Control elements	19		
6.2 Display and symbols	19		
6.2.1 Navigation	19		
6.2.2 Operating states	19		
6.2.3 Sleep mode (energy-saving mode)	19		
6.2.4 Overview of display symbols	20		
6.3 Main menus	21		
6.3.1 Operation	21		
6.3.2 Info	21		
6.3.3 Alarm	21		
6.3.4 Setup	21		
6.4 Operation modes	22		
6.4.1 Manual	22		
6.4.2 Pulse	22		
6.4.3 Analog 0/4-20 mA	22		



### Warning

Prior to installation, read these installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.

## 1. Safety instructions

These installation and operating instructions contain general instructions that must be observed during installation, operation and maintenance of the pump. It must therefore be read by the installation engineer and the relevant qualified operator prior to installation and start-up, and must be available at the installation location at all times.

### 1.1 Symbols used in this document



**Warning**

If these safety instructions are not observed, it may result in personal injury.

**Caution**

If these safety instructions are not observed, it may result in malfunction or damage to the equipment.

**Note**

Notes or instructions that make the job easier and ensure safe operation.

### 1.2 Qualification and training of personnel

The personnel responsible for the installation, operation and service must be appropriately qualified for these tasks. Areas of responsibility, levels of authority and the supervision of the personnel must be precisely defined by the operator. If necessary, the personnel must be trained appropriately.

#### Risks of not observing the safety instructions

Non-observance of the safety instructions may have dangerous consequences for the personnel, the environment and the pump and may result in the loss of any claims for damages.

It may lead to the following hazards:

- Personal injury from exposure to electrical, mechanical and chemical influences.
- Damage to the environment and personal injury from leakage of harmful substances.

### 1.3 Safety instructions for the operator/user

The safety instructions described in these instructions, existing national regulations on health protection, environmental protection and for accident prevention and any internal working, operating and safety regulations of the operator must be observed. Information attached to the pump must be observed.

Leakages of dangerous substances must be disposed of in a way that is not harmful to the personnel or the environment.

Damage caused by electrical energy must be prevented, see the regulations of the local electricity supply company.

**Caution**

Before starting work on the pump, the pump must be in the "Stop" operating state or be disconnected from the power supply. The system must be pressureless!

**Note**

The mains plug is the separator separating the pump from the mains.

Only original accessories and original spare parts should be used. Using other parts can result in exemption from liability for any resulting consequences.

### 1.4 Safety of the system in the event of a failure in the dosing pump

The dosing pump was designed according to the latest technologies and is carefully manufactured and tested.

If it fails regardless of this, the safety of the overall system must be ensured. Use the relevant monitoring and control functions for this.

**Caution**

Make sure that any chemicals that are released from the pump or any damaged lines do not cause damage to system parts and buildings.

The installation of leak monitoring solutions and drip trays is recommended.

## 1.5 Dosing chemicals

### Warning



Before switching the supply voltage back on, the dosing lines must be connected in such a way that any chemicals in the dosing head cannot spray out and put people at risk.

The dosing medium is pressurised and can be harmful to health and the environment.

### Warning



When working with chemicals, the accident prevention regulations applicable at the installation site should be applied (e.g. wearing protective clothing).

Observe the chemical manufacturer's safety data sheets and safety instructions when handling chemicals!

### Caution

A deaeration hose, which is routed into a container, e.g. a drip tray, must be connected to the deaeration valve.

### Caution

The dosing medium must be in liquid aggregate state!

Observe the freezing and boiling points of the dosing medium!

The resistance of the parts that come into contact with the dosing medium, such as the dosing head, valve ball, gaskets and lines, depends on the medium, media temperature and operating pressure.

### Caution

Ensure that parts in contact with the dosing media are resistant to the dosing medium under operating conditions, see data booklet!

Should you have any questions regarding the material resistance and suitability of the pump for specific dosing media, please contact Grundfos.

## 1.6 Diaphragm breakage

If the diaphragm leaks or is broken, dosing liquid escapes from the drain opening (fig. 23, pos. 11) on the dosing head. Observe section [7.6 Diaphragm breakage](#).

### Warning

Danger of explosion, if dosing liquid has entered the pump housing!

Operation with damaged diaphragm can lead to dosing liquid entering the pump housing.

In case of diaphragm breakage, immediately separate the pump from the power supply!

Make sure the pump cannot be put back into operation by accident!

Dismantle the dosing head without connecting the pump to the power supply and make sure no dosing liquid has entered the pump housing. Proceed as described in section [7.6.1 Dismantling in case of diaphragm breakage](#).

To avoid any danger resulting from diaphragm breakage, observe the following:

- Perform regular maintenance. See section [7.1 Regular maintenance](#).
- Never operate the pump with blocked or soiled drain opening.
  - If the drain opening is blocked or soiled, proceed as described in section [7.6.1 Dismantling in case of diaphragm breakage](#).
- Never attach a hose to the drain opening. If a hose is attached to the drain opening, it is impossible to recognise escaping dosing liquid.
- Take suitable precautions to prevent harm to health and damage to property from escaping dosing liquid.
- Never operate the pump with damaged or loose dosing head screws.

## 2. General information



The DDC dosing pump is a self-priming diaphragm pump. It consists of a housing with stepper motor and electronics, a dosing head with diaphragm and valves and the control cube.

Excellent dosing features of the pump:

- Optimal intake even with degassing media, as the pump always works at full suction stroke volume.
- Continuous dosing, as the medium is sucked up with a short suction stroke, regardless of the current dosing flow, and dosed with the longest possible dosing stroke.

### 2.1 Applications

The pump is suitable for liquid, non-abrasive, non-flammable and non-combustible media strictly in accordance with the instructions in these installation and operating instructions.

#### Areas of application

- Drinking water treatment
- Wastewater treatment
- Swimming pool water treatment
- Boiler water treatment
- CIP (Clean-In-Place) Observe section [3.2 Technical data for CIP \(Clean-In-Place\) applications](#).
- Cooling water treatment
- Process water treatment
- Wash plants
- Chemical industry
- Ultrafiltration processes and reverse osmosis
- Irrigation
- Paper and pulp industry
- Food and beverage industries

## 2.2 Improper operating methods

The operational safety of the pump is only guaranteed if it is used in accordance with section [2.1 Applications](#).

#### Warning



Other applications or the operation of pumps in ambient and operating conditions, which are not approved, are considered improper and are not permitted. Grundfos cannot be held liable for any damage resulting from incorrect use.



#### Warning

The pump is NOT approved for operation in potentially explosive areas!



#### Warning

A sunscreen is required for outdoor installation!





#### Caution

Frequent disengagement from the mains voltage, e.g. via a relay, can result in damage to the pump electronics and in the breakdown of the pump. The dosing accuracy is also reduced as a result of internal start procedures.

Do not control the pump via the mains voltage for dosing purposes!

Only use the "External stop" function to start and stop the pump!

### 2.3 Symbols on the pump

Symbol	Description
	Indication of universally dangerous spot.
	In case of emergency and prior to all maintenance work and repairs, take the mains plug out of the mains supply!
	The device complies with electrical safety class II.
	Connection for deaeration hose at dosing head. If the deaeration hose is not correctly connected, danger will arise due to possible leakage of dosing liquid!

### 2.4 Nameplate




Fig. 1 Nameplate

Pos.	Description	Pos.	Description
1	Type designation	6	Enclosure class
2	Voltage	7	Mark of approval, CE mark, etc.
3	Frequency	8	Country of origin
4	Power consumption	9	Max. operating pressure
5	Max. dosing flow	10	Model

TM04 8144 1720

## 2.5 Type key

The type key is used to identify the precise pump and is not used for configuration purposes.

Code	Example	DDC	6-	10	AR-	PP/	V/	C-	F-	3	1	U2U2	F	G
	Pump type													
	Max. flow [l/h]													
	Max. pressure [bar]													
	<b>Control variant</b>													
A	Standard													
AR	A with alarm relay and analog input													
	<b>Dosing head material</b>													
PP	Polypropylene													
PVC	PVC (polyvinyl chloride, only up to 10 bar)													
PV	PVDF (polyvinylidene fluoride)													
SS	Stainless steel DIN 1.4401													
	<b>Gasket material</b>													
E	EPDM													
V	FKM													
T	PTFE													
	<b>Valve ball material</b>													
C	Ceramic													
SS	Stainless steel DIN 1.4401													
	<b>Control cube position</b>													
F	Front-mounted (can be changed to the right or left)													
	<b>Voltage</b>													
3	1 x 100-240 V, 50/60 Hz													
	<b>Valve type</b>													
1	Standard													
2	Spring-loaded (HV version)													
	<b>Suction/discharge side connection</b>													
U2U2	Hose, 4/6 mm, 6/9 mm, 6/12 mm, 9/12 mm													
U7U7	Hose, 0.17" x 1/4"; 1/4" x 3/8"; 3/8" x 1/2"													
AA	Threaded Rp 1/4, female (stainless steel)													
VV	Threaded 1/4 NPT, female (stainless steel)													
XX	No connection													
	<b>Installation set*</b>													
I001	Hose, 4/6 mm (up to 7.5 l/h, 13 bar)													
I002	Hose, 9/12 mm (up to 60 l/h, 9 bar)													
I003	Hose, 0.17" x 1/4" (up to 7.5 l/h, 13 bar)													
I004	Hose, 3/8" x 1/2" (up to 60 l/h, 10 bar)													
	<b>Mains plug</b>													
F	EU													
B	USA, Canada													
G	UK													
I	Australia, New Zealand, Taiwan													
E	Switzerland													
J	Japan													
L	Argentina													
	<b>Design</b>													
G	Grundfos													

\* Including: 2 pump connections, foot valve, injection unit, 6 m PE discharge hose, 2 m PVC suction hose, 2 m PVC deaeration hose (4/6 mm).

2.6 Product overview




Fig. 2 Front view of the pump




Fig. 3 Rear view of the pump

TM04 1173 3117

TM04 1175 3510



### 3. Technical data / Dimensions



#### 3.1 Technical data

Data		6-10	9-7	15-4
Turn-down ratio (setting range)	[1:X]	1000	1000	1000
	[l/h]	6.0	9.0	15.0
Max. dosing capacity	[gph]	1.5	2.4	4.0
	[l/h]	3.00	4.50	7.50
Max. dosing capacity with SlowMode 50 %	[gph]	0.75	1.20	2.00
	[l/h]	1.50	2.25	3.75
Max. dosing capacity with SlowMode 25 %	[gph]	0.38	0.60	1.00
	[l/h]	0.0060	0.0090	0.0150
Min. dosing capacity	[gph]	0.0015	0.0024	0.0040
	[bar]	10	7	4
Max. operating pressure	[psi]	150	100	60
	[strokes/min]	140	200	180
Max. stroke frequency <sup>1)</sup>				
Stroke volume	[ml]	0.81	0.84	1.58
Accuracy of repeatability	[%]	± 1		
Max. suction lift during operation <sup>2)</sup>	[m]	6		
Max. suction lift when priming with wet valves <sup>2)</sup>	[m]	2	2	3
<b>Mechanical data</b>	Min. pressure difference between suction and discharge side	[bar]	1	
	Max. inlet pressure, suction side	[bar]	2	
Max. viscosity in SlowMode 25 % with spring-loaded valves <sup>3)</sup>	[mPas] (= cP)	2500	2000	2000
Max. viscosity in SlowMode 50 % with spring-loaded valves <sup>3)</sup>	[mPas] (= cP)	1800	1300	1300
Max. viscosity without SlowMode with spring-loaded valves <sup>3)</sup>	[mPas] (= cP)	600	500	500
Max. viscosity without spring-loaded valves <sup>3)</sup>	[mPas] (= cP)	50	50	300
Min. internal hose/pipe diameter suction/discharge side <sup>2), 4)</sup>	[mm]	4	6	6
Min. internal hose/pipe diameter suction/discharge side (high viscosity) <sup>4)</sup>	[mm]	9		
Min./Max. liquid temperature	[°C]	-10/45		
Min./Max. ambient temperature	[°C]	0/45		
Min./Max. storage temperature	[°C]	-20/70		
Max. relative humidity (non-condensing)	[%]	96		
Max. altitude above sea level	[m]	2000		

Data		6-10	9-7	15-4
<b>Electrical data</b>	Voltage [V]	100-240 V, - 10 %/+ 10 %, 50/60 Hz		
	Length of mains cable [m]	1.5		
	Max. inrush current for 2 ms (100 V) [A]	8		
	Max. inrush current for 2 ms (230 V) [A]	25		
	Max. power consumption P <sub>1</sub> [W]	22		
	Enclosure class	IP65, Nema 4X		
	Electrical safety class	II		
	Pollution degree	2		
<b>Signal input</b>	Max. load for level input	12 V, 5 mA		
	Max. load for pulse input	12 V, 5 mA		
	Max. load for External stop input	12 V, 5 mA		
	Min. pulse length [ms]	5		
	Max. pulse frequency [Hz]	100		
	Impedance at 0/4-20 mA analog input [Ω]	15		
	Accuracy of analog input (full-scale value) [%]	± 1.5		
	Min. resolution of analog input [mA]	0.05		
<b>Signal output</b>	Max. resistance in level/pulse circuit [Ω]	1000		
	Max. ohmic load on relay output [A]	0.5		
<b>Weight/size</b>	Max. voltage on relay output [V]	30 VDC / 30 VAC		
	Weight (PVC, PP, PVDF) [kg]	2.4		
	Weight (stainless steel) [kg]	3.2		
<b>Sound pressure</b>	Diaphragm diameter [mm]	44	50	
	Max. sound pressure level [dB(A)]	60		
<b>Approvals</b>		CE, CB, CSA-US, NSF61, EAC, ACS, RCM		

- 1) The maximum stroke frequency varies depending on calibration
- 2) Data is based on measurements with water
- 3) Maximum suction lift: 1 m, dosing capacity reduced (approx. 30 %)
- 4) Length of suction line: 1.5 m, length of discharge line: 10 m (at max. viscosity)

### 3.2 Technical data for CIP (Clean-In-Place) applications


Short-term temperature limits for max. 40 minutes at max. 2 bar operating pressure:

Max. liquid temperature for dosing head material PVDF	[°C]	85
Max. liquid temperature for dosing head material stainless steel	[°C]	120



The dosing head material Polyvinyl chloride (PVC) must not be used in CIP applications.

### 3.3 Dimensions



TM04 8169 3117

Fig. 4 Dimensional sketch

Pump type	A [mm]	A1 [mm]	B [mm]	C [mm]	D [mm]
DDC 6-10	280	251	196	46.5	24
DDC 9-7	280	251	196	46.5	24
DDC 15-4	280	251	200.5	39.5	24

## 4. Assembly and installation

For use in Australia:

Installation of this product must comply with AS/NZS3500!

Note

Certificate of suitability number: CS9431  
RCM number: N20683



### 4.1 Pump assembly

Warning



Install the pump in such a way that the plug can easily be reached by the operator during operation! This will enable the operator to separate the pump from the mains quickly in case of emergency!

The pump is delivered with a mounting plate. The mounting plate can be mounted vertically e.g. on a wall or horizontally e.g. on a tank. It takes just a few quick steps to firmly secure the pump to the mounting plate by means of a slot mechanism.

The pump can easily be released from the mounting plate for maintenance.

#### 4.1.1 Requirements

- The mounting surface must be stable and must not vibrate.
- Dosing must flow upwards vertically.

#### 4.1.2 Align and install mounting plate

- **Vertical installation:** Mounting plate slot mechanism must be above.
- **Horizontal installation:** Mounting plate slot mechanism must be opposite the dosing head.
- The mounting plate can be used as a drill template, please see fig. 4 for drill hole distances.




Fig. 5 Locate mounting plate



Warning

Make sure that you do not damage any cables and lines during installation!

1. Indicate drill holes.
2. Drill holes.
3. Secure mounting plate using four screws, diameter 5 mm, to the wall, on the bracket or the tank.

### 4.1.3 Engage pump in mounting plate

1. Attach the pump to the mounting plate support clamps and slide under slight pressure until it engages.




Fig. 6 Engaging the pump

### 4.1.4 Adjust control cube position

The control cube is fitted to the front of the pump on delivery. It can be turned by 90 ° so that the user can select to operate the pump from the right or left side.

Caution

The enclosure class (IP65/Nema 4X) and shock protection are only guaranteed if the control cube is installed correctly!

Caution

Pump must be disconnected from the power supply!

1. Carefully remove both protective caps on the control cube using a thin screwdriver.
2. Loosen screws.
3. Carefully lift off control cube only so far from the pump housing that no tensile stress is produced on the flat band cable.
4. Turn control cube by 90 ° and re-attach.
  - Make sure the O-ring is secure.
5. Tighten screws slightly and attach protective caps.




Fig. 7 Adjusting control cube

## 4.2 Hydraulic connection



### Warning

Risk of chemical burns!

Wear protective clothing (gloves and goggles) when working on the dosing head, connections or lines!

The dosing head may contain water from the factory check!

### Caution

When dosing media which should not come into contact with water, another medium must be dosed beforehand!

### Caution

Faultless function can only be guaranteed in conjunction with lines supplied by Grundfos!

### Caution

The lines used must comply with the pressure limits as per section 3.1 *Technical data*!

### Important information on installation

- Observe suction lift and line diameter, see section 3.1 *Technical data*.
- Shorten hoses at right angles.
- Ensure that there are no loops or kinks in the hoses.
- Keep suction line as short as possible.
- Route suction line up towards the suction valve.
- Installing a filter in the suction line protects the entire installation against dirt and reduces the risk of leakage.

### Hose connection procedure

1. Push union nut and tensioning ring across hose.
2. Push cone part fully into hose, see fig. 8.
3. Attach cone part with hose to corresponding pump valve.
4. Tighten union nut manually.
  - Do not use tools!
5. Tighten up union nuts after 2-5 operating hours if using PTFE gaskets!
6. Attach deaeration hose to the corresponding connection (see fig. 3) and run into a container or a collecting tray.




Fig. 8 Hydraulic connection

TM04 1155 0110

**Note** Pressure differential between suction and discharge side must be at least 1 bar / 14.5 psi!

**Caution** Tighten the dosing head screws with a torque wrench once before commissioning and again after 2-5 operating hours at 4 Nm.

### Installation example

The pump offers various installation options. In the picture below, the pump is installed in conjunction with a suction line, level switch and multifunction valve on a Grundfos tank.




Fig. 9 Installation example

TM04 1183 0110

### 4.3 Electrical connection



**Warning**  
The enclosure class (IP65/Nema 4X) is only guaranteed if plugs or protective caps are correctly installed!



**Warning**  
The pump can start automatically when the mains voltage is switched on!  
Do not manipulate mains plug or cable!


#### Signal connections



**Warning**  
Electric circuits of external devices connected to the pump inputs must be separated from dangerous voltage by means of double or reinforced insulation!

**Note**


The mains plug is the separator separating the pump from the mains.  
The rated voltage of the pump, see section [2.4 Nameplate](#), must conform to local conditions.




**Fig. 10** Wiring diagram of the electrical connections

TM04 1187 3410


**Analog, External stop and pulse input**

Function	Pins			
	1/brown	2/white	3/blue	4/black
 Analog	GND/(-) mA	(+) mA		
External stop	GND		X	
Pulse	GND			X

**Level signals: Empty signal and Low-level signal**

Function	Pins			
	1	2	3	4
 Low-level signal	X		GND	
Empty signal		X	GND	

**Relay outputs\***

Function	Pins			
	1/brown	2/white	3/blue	4/black
 Relay 1	X			X
Relay 2		X	X	

\* Applies to DDC-AR control variant




## 5. Startup


### 5.1 Setting the menu language

For description of control elements, see section 6.


1. Turn click wheel to highlight the cog symbol.




2. Press the click wheel to open the "Setup" menu.



3. Turn the click wheel to highlight the "Language" menu.




4. Press the click wheel to open the "Language" menu.



5. Turn the click wheel to highlight the desired language.



6. Press the click wheel to select the highlighted language.



7. Press the click wheel again to confirm the "Confirm settings?" prompt and apply the setting.



Fig. 11 Set menu language



## 5.2 Deaerating the pump



### Warning

The deaeration hose must be connected correctly and inserted into a suitable tank!

1. Open deaeration valve by approximately half a turn.
2. Press and hold down the [100 %] key (deaeration key) until liquid flows continuously without any bubbles from the deaeration hose.
3. Close deaeration valve.

Press the [100 %] key and simultaneously turn the click wheel clockwise to increase the duration of the process to up to 300 seconds. After setting the seconds, do not press the key any longer.

**Note**

## 5.3 Calibrating the pump

The pump is calibrated in the factory for media with a viscosity similar to water at maximum pump backpressure (see section [3.1 Technical data](#)).


If the pump is operated with a backpressure that deviates or if dosing a medium whose viscosity deviates, the pump must be calibrated.

### Requirements


- The hydraulics and electrics of the pump are connected (see section [4. Assembly and installation](#)).
- The pump is integrated into the dosing process under operating conditions.
- The dosing head and suction hose are filled with dosing medium.
- The pump has been deaerated.

**Calibration process - example for DDC 6-10**

1. Fill a measuring beaker with dosing medium.  
Recommended filling volumes  $V_1$ :
  - DDC 6-10: 0.3 l
  - DDC 9-7: 0.5 l
  - DDC 15-4: 1.0 l



2. Read off and note down the fill volume  $V_1$  (e.g. 300 ml).
3. Place the suction hose in the measuring beaker.




4. Start the calibration process in the "Setup > Calibration" menu.




5. The pump executes 200 dosing strokes and displays the factory calibration value (e.g. 125 ml).




6. Remove the suction hose from the measuring beaker and check the remaining volume  $V_2$  (e.g. 170 ml).



7. From  $V_1$  and  $V_2$ , calculate the actual dosed volume  $V_d = V_1 - V_2$  (e.g. 300 ml - 170 ml = 130 ml).



8. Set and apply  $V_d$  in the calibration menu.
  - The pump is calibrated.



## 6. Operation



### 6.1 Control elements

The pump control panel includes a display and the following control elements.




Fig. 12 Control panel

#### Keys

Key	Function
[Start/stop] key	Starting and stopping the pump.
[100 %] key	The pump doses at maximum flow regardless of the operation mode.

#### Click wheel

The click wheel is used to navigate through the menus, select settings and confirm them.

Turning the click wheel clockwise moves the cursor clockwise in increments in the display. Moving your finger counter-clockwise moves the cursor counter-clockwise.

## 6.2 Display and symbols

### 6.2.1 Navigation

In the "Info", "Alarm" and "Setup" main menus, the options and submenus are displayed in the rows below. Use the "Back" symbol to return to the higher menu level. The scroll bar at the right edge of the display indicates that there are further menu items which are not shown.

The active symbol (current cursor position) flashes. Press the click wheel to confirm your selection and open the next menu level. The active main menu is displayed as text, the other main menus are displayed as symbols. The position of the cursor is highlighted in black in the sub-menus.

When you position the cursor on a value and press the click wheel, a value is selected. Turning the click wheel clockwise increases the value, turning the click wheel counter-clockwise reduces the value. When you now press the click wheel, the cursor will be released again.

### 6.2.2 Operating states

The operating state of the pump is indicated by a symbol and display colour.

Display	Fault	Operating state		
White	-	Stop	Standby	
Green	-			Running
Yellow	Warning	Stop	Standby	Running
Red	Alarm	Stop	Standby	

### 6.2.3 Sleep mode (energy-saving mode)

If in the "Operation" main menu the pump is not operated for 30 seconds, the header disappears. After two minutes, the display brightness is reduced.

If in any other menu the pump is not operated for two minutes, the display switches back to the "Operation" main menu and the display brightness is reduced. This state will be cancelled when the pump is operated or a fault occurs.

TM04 1188 3117

### 6.2.4 Overview of display symbols

The following display symbols may appear in the menus.





Fig. 13 Overview of display symbols

### 6.3 Main menus

The main menus are displayed as symbols at the top of the display. The currently active main menu is displayed as text.

#### 6.3.1 Operation

Status information such as the dosing flow, selected operation mode and operating state is displayed in the "Operation" main menu.




TM04 1126 1110

#### 6.3.2 Info

You can find various counters, product data and the service system status in the "Info" main menu. The information can be accessed during operation.

The service system can also be reset from here.



TM04 1106 1010


#### Counters

The "Info > Counters" menu contains the following counters:

Counters	Resettable
<b>Volume</b>	
Total dosed volume [l] or US gallons	Yes
<b>Operating hours</b>	
Accumulated operating hours (pump switched on) [h]	No
<b>Motor runtime</b>	
Accumulated motor runtime [h]	No
<b>Strokes</b>	
Accumulated number of dosing strokes	No
<b>Power on/off</b>	
Accumulated frequency of switching mains voltage on	No

#### 6.3.3 Alarm

You can view errors in the "Alarm" main menu.




TM04 1109 1010

Up to 10 warnings and alarms, together with their cause, are listed in chronological order. If the list is full, the oldest entry will be overwritten, see Section 8. *Faults*.

#### 6.3.4 Setup

The "Setup" main menu contains menus for pump configuration. These menus are described in the following sections.



Section	
Language >	5.1
Operation mode >	6.4
Pulse memory* >	6.4.2
SlowMode >	6.5
Calibration >	5.3
Key lock >	6.6
Display >	6.7
Inputs/Outputs >	6.8
Basic settings >	6.9

TM04 8166 3510

\* Menu "Pulse memory" is only displayed in operation mode "Pulse".

## 6.4 Operation modes

Three different operation modes can be set in the "Setup > Operation mode" menu.

- Manual, see section 6.4.1
- Pulse, see section 6.4.2
- Analog 0-20mA, see section 6.4.3
- Analog 4-20mA, see section 6.4.3

### 6.4.1 Manual

In this operation mode, the pump constantly doses the dosing flow set with the click wheel. The dosing flow is set in l/h or ml/h in the "Operation" menu. The pump automatically switches between the units. Alternatively, the display can be reset to US units (gph). See section 6.7 [Display Setup](#).




Fig. 14 Manual mode

The setting range depends on the pump type:

Type	Setting range*	
	[l/h]	[gph]
DDC 6-10	0.0060 - 6.0	0.0015 - 1.5
DDC 9-7	0.0090 - 9.0	0.0024 - 2.4
DDC 15-4	0.0150 - 15.0	0.0040 - 4.0

\* When the "SlowMode" function is active, the maximum dosing flow is reduced, see section 3.1 [Technical data](#).

### 6.4.2 Pulse

In this operation mode, the pump doses the set dosing volume for each incoming (potential-free) pulse, e.g. from a water meter. The pump automatically calculates the optimum stroke frequency for dosing the set volume per pulse. The calculation is based on:

- the frequency of external pulses
- the set dosing volume/pulse.




Fig. 15 Pulse mode

The dosing volume per pulse is set in ml/pulse in the "Operation" menu using the click wheel. The setting range for the dosing volume depends on the pump type:

Type	Setting range [ml/pulse]
DDC 6-10	0.0016 - 16.2
DDC 9-7	0.0017 - 16.8
DDC 15-4	0.0032 - 31.6

The frequency of incoming pulses is multiplied by the set dosing volume. If the pump receives more pulses than it can process at the maximum dosing flow, it runs at the maximum stroke frequency in continuous operation. Excess pulses will be ignored if the memory function is not enabled.

### Memory function

When the "Setup > Pulse memory" function is enabled, up to 65,000 unprocessed pulses can be saved for subsequent processing.



#### Warning

Subsequent processing of saved pulses can cause local increase in concentration!

The contents of the memory will be deleted by:

- Switching off the power supply
- Changing the operation mode
- Interruption (e.g. alarm, External stop).

### 6.4.3 Analog 0/4-20 mA

*Applies to DDC-AR control variant*

In this operation mode, the pump doses according to the external analog signal. The dosing volume is proportional to the signal input value in mA.

Operation mode	Input value [mA]	Dosing flow [%]
4-20 mA	≤ 4.1	0
	≥ 19.8	100
0-20 mA	≤ 0.1	0
	≥ 19.8	100

TM04 8170 3510



TM04 1126 1110

If the input value in operation mode 4-20 mA falls below 2 mA, an alarm is displayed and the pump stops. A cable break or signal transmitter error has occurred. The "Cable break" symbol is displayed in the "Signal/error display" area of the display.




Fig. 16 Analog scaling




Fig. 17 Analog operation mode

## 6.5 SlowMode

When the "SlowMode" function is enabled, the pump slows down the suction stroke. The function is enabled in the "Setup > SlowMode" menu and is used to prevent cavitation in the following cases:

- for dosing media with a higher viscosity
- for degassing dosing media
- for long suction lines
- for large suction lift.

In the "Setup > SlowMode" menu, the speed of the suction stroke can be reduced to 50 % or 25 %.

**Caution**

Enabling the "SlowMode" function reduces the maximum dosing flow of the pump to the set percentage value!




Fig. 18 SlowMode menu

## 6.6 Key lock



The key lock is set in the "Setup > Key lock" menu by entering a four-digit code. It protects the pump by preventing changes to settings. Two levels of key lock can be selected:

Level	Description
Settings	All settings can only be changed by entering the lock code. The [Start/stop] key and the [100 %] key are not locked.
Settings + keys	The [Start/stop] key and the [100 %] key and all settings are locked.

It is still possible to navigate in the "Alarm" and "Info" main menu and reset alarms.

### 6.6.1 Temporary deactivation

If the "Key lock" function is activated but settings need to be modified, the keys can be unlocked temporarily by entering the deactivation code. If the code is not entered within 10 seconds, the display automatically switches to the "Operation" main menu. The key lock remains active.

### 6.6.2 Deactivation

The key lock can be deactivated in the "Setup > Key lock" menu via the "Off" menu point. The key lock is deactivated after the general code "2583" or a pre-defined custom code has been entered.

## 6.7 Display Setup

Use the following settings in the "Setup > Display" menu to adjust the display properties:

- Units (metric/US)
- Display contrast
- Additional display.

### 6.7.1 Units

Metric units (litres/millilitres/bar) or US units (US gallons/PSI) can be selected. According to the operation mode and menu, the following units of measurement are displayed:

Operation mode/function	Metric units	US units
Manual control	ml/h or l/h	gph
Pulse control	ml/□	ml/□
0/4-20 mA Analog control	ml/h or l/h	gph
Calibration	ml	ml
Volume counter	l	gal

TM04 1120 2010

TM04 1127 3117

TM04 1153 1110

### 6.7.2 Additional display

The additional display provides additional information about the current pump status. The value is shown in the display with the corresponding symbol.

In "Pulse" mode the "Target flow" information can be displayed with Q = 1.28 l/h (see fig. 19).




Fig. 19 Display with additional display

The additional display can be set as follows:

Setting	Description
Default display	<p>Q Target flow (Pulse)</p> <p>↻ Input current (analog)<sup>1)</sup></p>
Dosed volume	V Dosed vol. since last reset (see <i>Counters</i> on page 21)

1) only DDC-AR control variant

### 6.8 Inputs/Outputs

In the "Setup > Inputs/Outputs" menu, you can configure the two outputs "Relay 1 + Relay 2" and the signal inputs "External stop", "Empty signal" and "Low-level signal".




Fig. 20 Inputs/Outputs menu

### 6.8.1 Relay outputs

*Applies to DDC-AR control variant*

The pump can switch two external signals using installed relays. The relays are switched by potential-free pulses. The connection diagram of the relays is shown in section 4.3 *Electrical connection*.

Both relays can be allocated with the following signals:

Relay 1 signal	Relay 2 signal	Description
Alarm*	Alarm	Display red, pump stopped (e.g. empty signal, etc.)
Warning*	Warning	Display yellow, pump is running (e.g. low-level signal, etc.)
Stroke signal	Stroke signal	Each full stroke
Pump dosing	Pump dosing*	Pump running and dosing
Pulse input**	Pulse input**	Each incoming pulse from pulse input
Contact type		
NO*	NO*	Normally open contact
NC	NC	Normally closed contact

\* Factory setting

\*\* The correct transmission of incoming pulses can only be guaranteed up to a pulse frequency of 5 Hz.

### 6.8.2 External stop

The pump can be stopped via an external contact, e.g. from a control room. When activating the external stop signal, the pump switches from the operating state "Running" into the operating state "Standby". The corresponding symbol appears in the "Signal/error display" area of the display.

Frequent disengagement from the mains voltage, e.g. via a relay, can result in damage to the pump electronics and in the breakdown of the pump. The dosing accuracy is also reduced as a result of internal start procedures.

#### Caution

Do not control the pump via the mains voltage for dosing purposes!

Only use the "External stop" function to start and stop the pump!

The contact type is factory-set to closing contact (NO). In the "Setup > Inputs/Outputs > External stop" menu, the setting can be changed to opening contact (NC).

TM04 8167 0412



TM04 1152 1110



### 6.8.3 Empty and Low level signals



In order to monitor the fill level in the tank, a dual-level control unit can be connected to the pump. The pump responds to the signals as follows:

Fill level sensor	Pump status
Low level	<ul style="list-style-type: none"> <li>• Display is yellow</li> <li>•  flashes</li> <li>• Pump continues running</li> </ul>
Empty	<ul style="list-style-type: none"> <li>• Display is red</li> <li>•  flashes</li> <li>• Pump stops</li> </ul>

#### Caution

When the tank is filled up again, the pump restarts automatically!

Both signal inputs are allocated to the closing contact (NO) in the factory. They can be re-allocated in the "Setup > Inputs/Outputs" menu to opening contact (NC).

### 6.9 Basic settings

All settings can be reset to the settings default upon delivery in the "Setup > Basic settings" menu.

Selecting "Save customer settings" saves the current configuration to the memory. This can then be activated using "Load customer settings".

The memory always contains the previously saved configuration. Older memory data is overwritten.

## 7. Service



In order to ensure a long service life and dosing accuracy, wearing parts such as diaphragms and valves must be regularly checked for signs of wear. Where necessary, replace worn parts with original spare parts made from suitable materials.

Should you have any questions, please contact your service partner.



#### Warning

Maintenance work must only be carried out by qualified staff.

### 7.1 Regular maintenance

Interval	Task
	<p>Check, if liquid leaks from the drain opening (fig. 23, pos. 11) and if the drain opening is blocked or soiled. If so, follow the instructions given in section <a href="#">7.6 Diaphragm breakage</a>.</p>
Daily	<p>Check, if liquid leaks from the dosing head or valves. If necessary, tighten dosing head screws with a torque wrench at 4 Nm. If necessary, tighten valves and cap nuts, or perform service (see <a href="#">7.4 Perform service</a>).</p>
	<p>Check, if a service requirement is present at the pump display. If so, follow the instructions given in section <a href="#">7.3 Service system</a>.</p>
Weekly	<p>Clean all pump surfaces with a dry and clean cloth.</p>
Every 3 months	<p>Check dosing head screws. If necessary, tighten dosing head screws with a torque wrench at 4 Nm. Replace damaged screws immediately.</p>

### 7.2 Cleaning

If necessary, clean all pump surfaces with a dry and clean cloth.

### 7.3 Service system

According to the motor runtime service requirements will appear. Service requirements appear regardless of the current operating state of the pump and do not affect the dosing process. If no service requirement has occurred, service has to be performed at least every two years.

Service requirement	Motor runtime [h]*
Service soon!	7500
Service now!	8000

\* Since the last service system reset




Fig. 21 Service soon!





Fig. 22 Service now!

**Caution** For media which result in increased wear, the service interval must be shortened.

The service requirement signals when the replacement of wearing parts is due and displays the number of the service kit. Press the click wheel to temporarily hide the service prompt.

When the "Service now!" message appears (displayed daily), the pump must be serviced immediately. The  symbol appears in the "Operation" menu.

The number of the service kit required is also displayed in the "Info" menu.

### 7.4 Perform service

Only spare parts and accessories from Grundfos should be used for maintenance. The usage of non-original spare parts and accessories renders any liability for resulting damages null and void.

Further information about carrying out maintenance can be found in the service kit catalog on our homepage [www.grundfos.com](http://www.grundfos.com).

#### Warning

Risk of chemical burns!

When dosing dangerous media, observe the corresponding precautions in the safety data sheets!



Wear protective clothing (gloves and goggles) when working on the dosing head, connections or lines!

Do not allow any chemicals to leak from the pump. Collect and dispose of all chemicals correctly!


Before any work to the pump, the pump must be in the "Stop" operating state or be disconnected from the power supply. The system must be pressureless!



#### 7.4.1 Dosing head overview

TM04 1131 1110

TM04 1131 1110



TM04 1123 2110

Fig. 23 Dosing head, exploded view

1	Safety diaphragm
2	Flange
3	O-ring
4	Diaphragm
5	Valve on discharge side
6	Valve on suction side
7	Dosing head
8	Screws with discs
9	Cover
10	Deaeration valve
11	Drain opening

### 7.4.2 Dismantling the diaphragm and valves

#### Warning

Danger of explosion, if dosing liquid has entered the pump housing!



If the diaphragm is possibly damaged, don't connect the pump to the power supply! Proceed as described in section [7.6 Diaphragm breakage!](#)

This section refers to fig. [23](#).

1. Make system pressureless.
2. Empty dosing head before maintenance and flush it if necessary.
3. Set pump to "Stop" ■ operating state using the [Start/stop] key.
4. Press the [Start/stop] and [100 %] keys at the same time to put the diaphragm into "out" position.
  - Symbol ← must be displayed (see fig. [13](#)).
5. Take suitable steps to ensure that the returning liquid is safely collected.
6. Dismantle suction, pressure and deaeration hose.
7. Dismantle valves on suction and discharge side (5, 6).
8. Remove the cover (9).
9. Loosen screws (8) on the dosing head (7) and remove with discs.
10. Remove the dosing head (7).
11. Unscrew diaphragm (4) counter-clockwise and remove with flange (2).
12. Make sure the drain opening (11) is not blocked or soiled. Clean if necessary.
13. Check the safety diaphragm (1) for wear and damage. Replace if necessary.

If nothing indicates that dosing liquid has entered the pump housing, go on as described in section [7.4.3 Reassembling the diaphragm and valves](#). Otherwise proceed as described in section [7.6.2 Dosing liquid in the pump housing](#).

### 7.4.3 Reassembling the diaphragm and valves

The pump must only be reassembled, if nothing indicates that dosing liquid has entered the pump housing. Otherwise proceed as described in section [7.6.2 Dosing liquid in the pump housing](#).

This section refers to fig. [23](#).

1. Attach flange (2) correctly and screw on new diaphragm (4) clockwise.
  - Make sure that the O-ring (3) is seated correctly!
2. Press the [Start/stop] and [100 %] keys at the same time to put the diaphragm into "in" position.
  - Symbol → must be displayed (see fig. [13](#)).
3. Attach the dosing head (7).
4. Install screws with discs (8) and cross-tighten with a torque wrench.
  - Torque: 4 Nm.
5. Attach the cover (9).
6. Install new valves (5, 6).
  - Do not interchange valves and pay attention to direction of arrow.
7. Connect suction, pressure and deaeration hose (see section [4.2 Hydraulic connection](#)).
8. Press the [Start/stop] key to leave the service mode.

Tighten the dosing head screws with a torque wrench once before commissioning and again after 2-5 operating hours at 4 Nm.

#### Caution

9. Deaerate dosing pump (see section [5.2 Deaerating the pump](#)).
10. Please observe the notes on commissioning in section [5. Startup!](#)

### 7.5 Resetting the service system

After performing the service, the service system must be reset using the "Info > Reset service system" function.

## 7.6 Diaphragm breakage

If the diaphragm leaks or is broken, dosing liquid escapes from the drain opening (fig. 23, pos. 11) on the dosing head.

In case of diaphragm breakage, the safety diaphragm (fig. 23, pos. 1) protects the pump housing against ingress of dosing liquid.

When dosing crystallising liquids the drain opening can be blocked by crystallisation. If the pump is not taken out of operation immediately, a pressure can build up between the diaphragm (fig. 23, pos. 4) and the safety diaphragm in the flange (fig. 23, pos. 2). The pressure can press dosing liquid through the safety diaphragm into the pump housing.

Most dosing liquids don't cause any danger when entering the pump housing. However a view liquids can cause a chemical reaction with inner parts of the pump. In the worst case, this reaction can produce explosive gases in the pump housing.

### Warning

Danger of explosion, if dosing liquid has entered the pump housing!

Operation with damaged diaphragm can lead to dosing liquid entering the pump housing.



In case of diaphragm breakage, immediately separate the pump from the power supply!

Make sure the pump cannot be put back into operation by accident!

Dismantle the dosing head without connecting the pump to the power supply and make sure no dosing liquid has entered the pump housing. Proceed as described in section [7.6.1 Dismantling in case of diaphragm breakage](#).

To avoid any danger resulting from diaphragm breakage, observe the following:

- Perform regular maintenance. See section [7.1 Regular maintenance](#).
- Never operate the pump with blocked or soiled drain opening.
  - If the drain opening is blocked or soiled, proceed as described in section [7.6.1 Dismantling in case of diaphragm breakage](#).
- Never attach a hose to the drain opening. If a hose is attached to the drain opening, it is impossible to recognise escaping dosing liquid.
- Take suitable precautions to prevent harm to health and damage to property from escaping dosing liquid.
- Never operate the pump with damaged or loose dosing head screws.

## 7.6.1 Dismantling in case of diaphragm breakage

### Warning



Danger of explosion, if dosing liquid has entered the pump housing!

Do not connect the pump to the power supply!

This section refers to fig. 23.

1. Make system pressureless.
2. Empty dosing head before maintenance and flush it if necessary.
3. Take suitable steps to ensure that the returning liquid is safely collected.
4. Dismantle suction, pressure and deaeration hose.
5. Remove the cover (9).
6. Loosen screws (8) on the dosing head (7) and remove with discs.
7. Remove the dosing head (7).
8. Unscrew diaphragm (4) counter-clockwise and remove with flange (2).
9. Make sure the drain opening (11) is not blocked or soiled. Clean if necessary.
10. Check the safety diaphragm (1) for wear and damage. Replace if necessary.

If nothing indicates that dosing liquid has entered the pump housing, go on as described in section [7.4.3 Reassembling the diaphragm and valves](#). Otherwise proceed as described in section [7.6.2 Dosing liquid in the pump housing](#).

## 7.6.2 Dosing liquid in the pump housing

### Warning



Danger of explosion!

Immediately separate the pump from the power supply!

Make sure the pump cannot be put back into operation by accident!

If dosing liquid has entered the pump housing:

- Send the pump to Grundfos for repair, following the instructions given in section [7.7 Repairs](#).
- If a repair isn't economically reasonable, dispose of the pump observing the information in section [9. Disposal](#).

## 7.7 Repairs



### Warning

The pump housing must only be opened by personnel authorised by Grundfos!

Repairs must only be carried out by authorised and qualified personnel!

Switch off the pump and disconnect it from the voltage supply before carrying out maintenance work and repairs!

After consulting Grundfos, please send the pump, together with the safety declaration completed by a specialist, to Grundfos. The safety declaration can be found at the end of these instructions. It must be copied, completed and attached to the pump.

The pump must be cleaned prior to dispatch!

### Caution

If dosing liquid has possibly entered the pump housing, state that explicitly in the safety declaration! Observe section [7.6 Diaphragm breakage](#).

If the above requirements are not met, Grundfos may refuse to accept delivery of the pump. The shipping costs will be charged to the sender.

## 8. Faults



In the event of faults in the dosing pump, a warning or an alarm is triggered.


The corresponding fault symbol flashes in the "Operation" menu, see section [8.1 List of faults](#). The cursor jumps to the "Alarm" main menu symbol. Press the click wheel to open the "Alarm" menu and, where necessary, faults to be acknowledged will be acknowledged.

A yellow display indicates a warning and the pump continues running.

A red display indicates an alarm and the pump is stopped.

The last 10 faults are stored in the "Alarm" main menu. When a new fault occurs, the oldest fault is deleted.

The two most recent faults are shown in the display, you can scroll through all the other faults. The cause of the fault is displayed.








TM04 1109 1010

The list of faults can be deleted at the end of the list.

If there is a service requirement, this appears when the "Alarm" menu is opened. Press the click wheel to temporarily close the service prompt (see section [7.3 Service system](#)).

## 8.1 List of faults

### 8.1.1 Faults with error message

Display in the "Alarm" menu	Possible cause	Possible remedy
 Empty (Alarm)	<ul style="list-style-type: none"> <li>Dosing medium tank empty</li> </ul>	<ul style="list-style-type: none"> <li>Fill tank.</li> <li>Check contact setting (NO/NC).</li> </ul>
 Low level (Warning)	<ul style="list-style-type: none"> <li>Dosing medium tank almost empty</li> </ul>	
 Motor blocked (Alarm)	<ul style="list-style-type: none"> <li>Backpressure greater than nominal pressure</li> <li>Damage to gears</li> </ul>	<ul style="list-style-type: none"> <li>Reduce backpressure.</li> <li>Arrange for repair to drive if necessary.</li> </ul>
 Cable break (Alarm)	<ul style="list-style-type: none"> <li>Defect in analog line 4-20 mA (input current &lt; 2 mA)</li> </ul>	<ul style="list-style-type: none"> <li>Check line/plug connections and replace, if necessary.</li> <li>Check signal transmitter.</li> </ul>
 Service now (Warning)	<ul style="list-style-type: none"> <li>Time interval for service expired</li> </ul>	<ul style="list-style-type: none"> <li>Perform service (see section <a href="#">7.4 Perform service</a>).</li> </ul>

### 8.1.2 General faults

Fault	Possible cause	Possible remedy	
Dosing flow too high	Inlet pressure greater than backpressure	Install additional spring-loaded valve (approx. 3 bar) on the discharge side. Increase pressure differential.	
	Incorrect calibration	Calibrate the pump (see section <a href="#">5.3 Calibrating the pump</a> ).	
No dosing flow or dosing flow too low	Air in dosing head	Deaerate the pump.	
	Faulty diaphragm	Change the diaphragm (see section <a href="#">7.4 Perform service</a> ).	
	Leakage/fracture in lines	Check and repair lines.	
	Valves leaking or blocked	Check and clean valves.	
	Valves installed incorrectly	Check that the arrow on the valve housing is pointing in the direction of flow. Check whether all O-rings are installed correctly.	
	Blocked suction line	Clean suction line/install filter.	
	Suction lift too high		Reduce suction lift. Install priming aid.
			Enable "SlowMode" (see section <a href="#">6.5 SlowMode</a> ).
	Viscosity too high		Enable "SlowMode" (see section <a href="#">6.5 SlowMode</a> ).
			Use hose with larger diameter. Install spring-loaded valve on the discharge side.
Irregular dosing	Faulty calibration	Calibrate the pump (see section <a href="#">5.3 Calibrating the pump</a> ).	
	Deaeration valve open	Close the deaeration valve.	
Liquid escaping from the drain opening on the flange	Valves leaking or blocked	Tighten up valves, replace valves if necessary (see section <a href="#">7.4 Perform service</a> ).	
	Backpressure fluctuations	Keep backpressure constant.	
	Faulty diaphragm	Immediately separate the pump from the power supply! Observe section <a href="#">7. Service</a> and especially section <a href="#">7.6 Diaphragm breakage</a> .	

Fault	Possible cause	Possible remedy
Liquid escaping	Dosing head screws not tightened	Tighten up screws (see section <a href="#">4.2 Hydraulic connection</a> ).
	Valves not tightened	Tighten up valves/union nuts (see section <a href="#">4.2 Hydraulic connection</a> ).
Pump not sucking in	Suction lift too high	Reduce suction lift, if necessary provide positive inlet pressure.
	Backpressure too high	Open the deaeration valve.
	Soiled valves	Flush system, replace valves if necessary (see section <a href="#">7.4 Perform service</a> ).

## 9. Disposal



This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.



The crossed-out wheeled bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local

waste disposal authorities. The separate collection and recycling of such products will help protect the environment and human health.

See also end-of-life information at [www.grundfos.com/product-recycling](http://www.grundfos.com/product-recycling).


## 中国 RoHS

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴联苯醚 (PBDE)
泵壳	X	O	O	O	O	O
印刷电路板	X	O	O	O	O	O
紧固件	X	O	O	O	O	O
管件	X	O	O	O	O	O
定子	X	O	O	O	O	O
转子	X	O	O	O	O	O

本表格依据 SJ/T 11364 的规定编制

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。  
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 该规定的限量要求。

 该产品环保使用期限为 10 年，标识如左图所示。  
此环保期限只适用于产品在安装与使用说明书中所规定的条件下工作





**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garin  
1619 - Garin Pcia. de B.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb  
Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomsesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в  
Минске 220125, Минск ул.  
Шафарнянская, 11, оф. 56, БЦ «Порт»  
Тел.: +375 17 397 397 3  
+375 17 397 397 4  
Факс: +375 17 397 397 1  
E-mail: minsk@grundfos.com

**Bosnia and Herzegovina**

GRUNDFOS Sarajevo  
Zmaja od Bosne 7-7A,  
BH-71000 Sarajevo  
Phone: +387 33 592 480  
Telefax: +387 33 590 465  
www.ba.grundfos.com  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo  
Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China**

**Grundfos Alldos**  
**Dosing & Disinfection**  
ALLDOS (Shanghai) Water Technology  
Co. Ltd.  
West Unit, 1 Floor, No. 2 Building (T 4-2)  
278 Jinhui Road, Jin Qiao Export  
Processing Zone  
Pudong New Area  
Shanghai, 201206  
Phone: +86 21 5055 1012  
Telefax: +86 21 5032 0596  
E-mail:  
grundfosalldos-CN@grundfos.com

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
10F The Hub, No. 33 Suhong Road  
Minhang District  
Shanghai 201106  
PRC  
Phone: +86-21 6122 5222  
Telefax: +86-21 6122 5333

**COLOMBIA**

GRUNDFOS Colombia S.A.S.  
Km 1.5 via Siberia-Cota Conj. Potrero  
Chico,  
Parque Empresarial Arcos de Cota Bod.  
1A,  
Cota, Cundinamarca  
Phone: +57(1)-2913444  
Telefax: +57(1)-8764586

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Buzinski prilaz 38, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.hr.grundfos.com

**GRUNDFOS Sales Czechia and****Slovakia s.r.o.**

Čapkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumput AB  
Trukkikuja 1  
FI-01360 Vantaa  
Phone: +358-(0)207 889 500

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS Water Treatment GmbH  
Reetzstraße 85  
D-76327 Pfinztal (Söllingen)  
Tel.: +49 7240 61-0  
Telefax: +49 7240 61-177  
E-mail: gwt@grundfos.com

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
E-mail: infoservice@grundfos.de  
Service in Deutschland:  
E-mail: kundendienst@grundfos.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Tópark u. 8  
H-2045 Törökbálint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private  
Limited  
118 Old Mahabalipuram Road  
Thoraiappakkam  
Chennai 600 097  
Phone: +91-44 4596 6800

**Indonesia**

PT. GRUNDFOS POMPA  
Graha Intirub Lt. 2 & 3  
Jln. Cillilitan Besar No.454. Makasar,  
Jakarta Timur  
ID-Jakarta 13650  
Phone: +62 21-469-51900  
Telefax: +62 21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
1-2-3. Shin-Miyakoda, Kita-ku  
Hamamatsu  
431-2103 Japan  
Phone: +81 53 428 4760  
Telefax: +81 53 428 5005

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de  
C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос Россия  
ул. Школьная, 39-41  
Москва, RU-109544, Russia  
Тел. (+7) 495 564-88-00 (495)  
737-30-00  
Факс (+7) 495 564 8811  
E-mail grundfos.moscow@grundfos.com

**Serbia**

Grundfos Srbija d.o.o.  
Omladinskih brigada 90b  
11070 Novi Beograd  
Phone: +381 11 2258 740  
Telefax: +381 11 2281 769  
www.rs.grundfos.com

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovakia**

GRUNDFOS s.r.o.  
Prievozská 4D  
821 09 BRATISLAVA  
Phona: +421 2 5020 1426  
sk.grundfos.com

**Slovenia**

GRUNDFOS LJUBLJANA, d.o.o.  
Leskoškova 9e, 1122 Ljubljana  
Phone: +386 (0) 1 568 06 10  
Telefax: +386 (0)1 568 0619  
E-mail: tehnika-si@grundfos.com

**South Africa**

Grundfos (PTY) Ltd.  
16 Lascelles Drive, Meadowbrook Estate  
1609 Germiston, Johannesburg  
Tel.: (+27) 10 248 6000  
Fax: (+27) 10 248 6002  
E-mail: lgradidge@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentequilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloein Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd.  
Sti.  
Gebze Organize Sanayi Bölgesi  
İhsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

Бізнес Центр Європа  
Столичне шосе, 103  
м. Київ, 03131, Україна  
Телефон: (+38 044) 237 04 00  
Факс.: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971-4- 8815 166  
Telefax: +971-4-8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
9300 Loiret Blvd.  
Lenexa, Kansas 66219  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Grundfos Tashkent, Uzbekistan The  
Representative Office of Grundfos  
Kazakhstan in Uzbekistan  
38a, Oybek street, Tashkent  
Телефон: (+998) 71 150 3290 / 71 150  
3291  
Факс: (+998) 71 150 3292

Addresses revised 31.03.2020

**95726994** 0520

ECM: 1285312

Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and "be think innovate" are registered trademarks owned by The Grundfos Group. All rights reserved. © 2020 Grundfos Holding A/S, all rights reserved.