

Service instructions

CRT 8 and 16

Produced after 0404 (yyww)

50/60 Hz, IEC


1/3~

Contents

1.	Type identification	2
1.1	Nameplate.....	2
1.2	Type key	3
1.3	Code for shaft seal.....	4
2.	Torques and lubricants.....	5
3.	Service tools.....	6
3.1	Special tools	6
3.2	Standard tools	6
3.3	Torque tools	7
4.	Dismantling and assembly	8
4.1	Transport bracket	9
4.2	Dismantling the pump.....	11
4.3	Mounting.....	12
4.4	Replacing the shaft seal of pumps with spacer coupling.....	13
4.5	Checking and replacing impellers/wear rings and neck rings.....	14
4.6	Order of assembly for chambers and impellers.....	15

1. Type identification

1.1 Nameplate



Pos.	Description	Pos.	Description
1	Type designation	10	Country of production
2	Model	11	Frequency
3	Product number	12	Speed
4	Place of production	13	Rated flow rate
5	Production year and week	14	Maximum pressure and temperature
6	P ₂	15	The number of the copy of the technical file kept at KEMA (stated if the pump is ATEX classified)
7	Closed valve head, 50 Hz	16	The serial number of the pump (stated if the pump is ATEX classified)
8	Head at rated flow rate, 50 Hz	17	ATEX category (stated if the pump is ATEX classified)
9	Direction of rotation CCW: Counter-clockwise CW: Clockwise		

1.2 Type key

Example	CRT	5 -	10	AE-	FGJ-	A-	E-	AUUE
Type range								
Rated flow rate m ³ /h								
Number of stages								
Code for pump version								
<p>A = Basic version B = Oversize motor E = Certificate/approval F = Pump for high temperatures (air-cooled top) H = Horizontal version HS = High-pressure pump with over-synchronous speed and reversed chamber stack and direction of rotation I = Different pressure rating K = Pump with low NPSH M = Magnetic drive P = Undersize motor R = Horizontal version with bearing bracket SF = High-pressure pump with reversed chamber stack and direction of rotation T = Oversize motor (two flange sizes bigger) X = Special version, or the pump consists of more than two versions</p>								
Code for pipe connections								
<p>A = Oval flange B = NPT-thread CA = FlexiClamp (CRI,CRN) CX = TriClamp (CRI,CRN) F = DIN flange FGJ = DIN, ANSI and JIS flange GJ = ANSI and JIS flange G = ANSI flange J = JIS flange N = Different connection diameter O = Externally threaded, union P = PJE coupling W = Internally threaded X = Special version</p>								
Code for materials								
<p>A = Pump head: Cast iron Other parts in contact with the pumped liquid: stainless steel DIN W.-Nr. 1.4301 D = Carbon-graphite filled PTFE (bearings) G = Stainless steel parts of DIN W.-Nr. 1.4401 / AISI 316 or better class GI = Base plate and flanges of DIN W.-Nr. 1.4408 / AISI 316LN or better class I = Stainless steel parts of DIN W.-Nr. 1.4301 / AISI 304 or similar class II = All part of stainless steel; parts in contact with the pumped liquid of DIN W.-Nr. 1.4301/ AISI 304 K = Bronze (bearings) S = Silicon carbide bearings and PTFE neck rings (standard in CR) T = Titanium X = Special version</p>								
Code for rubber parts								
<p>E = EPDM (ethylene propylene) F = FXM (polytetrafluorethylene and propylene) K = FFKM (perfluor) P = NBR (nitrile) T = PTFE (polytetrafluorethylene) V = FKM (fluor)</p>								
Code for shaft seal, see 1.3 Code for shaft seal .								

1.3 Code for shaft seal

The code for shaft seal always consists of four letters.

Example	A	U	U	E
Principal Grundfos type designation for shaft seal	1			
Material, rotating seal face	2			
Material, stationary seat	3			
Material, secondary seal	4			

The following codes are used:

Position	Code	Description
1	A	O-ring seal with fixed driver
2	U	Cemented tungsten carbide
and 3	Q	Silicon carbide
4	E	EPDM
	F	FXM
	K	FFKM

2. Torques and lubricants


Pos.	Designation	Quantity	Dimensions	Torque [Nm]	Lubricant
7.a	Screw	4	M4		-
			M6	13	
9	Hexagon socket head screw	4	M8	31	Thread-Eze
			M10	62	
18	Air vent screw	1	½"	35	-
	Air vent screw, spindle	1	M8		
23	Plug	1	½"	35	-
25	Priming valve	1	½"	35	-
	Priming valve, spindle	1	M10	5	
26	Staybolt	4	M16		Gardolube L 6034
26b	Hexagon socket head screw	2	M8	12	-
			M6	10	
			M8	12	
28	Hexagon head screw	4	¾" UNC	23	Thread-Eze
			M12	40	
			½" UNC	40	
			M16	80	
36	Nut for staybolt	4	M16	100	Gardolube L 6034
37	O-ring	2	ø170,7 x 3,3		Rocol 22
47a	Bearing ring	-	-	-	Rocol 22
67	Castle nut	1	M12	40	Gardolube L 6034
100	O-ring	1	16.3 x 2.4		Rocol 22
105	Shaft seal	1			Soapy water
107	Plug	1	M33	35	-

Thread-Eze, part no. SV9997 (0.5 l).

Gardolube L 6034, part no. SV9995 (1 l).

Rocol 22 (SAPPHIRE AGUA SIL), part no. RM2924 (1 kg).

3. Service tools



3.1 Special tools

Pos.	Designation	For pos.	Description	Part number
A	Shaft holder for assembly	80		SV0040
B	Ring insert tool for shaft seal + square adapter	105		SV2101 SV2100
C	Puller for neck ring	49, 65		SV0239

3.2 Standard tools

Pos.	Designation	For pos.	Description	Part number
D	Bits kit	9, 26b, 113		SV2010
E	Screwdriver	105	Straight slot	-
		7a	Torx TX20	-
F	Ring/open-end spanner	28, 36	M6 - 10 mm	SV0083
			M8 - 13 mm	SV0055
			M12 - 19 mm	SV0054
			½" UNC - 19 mm	
			M16 - 24 mm	SV0122
G	Socket	28, 36	M6 - 10 mm	SV0806
			M8 - 13 mm	SV0091
			M12 - 19 mm	SV0267
			½" UNC - 19 mm	
			M16 - 24 mm	SV0092
H	Plastic hammer	2	No. 2	SV0349

3.3 Torque tools

Pos.	Designation	For pos.	Description	Part number
I	Torque wrench	9, 26b, 28, 36, 105, 113	1-6 Nm	SV0438
			4-20 Nm	SV0292
			20-100 Nm	SV0269
J	Ratchet insert tool	H	9 x 12, ½" x ½"	SV0295

4. Dismantling and assembly

Position numbers

Position numbers of parts (digits) refer to exploded views, sectional drawings and parts lists; position numbers of tools (letters) refer to [3. Service tools](#).

Before dismantling

- Disconnect the electricity supply to the motor.
- Close the isolating valves, if fitted, to avoid draining the system.
- Remove the electric cable in accordance with local regulations.
- Note the centre of gravity of the pump to prevent it from overturning. This is especially important in the case of long pumps.

Before assembly

O-rings should always be replaced when the pump is overhauled.

- Clean and check all parts.
- Order the necessary service kits.
- Replace defective parts by new parts.

During assembly

- Lubricate and tighten screws and nuts to the torque stated, see [2. Torques and lubricants](#).

4.1 Transport bracket

To protect the bearings and the shaft seal, a transport bracket must always be used when transporting the pump without motor.




Fig. 1 Transport bracket for small flange sizes




Fig. 2 Transport bracket for large flange sizes

Flange size	Fig. 1		Fig. 2		Hexagon head screw		Nut
	Transport bracket complete pos. 700	Shaft stub pos. 701	Rail pos. 702	pos. 703 (2 pcs.)	pos. 704 (2 pcs.)		
F85	96521627	-	-	ID8022	M6 x 20	96429513	
F100	96521627	-	-	ID8023	M6 x 25	96429513	
F115	96521626	-	-	ID8024	M8 x 20	ID0825	
F130	96521626	-	-	ID8025	M8 x 25	ID0825	
F265	-	96508079	96508073	ID7904	M12 x 30	None	
F300	-	96508080	96508073	ID7905	M16 x 45	ID7908	
56C	-	96508075	96508072	ID1839	UNC 3/8" x 25	96120884	
182TC	-	96508076	96508074	ID1840	UNC 1/2" x 25	96467385	
213TC	-	96508077	96508074	ID0185	UNC 1/2" x 1 1/2"	96467385	
254TC	-	96508078	96508074	96491112	UNC 1/2" x 2 1/2"	96467385	
284TSC	-	96508078	96508074	ID1840	UNC 1/2" x 25	96467385	


4.1.1 Fitting the transport bracket

1. Press home the shaft pos. 51.
2. Press home the driver of the shaft seal pos. 105 and tighten the three screws pos. 113.
3. Lift the shaft pos. 51 and fit the adjusting fork.
4. Fit the coupling pos. 8 and the screws pos. 9, but leave loose.
5. Fit the transport bracket.
6. Fit the two screws and nuts pos. 703 and 704, but leave loose.
7. Tighten the screws pos. 9 in the coupling.
The coupling must be fitted so that it is possible to remove it without slackening the screws pos. 703.
8. Tighten the screws pos. 703.
9. Remove the adjusting fork.
10. The pump can now be transported without motor.

4.1.2 Removing the transport bracket

It is very important to proceed according to these instructions, as the shaft seal may otherwise be damaged.


1. Remove the screws pos. 9.
2. Slacken the last screw pos. 9, but do not unscrew it completely.
3. Hit the end of the hexagon key carefully with the flat of the hand to loosen one of the coupling halves.
4. Remove the last screw pos. 9 and the loose coupling half.
5. Hit the flat part of the coupling half on the shaft end very carefully.
6. Remove the coupling half when it is loose.
7. Remove the screws pos. 703 and the nuts pos. 704 and remove the transport bracket.
8. Fit the motor to the pump head.
9. Fit the screw pos. 28, lubricate and tighten them diagonally to the torque stated, see [2. Torques and lubricants](#).
10. Fit the pin pos. 10 and the two coupling halves pos. 10a.
11. Lubricate the four screws pos. 9 with Thread-Eze and fit them.
12. Yellow-chromated couplings: Check that the gaps either side of the coupling halves are equal.



TM02 0462 0000

Fig. 3 Gaps between coupling halves

13. Place a screwdriver between the coupling and the plug pos. 107.
14. Lift the shaft/coupling as far as possible and lower the shaft/coupling to half that height.



TM02 1051 2303

Fig. 4 Adjustment of chamber stack

15. Hold the shaft/coupling in this position and tighten the four screws in the coupling pos. 9 diagonally to the torque stated, see [2. Torques and lubricants](#).
16. Check that the shaft rotates freely and noiselessly.
17. Fit the coupling guards pos. 7 and the screws pos. 7a.

4.2 Dismantling the pump

4.2.1 Removing the motor and coupling

1. Remove the screws pos. 7a together with the coupling guards pos. 7.
2. Remove the screws pos. 9 together with the coupling halves pos. 10a and the shaft pin pos. 10.
3. Remove the screws pos. 28.
4. Lift the motor off the pump head pos. 2.

4.2.2 Removing the pump main parts and the shaft seal

1. Remove the plug pos. 107.
2. Remove the nuts pos. 36 together with the washers pos. 66a.
3. Loosen the pump head pos. 2 with a light knock on the edge and lift it free of the staybolts pos. 26.
4. Remove the shaft seal pos. 105.
5. Remove the outer sleeve pos. 55.
6. Lift the chamber stack off the base.
7. Remove the O-rings pos. 37.

4.2.3 Dismantling the chamber stack

1. Place the shaft holder [pos. A](#) in a vice, but do not tighten the vice.
2. Fit the shaft pin pos. 10 into the shaft pin hole and place the chamber stack in the shaft holder [pos. A](#) and tighten the vice.




Fig. 5 Fitting the chamber stack in the holder

3. Remove the screws pos. 26b and the washers pos. 26c holding the straps to the chamber stack.
4. Remove the straps pos. 26a and the inlet parts pos. 44b and 44a.
5. Remove the split pin pos. 67a, the nut pos. 67 and the splined clamp pos. 64c.
6. Remove the chamber stack parts: impellers, spacing pipes, chambers and bearing rings, see [4.6 Order of assembly for chambers and impellers](#).
7. Remove the driver pos. 61.
8. If the neck rings pos. 45 in the chambers are worn, remove them by pressing off the retainer for neck rings using the puller for neck ring [pos. C](#).
9. If the wear rings of the impellers pos. 49a are worn, remove them with the puller for neck ring [pos. C](#).

4.3 Mounting

4.3.1 Assembling the chamber stack

1. Fit the neck rings into the chambers pos. 45 if removed.
2. Fit the wear rings on the impellers pos. 49a if removed.
3. Place the shaft holder [pos. A](#) in a vice, but do not tighten the vice.
4. Fit the shaft pin pos. 10 into the shaft pin hole, place the chamber stack in the shaft holder and tighten the vice.
5. Check that the lock ring of the shaft pos. 51 is not damaged.
6. Fit the driver pos. 61.
7. Fit the chamber stack parts on the shaft: chamber, spacing pipe, impeller and bearing ring, see [4.6 Order of assembly for chambers and impellers](#).
Note: When fitting the chamber stack make sure that bearings and other rotating parts are not dropped on the shaft. They must be slid carefully over the shaft to prevent any damage to bearings.
8. Fit the splined clamp pos. 66 and the nut pos. 67 and tighten with 40 Nm.
9. Fit the inlet parts pos. 44a and 44b and the straps pos. 26a.
10. Fit the split pin pos. 67a.
11. Fit the washers pos. 26c and the screws pos. 26b holding the straps to the chamber stack.
12. Check that the straps are straight (parallel with the shaft), and tighten the screws alternately to ensure that the chamber stack is clamped straight. Tighten with 12 Nm.
13. Slacken the vice and remove the chamber stack pos. 80 and the shaft pin pos. 10.

4.3.2 Assembling the pump main parts

1. Assemble the chamber stack, see [4.3.1 Assembling the chamber stack](#).
2. Fit the O-ring pos. 37 in the pump head pos. 2 and in the base pos. 6 and lubricate them with Rocol 22.
3. Fit the chamber stack on the base taking care that the heads of the screws for straps do not touch the inlet pipe in the base.
4. Fit the outer sleeve pos. 55 in the base and press it home in the base.
5. Fit the shaft seal pos. 105. If necessary, clean and smooth the shaft end using the holder with emery cloth supplied with the shaft seal kit.
6. Check that the four rubber springs pos. 60 are in the pump head.
7. Fit the pump head on the pump with the air vent screw pos. 18 towards the discharge side.
8. Lubricate the threads of the staybolts pos. 26, see [2. Torques and lubricants](#).
9. Fit the washers pos. 66a and the nuts pos. 36.
10. Tighten the nuts pos. 36 diagonally to the torque stated, see [2. Torques and lubricants](#).

4.3.3 Fitting the motor and coupling

1. Press the O-ring pos. 106 and the plug pos. 107 down on the shaft, screw the plug into the pump head and tighten with 35 Nm using the ring insert tool for shaft seal [pos. B](#).
2. Fit the motor to the pump head.
3. Fit the screw pos. 28, lubricate and tighten them diagonally to the torque stated, see [2. Torques and lubricants](#).
4. Fit the pin pos. 10 and the two coupling halves pos. 10a.
5. Lubricate the four screws pos. 9 with Thread-Eze and fit them.
6. Check that the gaps either side of the coupling halves are equal.




Fig. 6 Gaps between coupling halves

TM02 0462 4600

7. Place a screwdriver between the coupling and the top ring for shaft seal.
8. Lift the shaft/coupling as far as possible and lower the shaft/coupling to half that height.




Fig. 7 Adjustment of chamber stack

9. Hold the shaft/coupling in this position and tighten the four screws in the coupling pos. 9 diagonally to the torque stated, see [2. Torques and lubricants](#).
10. Check that the gaps either side of the coupling halves are equal.
11. Check that the shaft rotates freely and noiselessly.
12. Fit the coupling guard pos. 7 and the screws pos. 7a.

4.4 Replacing the shaft seal of pumps with spacer coupling

4.4.1 Dismantling

1. Remove the screws pos. 7a together with the coupling guards pos. 7.
2. Remove the screws pos. 9 together with the coupling halves pos. 10a and the shaft pin pos. 10.
3. Slacken the three screws of the shaft seal pos. 113 by approx. ¼ of a turn.
4. Slacken the shaft seal pos. 105 using the ring insert tool for shaft seal [pos. B](#) until the thread is completely free of the pump head.
5. Pull the shaft seal off the shaft.

4.4.2 Mounting

1. If necessary, clean and smooth the shaft end using the holder with emery cloth supplied with the shaft seal kit.
2. Moisten the shaft end with soapy water.
3. Press the shaft seal on the shaft, screw it into the pump head and tighten it with 35 Nm.
4. Press the ring with the three set screws pos. 113 against the hexagon plug.
5. Tighten the screws pos. 113 with 2.5 Nm.
6. Lift the chamber body by inserting a screwdriver or similar tool in the hole for the pin in the shaft and fit the adjusting fork, which is fitted to one of the coupling guards pos. 7.




Fig. 8 Fitting the adjusting fork

7. Fit the pin pos. 10 and the two coupling halves pos. 10a.
8. Lubricate and fit the four screws pos. 9.

9. Yellow-chromated couplings: Check that the gaps either side of the coupling halves are equal.




Fig. 9 Gaps between coupling halves

10. Tighten the screws to the torque stated, see [2. Torques and lubricants](#), and remove the adjusting fork.
11. Check that the shaft rotates freely and noiselessly.
12. Place the adjusting fork on the inside of one of the coupling guards.
13. Fit the coupling guard pos. 7 and the screws pos. 7a.

4.5 Checking and replacing impellers/wear rings and neck rings

Impellers/wear rings

1. Check if there is a noticeable groove in the impeller skirts (CRT 8) or wear rings (CRT 16) caused by friction (use a finger nail).
2. If there is a groove, the impellers/wear rings must be replaced. The wear rings can be removed by means of the puller for neck ring [pos. C](#).

Neck rings

The neck rings pos. 65 should always be replaced if the chamber stack has been dismantled.

1. Push the retainer for neck ring free of the chamber using the puller for neck ring [pos. C](#).
2. Remove the neck ring pos. 45.
3. Fit a new neck ring in the chamber.




Fig. 10 Correct fitting of neck ring



4. Press the retainer for neck ring down on the neck ring and make it engage with the chamber. It must be possible to move the neck ring freely (sideways) between the retainer and the chamber.

Bearing rings



1. Check whether there is a visible or noticeable (use a finger nail) edge on the rotating bearing rings.
2. The bearing rings pos. 47a and the chambers with bearing ring pos. 4a must be replaced at the same time.

4.6 Order of assembly for chambers and impellers

CRT 8



TMO2 8126-4703



TM02 8127 4703