

## HYDRO 2000 PFU

## Quick Guide

### 1 Before starting



Do not start the booster set until it has been filled with water and vented.

### 2 Start/stop



Switch the electricity supply on and off by means of the switch on the control box. The pumps will start approx. 15 secs. after the electricity supply has been switched on.

### 3 PFU 2000 front cover




	STOP	The electricity supply is switched off.
		At least one pump is in operation. No faults.
	STOP	All pumps have been stopped. The pumps are ready for operation. No faults.
	STOP	All pumps have been stopped due to a fault.
	STOP	At least one pump is or has been stopped due to a fault. At least one pump is in operation.
	STOP	All pumps have been stopped. At least one pump is or has been stopped due to a fault. All other pumps are ready for operation.

Flashes.



## 4 Setpoint setting



## 5 Settings

### Factory setting

Date	Setpoint

### Customer settings

Date	Setpoint	Initials

96 40 91 90 0303	GB
Repl. V7 12 57 00 0497	

Subject to alterations.